

Whaply B09GN8PCC8

Whaply Mini LED Flashlights Instruction Manual

Model: B09GN8PCC8

INTRODUCTION

Welcome to your Whaply Mini LED Flashlights. This manual provides essential information for the safe and effective use of your new flashlights. These portable aluminum flashlights are designed for various uses, including night reading, camping, emergencies, and general illumination.



Figure 1: Versatile applications of the Whaply Mini LED Flashlight.




Figure 2: Whaply Mini LED Flashlight used for reading.

SETUP

Battery Installation

Your Whaply Mini LED Flashlights come with 3 AAA batteries pre-installed in each unit. To access or replace the batteries:

1. Unscrew the tail cap of the flashlight by turning it counter-clockwise.
2. Carefully remove the battery holder from the flashlight body.
3. Insert three AAA batteries into the holder, ensuring correct polarity (the positive (+) end of the battery should align with the positive (+) marking on the holder).
4. Place the battery holder back into the flashlight body, ensuring it is fully seated.
5. Screw the tail cap back on securely by turning it clockwise until snug. Do not overtighten.



Swicth Button



LED



Lanyard



Battery Holder


Each Flashlight Requires
(3) AAA Batteries(Included)

Durable
Slip Proof
Aluminum Body

Figure 3: Disassembled flashlight showing battery holder and components.

Bright Illumination

MAX 30-Lumen of bright light from premium LEDs



*Contact us to get No-Question Asked Replacement or Refund for defective flashlights

Figure 4: Flashlight features including the switch button and performance metrics.

OPERATING INSTRUCTIONS

Turning On/Off

To turn the flashlight on or off, firmly press the rubber button located on the tail cap. Each press will toggle the power state.

Lanyard Use

Each flashlight includes a lanyard for convenient carrying and to help prevent accidental drops. Attach the lanyard to the small loop located on the tail cap for secure handling.

MAINTENANCE

Cleaning

Wipe the flashlight body with a soft, dry cloth to remove dust or dirt. Do not use abrasive cleaners, solvents, or immerse the flashlight in water, as this may damage the internal components and finish.

Battery Care

If the flashlight will not be used for an extended period (e.g., several weeks or months), it is recommended to remove the AAA batteries. This prevents potential battery leakage, which can corrode and damage the flashlight's internal circuitry.

Durability

The flashlight features a durable aluminum body designed to withstand minor drops and bumps during normal use. While robust, avoid excessive force or impact to maintain optimal performance.

TROUBLESHOOTING

Problem	Solution
Flashlight does not turn on	• Check if batteries are inserted correctly with proper polarity. • Ensure the tail cap is screwed on tightly, as a loose connection can prevent operation. • Replace batteries if they are depleted.
Light is dim or flickers	• Replace the AAA batteries with fresh ones. • Ensure the tail cap is screwed on tightly to ensure a stable electrical connection.

If problems persist after attempting these solutions, please contact customer support for further assistance.

SPECIFICATIONS

- Brand:** Whaply
- Model:** Mini LED Flashlight (B09GN8PCC8)
- Light Source:** LED
- Power Source:** 3 x AAA Batteries (Included)
- Material:** Aluminum
- Special Features:** Lightweight, Portable
- Brightness:** Up to 30 Lumens
- Runtime:** Approximately 30 hours (based on FL 1 Standard)
- Beam Distance:** Approximately 61 meters (based on FL 1 Standard)
- Dimensions:** Approximately 3.34 inches (length) x 1.06 inches (diameter)
- Colors:** Assorted (Black, Blue, Red, Purple, Yellow, Silver)



Figure 5: Flashlight dimensions compared to a credit card.

Six kinds of color

BLACK

BLUE

RED

PURPLE

YELLOW

SILVER



Figure 6: Available flashlight colors.

WARRANTY AND SUPPORT

Warranty Information

Whaply offers a 1-year warranty from the date of purchase and a 30-day satisfaction or return guarantee for these flashlights. This warranty covers manufacturing defects under normal use.

Customer Support

For any issues, questions, or warranty claims, please contact us directly via Amazon email. Our customer support team is available to assist you with product inquiries and troubleshooting.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09GN8PCC8>

More documents and user manuals: **<https://manuals.plus/>**