

DR1TECH DR10030

DR1TECH Hunter Professional Gaming Mouse User Manual

Model: DR10030

PRODUCT OVERVIEW

The DR1TECH Hunter is a powerful USB gaming mouse designed for professional gamers. It features an adjustable and compact weight system, an ergonomic design for extended gaming sessions, and 9 programmable buttons. This mouse is engineered to adapt to various playing styles, offering precision and comfort. Its braided fabric cable ensures smooth movement without hindrance. The integrated rainbow LED effect enhances the gaming experience. It is compatible with Windows, Mac, PlayStation, and Xbox systems.

KEY FEATURES

- **Adjustable DPI:** Features 8 available DPI levels (400 to 4200 DPI) for precise control and adaptability during gameplay.
- **Ergonomic Design:** Smooth, matte surface and shape designed for comfortable grip during long gaming or working sessions.
- **Weight Adjustment System:** Includes 5 removable weights for customizable balance and feel.
- **9 Programmable Buttons:** Reactive buttons can be adjusted to match individual playing styles, including a triple fire function.
- **Wired USB Connection:** Ensures maximum speed in data transfer with no input lag and a high query rate.
- **Durable Cable:** Braided fabric cable for improved movement and longevity.
- **Rainbow LED Effect:** Customizable lighting to enhance the gaming atmosphere.

SETUP GUIDE

Package Contents

- DR1TECH Hunter Professional Gaming Mouse
- User Manual

Connecting Your Mouse

To set up your DR1TECH Hunter gaming mouse, follow these simple steps:

1. Unpack the gaming mouse from its packaging.
2. Locate an available USB port on your computer (PC, Mac, PlayStation, or Xbox).

3. Insert the USB connector of the DR1TECH Hunter mouse firmly into the USB port.
4. The mouse should be automatically recognized by your operating system. Drivers will typically install automatically.
5. Once installed, the mouse's LED lighting will activate, indicating it is ready for use.





Image: Top view of the DR1TECH Hunter Professional Gaming Mouse, showcasing its design and red LED lighting. This is the primary view of the mouse when connected and in operation.

OPERATING INSTRUCTIONS

Button Functions

The DR1TECH Hunter mouse features 9 programmable buttons designed for enhanced gaming control. While specific programming requires compatible software (not included), the default functions are as follows:

- **Left Click:** Primary action button.
- **Right Click:** Secondary action button, often for context menus.
- **Scroll Wheel:** For scrolling up and down, also functions as a clickable middle button.
- **DPI Cycle Button:** Changes the mouse sensitivity (DPI) on the fly.
- **Forward/Backward Buttons:** Located on the side, typically for navigation in web browsers or applications.
- **Triple Fire Button:** Executes multiple clicks with a single press, useful in gaming.
- **Additional Programmable Buttons:** Two additional buttons for custom assignments.

Adjusting DPI (Sensitivity)

The Hunter mouse allows you to adjust its sensitivity (DPI) to match your preference and game requirements. Press the dedicated DPI cycle button (usually located behind the scroll wheel) to cycle through the available DPI settings: 400, 800, 1600, 2400, 3200, and 4200 DPI. Each change will typically be indicated by a change in the mouse's LED lighting or a brief visual cue.

Weight Adjustment System

The DR1TECH Hunter mouse includes a weight adjustment system to customize its feel and balance. This system consists of 5 removable weights located in a compartment on the underside of the mouse.

1. Gently open the weight compartment cover on the bottom of the mouse.
2. Add or remove the desired weights to achieve your preferred mouse feel and balance.
3. Securely close the weight compartment cover.



Image: Underside view of the DR1TECH Hunter mouse, highlighting the removable weight compartment. This allows users to customize the mouse's feel and balance.

MAINTENANCE AND CARE

Cleaning

To ensure the longevity and optimal performance of your DR1TECH Hunter mouse, regular cleaning is recommended:

- Disconnect the mouse from your computer before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the surface of the mouse.
- Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the mouse.
- For optical sensor cleaning, use a cotton swab lightly dampened with rubbing alcohol to gently clean the sensor area on the underside of the mouse.
- Allow the mouse to dry completely before reconnecting it.

Storage

When not in use for extended periods, store your mouse in a clean, dry environment away from direct sunlight and extreme temperatures. Avoid placing heavy objects on the mouse or bending its cable sharply.

TROUBLESHOOTING

If you encounter issues with your DR1TECH Hunter gaming mouse, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Mouse not responding	Loose USB connection, faulty USB port, driver issue.	Ensure USB cable is fully inserted. Try a different USB port. Restart your computer. Check Device Manager for driver issues.
DPI not changing	DPI button malfunction, software conflict.	Press the DPI button firmly. Ensure no other software is overriding mouse settings. Reinstall mouse drivers if necessary.
Buttons not working	Software conflict, physical damage, incorrect programming.	Check if buttons are programmed correctly in any installed software. Test on another computer. Ensure no physical obstructions.
LED lights not working	Power issue, software setting.	Ensure mouse is properly connected and receiving power. Check if there's a software setting to disable LEDs.

TECHNICAL SPECIFICATIONS

Feature	Specification
Brand	DR1TECH
Model Name	Hunter
Item Model Number	DR10030
Connectivity Technology	USB (Wired)
Movement Detection Technology	Optical
Adjustable DPI	400/800/1600/2400/3200/4200
Number of Buttons	9
Acceleration	10 g
Polling Rate	500 Hz
Image Processing	4200 FPS
Removable Weights	5
Dimensions (L x W x H)	124 x 80 x 38 mm (approx. 7.3 x 3.2 x 11.9 cm)
Item Weight	164 g (approx. 130 g without weights)
Compatible Operating Systems	Windows Vista, Windows XP, Linux, Mac

Feature	Specification
Compatible Devices	PC, PS4, Xbox

WARRANTY AND SUPPORT

DR1TECH products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your product or visit the official DR1TECH website. If you require technical assistance, have questions about product functionality, or encounter any issues not covered in this manual, please contact DR1TECH customer support. Contact details can typically be found on the product packaging or the official brand website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question