

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [NACON](#) /

› [NACON Revolution X Pro Controller \(XSX800REVXCONT\) User Manual](#)

## NACON XSX800REVXCONT

# NACON Revolution X Pro Controller (XSX800REVXCONT) User Manual

Model: XSX800REVXCONT | Brand: NACON

## INTRODUCTION

The NACON Revolution X Pro Controller is a professional wired controller designed for competitive gaming on Xbox Series X|S, Xbox One, and PC (Windows 10/11). It offers advanced customization options, programmable buttons, and supports Dolby Atmos for immersive audio experiences. This manual provides detailed instructions for setup, operation, and maintenance of your controller.

## WHAT'S IN THE BOX

Upon unboxing your NACON Revolution X Pro Controller, you should find the following items:

- NACON Revolution X Pro Controller
- 3-meter Braided USB-C to USB-A Cable
- Hard Shell Carry Case
- Weight Compartment with various weights (10g, 14g, 16g)
- Alternative Thumbsticks (various shapes/heights)
- Polishing Cloth
- Instruction Manual



Image: Front view of the NACON Revolution X Pro Controller, showcasing the face buttons, D-pad, and thumbsticks.

## CONTROLLER FEATURES

The Revolution X Pro Controller is engineered for precision and comfort:

- **Wired Connection:** Connects via a durable 3-meter braided USB-C to USB-A cable for a stable, lag-free gaming experience. The USB-C port is located at the top of the controller.
- **Ergonomic Design:** Features textured grips on the handles for enhanced comfort and control during extended gaming sessions.
- **Responsive Buttons:** Includes standard Xbox face buttons (A, B, X, Y), a precise D-pad, and highly responsive shoulder buttons and triggers.
- **Programmable Back Buttons:** Four additional buttons are located on the underside of the controller, fully programmable for custom commands and macros.
- **Profile Switch:** A switch on the back allows toggling between Classic and Advanced profiles, offering different button mappings and settings.
- **3.5mm Headphone Jack:** Located at the bottom for audio and chat functionality (headphones required for Dolby Atmos access).



Image: Back view of the NACON Revolution X Pro Controller, showing the programmable back buttons, profile switch, and USB-C port.

## CUSTOMIZATION

The NACON Revolution X Pro Controller offers extensive customization to tailor it to your preferences:

- **Adjustable Weights:** The controller features removable compartments in its handles where you can insert various weights (10g, 14g, 16g) to achieve your desired feel and balance.
- **Interchangeable Thumbsticks:** A selection of alternative thumbsticks with different heights and textures is included, allowing you to swap them out for optimal grip and precision.
- **Software Customization:** Utilize the dedicated Revolution X App (available on Microsoft Store) to create and save custom profiles. This software allows you to remap buttons, adjust joystick sensitivity, trigger dead zones, and manage RGB lighting effects and vibration motors.

## SETUP

1. **Connect the Cable:** Insert the USB-C end of the braided cable into the port on the top of the controller.
2. **Connect to Console/PC:** Plug the USB-A end of the cable into an available USB port on your Xbox console (Series X|S, Xbox One) or PC.
3. **Power On:** The controller will automatically power on and connect to your device. The Xbox button on the controller will illuminate.
4. **Install Software (PC Only):** For advanced customization on PC, download the "Revolution X App" from the Microsoft Store.
5. **Dolby Atmos Setup:** If using headphones, connect them to the 3.5mm jack. Dolby Atmos access is included, but headphones are required for the 3D sound experience.

## OPERATING THE CONTROLLER

The NACON Revolution X Pro Controller functions similarly to a standard Xbox controller, with added features:

- **Basic Controls:** Use the left thumbstick for movement, right thumbstick for camera control, D-pad for navigation, and face buttons for in-game actions.
- **Shoulder Buttons & Triggers:** L1/R1 (shoulder buttons) and L2/R2 (triggers) provide additional input options. The triggers offer progressive travel for precise control.
- **Using Programmable Buttons:** The four back buttons (M1, M2, M3, M4) can be assigned to any other controller function using the Revolution X App. This allows for quick access to complex commands without removing your thumbs from the thumbsticks.
- **Switching Profiles:** Use the profile switch on the back of the controller to quickly change between your customized settings.

## MAINTENANCE

---

To ensure the longevity and optimal performance of your controller:

- **Cleaning:** Use the provided polishing cloth or a soft, dry cloth to wipe down the controller regularly. Avoid abrasive cleaners or solvents.
- **Cable Care:** Store the braided USB cable neatly to prevent kinks or damage. Avoid excessive pulling or bending at the connectors.
- **Storage:** When not in use, store the controller in its hard shell carry case to protect it from dust, spills, and physical damage.
- **Thumbstick & Weight Management:** Keep interchangeable thumbsticks and weights in their designated storage compartments to prevent loss.

## TROUBLESHOOTING

---

If you encounter issues with your NACON Revolution X Pro Controller, try the following steps:

- **Controller Not Responding:**
  - Ensure the USB cable is securely connected to both the controller and your console/PC.
  - Try connecting the controller to a different USB port.
  - Restart your console or PC.
- **Buttons/Thumbsticks Not Working Correctly:**
  - Check for any debris or obstructions around the buttons or thumbsticks.
  - If using interchangeable thumbsticks, ensure they are properly seated.
  - Recalibrate the controller using the Revolution X App on PC, if applicable.
- **Audio Issues:**
  - Ensure your headphones are fully plugged into the 3.5mm jack.
  - Check audio settings on your console/PC to ensure the controller is selected as the audio output device.
- **Software Issues (PC):**
  - Ensure the Revolution X App is up to date.
  - Try reinstalling the Revolution X App.

If problems persist, please refer to the support section for further assistance.

## SPECIFICATIONS

Feature	Detail
Model Number	XSX800REVXCONT
Connectivity	Wired (USB-C to USB-A)
Cable Length	3 meters
Compatibility	Xbox Series X S, Xbox One, PC (Windows 10/11)
Audio Support	Dolby Atmos (with headphones)
Customization	Adjustable weights, interchangeable thumbsticks, programmable buttons via Revolution X App
Product Dimensions	8.07 x 3.74 x 7.68 inches
Item Weight	1.84 pounds
Date First Available	October 7, 2021

## WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your product or visit the official NACON website. Keep your proof of purchase for warranty claims.

Online resources may include:

- [NACON Support Website](#)
- [Revolution X App \(Microsoft Store\)](#)