Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Mytee /
- Mytee S300-H Tempo Heated Spotter User Manual

Mytee S300-H

Mytee S300-H Tempo Heated Spotter User Manual

Model: S300-H | Brand: Mytee

1. Introduction

This manual provides comprehensive instructions for the safe and effective operation, maintenance, and troubleshooting of your Mytee S300-H Tempo Heated Spotter. Please read this manual thoroughly before operating the unit and retain it for future reference.

1.1 Safety Information

Always observe basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury. This includes:

- · Read all instructions before use.
- · Connect to a properly grounded outlet only.
- Do not immerse the unit in water.
- Do not operate with a damaged cord or plug.
- · Keep children and pets away from the unit during operation.
- Use only recommended cleaning solutions.

2. PRODUCT OVERVIEW

The Mytee S300-H Tempo Heated Spotter is a compact and powerful heated carpet extractor designed for efficient spot cleaning and interior maintenance. Its features include:

- Powerful Vacuum Motor: Produces 85 inches of water lift for maximum extraction, reducing drying times with its two-stage design.
- User-Friendly Design: Features one-switch operation and easy-to-open caps for solution and recovery tanks, enhancing convenience and safety.
- **Durable Construction:** Built with Mytee's robust roto-molded housing for long-lasting performance, and includes an Air Lite Upholstery Tool.
- Portable and Compact: With a 1-gallon tank capacity and weighing only 26 pounds, it is easy to transport and store.

2.1 Components

Familiarize yourself with the main components of your S300-H Tempo Heated Spotter:



Figure 1: Full view of the Mytee S300-H Tempo Heated Spotter, showing the main unit, vacuum hose, solution hose, and upholstery tool.



Figure 2: Side view of the unit, highlighting the control panel with power switches and the quick-connect fitting for the solution hose.



Figure 3: Close-up of the easy-to-open cap for the solution tank, located on the top of the unit.

3. SETUP

3.1 Initial Assembly

- 1. Unpack all components from the packaging.
- 2. Ensure all hoses and the upholstery tool are present.
- 3. Attach the vacuum hose to the vacuum port on the unit.
- 4. Connect the solution hose to the quick-connect fitting on the unit and to the upholstery tool.

3.2 Filling the Solution Tank

- 1. Open the solution tank cap (refer to Figure 3).
- 2. Fill the tank with clean water and the recommended carpet cleaning solution according to the solution manufacturer's instructions. Do not overfill.
- 3. Securely close the solution tank cap.

4. OPERATING INSTRUCTIONS

4.1 Powering On

- 1. Plug the power cord into a grounded electrical outlet.
- 2. Turn on the "Vacuum" switch.
- 3. Turn on the "Pump" switch.
- 4. If heated cleaning is desired, turn on the "Heater" switch. Allow a few minutes for the water to heat up.

4.2 Cleaning Process

- 1. Pre-test the cleaning solution on an inconspicuous area of the material to be cleaned for colorfastness.
- 2. Position the upholstery tool over the area to be cleaned.
- 3. Press the trigger on the upholstery tool to spray the cleaning solution onto the surface.
- 4. While spraying, pull the tool slowly across the surface to extract the dirty solution. Overlap passes slightly.
- 5. For heavily soiled areas, repeat the process. For best results, perform a final pass without spraying solution to maximize extraction of moisture.
- 6. Monitor the recovery tank for dirty water.



Figure 4: The upholstery tool in action, demonstrating the cleaning process on a carpeted surface.

4.3 Emptying the Recovery Tank

- 1. Turn off all switches and unplug the unit.
- 2. Locate the recovery tank drain.
- 3. Carefully drain the dirty water into a suitable receptacle.
- 4. Rinse the recovery tank with clean water if necessary.

5. MAINTENANCE

5.1 Routine Cleaning

- After each use, empty and rinse both the solution and recovery tanks thoroughly.
- Flush the solution lines by running clean water through the system.
- Clean the upholstery tool, removing any debris from the nozzle and extraction head.
- Wipe down the exterior of the unit with a damp cloth.

5.2 Storage

Store the unit in a clean, dry place, away from extreme temperatures. Ensure all tanks are empty and hoses are properly coiled to prevent damage.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Unit does not power on.	Not plugged in; circuit breaker tripped; faulty power switch.	Check power connection; reset circuit breaker; contact service center.
No spray from upholstery tool.	Solution tank empty; pump switch off; clogged nozzle; kinked solution hose.	Refill solution tank; turn on pump switch; clean nozzle; straighten hose.
Low suction.	Recovery tank full; vacuum hose clogged or disconnected; vacuum motor issue.	Empty recovery tank; check hose connections and clear obstructions; contact service center.
Heater not working.	Heater switch off; electrical issue.	Turn on heater switch; ensure adequate power supply; contact service center.
Water leaking from unit.	Loose hose connection; damaged tank or seal; internal component issue.	Check all connections; inspect tanks and seals for damage; contact service center.

For issues not listed or if solutions do not resolve the problem, please contact Mytee customer support.

7. SPECIFICATIONS

Feature	Detail
Model Number	S300-H
Manufacturer	Mytee
Item Weight	26 Pounds
Package Dimensions	24.25 x 22 x 10 inches
Tank Capacity	1 Gallon (Solution & Recovery)
Water Lift	85 inches
Vacuum Motor	Two-stage
Color	White (Unit housing is black and blue)
ASIN	B09GPR8VY3

8. WARRANTY AND SUPPORT

8.1 Warranty Information

Mytee offers a limited lifetime warranty on the body of the S300-H Tempo Heated Spotter. Additionally, there is a one-year warranty covering the pump, vacuum motor, and heating system. Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, warranty service, or to locate a service center, please visit the official Mytee website or contact their customer support directly. Mytee maintains a national network of authorized service centers to assist you.

Related Documents - S300-H



Mytee Tempo S-300/S-300H Upholstery Spotter User Manual

Comprehensive user manual for the Mytee Tempo S-300 and S-300H upholstery spotter extractors, covering operation, maintenance, safety, and troubleshooting. Includes technical specifications, included accessories, and detailed guides.




Mytee Lite 8070 User Manual

User manual for the Mytee Lite 8070 carpet and upholstery spotter, detailing its features, operation, maintenance, and troubleshooting.



Mytee S-300H Tempo Spot Cleaner Operations and Maintenance Manual

This manual provides comprehensive instructions for operating, maintaining, and troubleshooting the Mytee S-300H Tempo spot cleaner. It includes setup procedures, safety warnings, parts lists, and wiring diagrams for professional cleaning applications.



Mytee Tempo Spotter CS-300H Parts List and Assembly Diagram

A detailed parts list and assembly diagram for the Mytee Tempo Spotter CS-300H, including component assemblies and part numbers.



Mytee Tempo Spotter CS-300H-230.6.25 Parts List and Diagram

Detailed parts list and assembly diagrams for the Mytee Tempo Spotter, model CS-300H-230.6.25. Includes component assemblies and a breakdown of parts for the spotting tool.



Mytee Stingray HP90 User Manual: Automotive Detailing Extractor Guide

Comprehensive user manual for the Mytee Stingray HP90 automotive detailing extractor. Covers operation, safety, maintenance, and troubleshooting for professional cleaning equipment.