

Roxel RSB100

ROXEL RSB100 Soundbar User Manual

Portable Bluetooth Soundbar for PC, Smart TV, Laptops, and Smartphones

1. INTRODUCTION

Thank you for choosing the ROXEL RSB100 Soundbar. This compact and versatile soundbar is designed to enhance your audio experience for music, movies, and gaming across various devices. Featuring Bluetooth connectivity, auxiliary input, USB, and Micro SD card support, along with a built-in microphone for hands-free calls, the RSB100 offers superior sound quality in a portable and elegant design. Please read this manual carefully to ensure proper use and maintenance of your device.

2. PACKAGE CONTENTS

Please check the box for the following items:

- ROXEL RSB100 Soundbar
- Power Cable
- Auxiliary Cable
- User Manual

3. KEY FEATURES

- Compact and portable design
- Multiple connectivity options: Bluetooth, AUX, USB, Micro SD card
- Built-in microphone for hands-free calling
- 20W PMPO impressive audio output with superior bass and adaptive equalizer
- TWS (True Wireless Stereo) function for combining two RSB100 soundbars wirelessly
- Long battery life (up to 12 hours)
- Compatible with Smart TVs, PCs, laptops, smartphones, tablets, gaming consoles (XBOX, PS5), MP3 players

4. PRODUCT OVERVIEW



Figure 4.1: Angled view of the ROXEL RSB100 Soundbar, showcasing its sleek black design and illuminated control dial on the right side.




Figure 4.2: Front view of the ROXEL RSB100 Soundbar, highlighting the metal grille and the "ROXEL" branding.



Figure 4.3: Internal view of the ROXEL RSB100 Soundbar, illustrating the placement of its speakers and internal wiring for optimal sound delivery.

5. SETUP

5.1. Charging the Soundbar

Before first use, fully charge the soundbar using the provided power cable. The charging indicator light will show the charging status.

5.2. Powering On/Off

Press and hold the power button (usually integrated with the control dial) for a few seconds to turn the soundbar on or off.

5.3. Initial Placement



Figure 5.1: The ROXEL RSB100 Soundbar positioned neatly on a desk beneath a computer monitor, demonstrating its compact size and suitability for desktop use.

Place the soundbar on a stable, flat surface near your TV, PC, or desired audio source. Ensure there are no obstructions in front of the soundbar for optimal sound projection.

6. OPERATING INSTRUCTIONS

6.1. Bluetooth Connection

1. Turn on the RSB100 Soundbar. It will automatically enter Bluetooth pairing mode (indicated by a flashing light).
2. On your device (smartphone, tablet, PC), enable Bluetooth and search for "RSB100" in the list of available devices.
3. Select "RSB100" to pair. Once connected, you will hear a confirmation tone, and the light will become solid.

**Multipurpose
Support Multi-Device Connection**

Easily connect to TV, desktop, laptop, tablet, mobile phone, and PSP, etc with Bluetooth



Figure 6.1: The ROXEL RSB100 Soundbar shown connected to various devices like a TV, laptop, and mobile phone, illustrating its versatile multi-device connection capability via Bluetooth.

6.2. AUX (Auxiliary) Connection

Connect one end of the provided 3.5mm auxiliary cable to the AUX port on the soundbar and the other end to the audio output jack of your device (e.g., TV, PC, MP3 player). The soundbar will automatically switch to AUX mode.

6.3. USB and Micro SD Card Playback

Insert a USB flash drive or a Micro SD card (with audio files) into the respective port on the soundbar. The soundbar will automatically detect the storage device and begin playing audio files.

6.4. TWS (True Wireless Stereo) Function

The TWS function allows you to pair two RSB100 soundbars together for a true stereo sound experience.

1. Ensure both RSB100 soundbars are powered on and not connected to any other Bluetooth device.
2. On one of the soundbars, press and hold the TWS button (refer to the soundbar's physical buttons for exact location, usually a dedicated button or a long press on a mode button).
3. The soundbars will attempt to pair with each other. Once successfully paired, you will hear a confirmation tone.
4. Now, connect your device via Bluetooth to one of the paired soundbars. Audio will play through both soundbars in stereo.

TWS Connection in Series More Stunning Bass

Support 2 soundbars to be connected in series for more stunning surround stereo


TWS
Function





Figure 6.2: Two ROXEL RSB100 Soundbars displayed side-by-side, illustrating the TWS (True Wireless Stereo) function that allows them to connect wirelessly for enhanced surround sound.

6.5. Hands-Free Calling

When connected via Bluetooth to a smartphone, the built-in microphone allows you to answer calls directly through the soundbar. Press the Play/Pause button to answer or end a call.

7. MAINTENANCE

- Clean the soundbar with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Keep the soundbar away from water, moisture, and extreme temperatures.
- Do not block the speaker grilles.
- Store in a cool, dry place when not in use for extended periods.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Battery is low or depleted.	Charge the soundbar using the provided power cable.
No sound	Volume is too low; incorrect input mode; device not connected properly.	Increase volume; switch to correct input mode (Bluetooth, AUX, USB, TF); ensure device is paired/connected.
Bluetooth pairing failed	Soundbar not in pairing mode; device too far; interference.	Ensure soundbar is in pairing mode; move device closer; restart both devices.
TWS pairing failed	Soundbars not in TWS pairing mode; too far apart.	Ensure both soundbars are in TWS pairing mode; place them closer to each other.

9. SPECIFICATIONS

Model Name	RSB100
Brand	Roxel
Connectivity Technology	Bluetooth, Auxiliary, USB
Speaker Type	Soundbar
Audio Output Mode	Stereo
Maximum Speaker Output Power	20 Watts
Frequency Response	134 KHz
Battery Life	12 hours
Product Dimensions (L x W x H)	44 x 7.5 x 7 cm
Item Weight	900 Grams
Color	Black
Material	Metal Grille
Compatible Devices	Android, Computer, iOS, Laptop, PC, Samsung, Tablet, Television
Special Features	Hands-free calling, Bluetooth, TF Card, Auxiliary Input, Portable, Rechargeable, TWS, USB

Large Capacity Long Batter Life

By virtue of 1800mAh battery capacity, it can be placed at home or office freely

3.5h

Working Time

3h

Charging Time



Figure 9.1: Visual representation of the ROXEL RSB100 Soundbar's battery performance, indicating 3.5 hours of working time and 3 hours of charging time for its 1800mAh battery.

10. WARRANTY AND SUPPORT

The ROXEL RSB100 Soundbar comes with a **12-month manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects and material faults under normal use. For technical support, warranty claims, or further assistance, please contact your retailer or visit the official Roxel website. Please retain your proof of purchase for warranty purposes. For more information, you may visit the [Roxel Brand Store on Amazon](#).

© 2024 Roxel. All rights reserved. Product specifications are subject to change without notice.