Sensea 3276007141962

Sensea Under-Sink Cabinet User Manual

Model: 3276007141962

1. Product Overview

The Sensea Easy under-sink cabinet is a practical, easily accessible, and user-friendly solution designed to enhance your bathroom. This white wooden cabinet features two spacious drawers, offering ample storage for your toiletries and other essentials. It is part of the Sensea Easy range, known for its functional and eco-friendly design.



Figure 1: Front view of the Sensea Easy Under-Sink Cabinet.

The cabinet's design is both elegant and timeless, ensuring it complements various bathroom decors. Its thoughtful construction includes a fully enclosed top drawer for small items and a deep second drawer for larger storage needs. The cabinet also features a soft-close system for smooth and quiet drawer operation.



Figure 2: Sensea Easy Under-Sink Cabinet integrated into a bathroom.

2. Key Features

- **Modern Design:** Elegant and timeless design that enhances your bathroom decor while providing practical storage for toiletries.
- **Practical Storage:** Features a 70 cm width. The first drawer is fully enclosed without a cutout, maximizing storage space. The second drawer offers deep capacity.
- **Adjustable Drawer Fronts:** Drawer fronts can be adjusted to align perfectly with your furniture assembly.
- **Soft-Close System:** Includes a soft-close mechanism for smooth and quiet drawer operation, preventing slamming.
- **Adjustable Legs:** Equipped with 4 independently height-adjustable legs, ensuring stability on uneven surfaces.
- **Wall-Mountable:** Can be securely fixed to a non-load-bearing wall for added stability.
- **Eco-Friendly Construction:** Made in Italy using a unique wood recycling process, with all panels designed from recycled and FSC-certified wood.

- **Easy Range Compatibility:** Available in 50 cm and 70 cm sizes and two colors (matte white and light oak), compatible with the entire Sensea Easy bathroom furniture range and Easy washbasins.



Figure 3: Drawers open, showcasing storage capacity and sink compatibility.

3. Setup and Installation Guide

3.1 Unpacking

Carefully unpack all components from the packaging. Inspect all parts for any damage. Keep the packaging materials until assembly is complete, in case any parts need to be returned or replaced.

3.2 Assembly

The Sensea Easy cabinet is designed for easy assembly. Detailed assembly instructions are included with your product to facilitate the process. Please follow these instructions carefully.

- **Component Identification:** Before starting, identify all components and hardware using the provided parts list in

the assembly manual.

- **Cabinet Assembly:** Assemble the main cabinet structure according to the step-by-step instructions.
- **Drawer Installation:** Install the drawers, ensuring the soft-close mechanism is correctly aligned and functional. The drawer fronts can be adjusted for a perfect fit.
- **Leg Adjustment:** Attach the four adjustable legs. Adjust their height independently to ensure the cabinet is level and stable on your bathroom floor.
- **Wall Mounting:** For enhanced stability and safety, the cabinet should be fixed to a non-load-bearing wall. **Important:** Screws, washers, and wall plugs suitable for your specific wall material are**not included** and must be purchased separately. Ensure you use appropriate hardware for your wall type (e.g., plasterboard, concrete, brick).
- **Washbasin Combination:** This cabinet is designed to be combined with a Sensea Easy washbasin of the same width (70 cm). Ensure proper alignment and sealing as per the washbasin's installation guide.




Figure 4: Cabinet dimensions for planning installation.

4. Operation

Operating your Sensea Easy under-sink cabinet is straightforward:

- **Drawer Usage:** Gently pull the drawer handles to open. The soft-close mechanism will ensure the drawers close smoothly and quietly when pushed back.
- **Storage:** Utilize the fully enclosed top drawer for smaller items like toiletries, and the deeper bottom drawer for larger bathroom essentials.
- **Adjusting Drawer Fronts:** If needed, the drawer fronts can be adjusted to ensure they are perfectly aligned. Refer to the detailed assembly instructions for specific steps on how to make these adjustments.

5. Care and Maintenance

To ensure the longevity and appearance of your Sensea Easy under-sink cabinet, follow these care and maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. For stubborn marks, use a mild, non-abrasive cleaner specifically designed for furniture. Avoid harsh chemicals, abrasive cleaners, or scouring pads, as these can damage the finish.
- **Spills:** Immediately wipe up any spills, especially water, to prevent moisture damage to the wood.
- **Humidity:** Maintain a consistent humidity level in your bathroom to prevent warping or cracking of the wood.
- **Regular Checks:** Periodically check all screws and fittings to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Drawer Mechanisms:** Keep the drawer runners clean and free of debris to ensure smooth operation of the soft-close system.

6. Troubleshooting

If you encounter any issues with your Sensea Easy under-sink cabinet, refer to the table below for common problems and their solutions:

Problem	Possible Cause	Solution
Cabinet is wobbly or unstable.	Uneven floor; loose wall fixings; legs not properly adjusted.	Adjust the height of the individual legs until the cabinet is stable. Ensure wall fixings are secure and appropriate for your wall type.
Drawers do not close smoothly or soft-close mechanism is not working.	Obstruction in the drawer runners; mechanism misalignment; drawer overloaded.	Check for any objects blocking the runners. Ensure drawers are not overloaded. Refer to assembly instructions for adjusting the soft-close mechanism or drawer alignment.
Drawer fronts are misaligned.	Adjustment screws need fine-tuning.	Refer to the assembly instructions for guidance on adjusting the drawer fronts.

7. Product Specifications

Specification	Detail

Specification	Detail
Brand	Sensea
Model	3276007141962
Color	White
Product Dimensions (L x W x H)	40 x 70 x 79.5 cm
Item Weight	20.2 Kilograms
Special Features	Soft-close drawers, Eco-friendly (recycled wood, FSC certified)
Recommended Product Uses	Bathroom
Mounting Type	Wall Mount
Made in	Italy





Figure 5: Product details including FSC certification and weight.

8. Environmental Responsibility

Sensea is committed to sustainable practices. This Easy cabinet is a testament to that commitment, being manufactured in Italy through a unique wood recycling process. All wood panels used in the Easy concept furniture are made from recycled wood and are certified by the Forest Stewardship Council (FSC), ensuring that the materials come from responsibly managed forests.

9. Warranty and Customer Support

Sensea products are designed for durability and reliability. For specific warranty information regarding your Sensea Easy under-sink cabinet, please refer to the documentation provided at the time of purchase or visit the official Sensea website. In case of any questions, concerns, or need for technical assistance, please contact Sensea customer support through their official channels.



Sensea designs furniture, accessories, and sanitary equipment for a bathroom that is easy to live in, in the style you desire.

Visit the Sensea Brand Store for more products and information.

© 2024 Sensea. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question