

SENSEA 3276007141931

SENSEA Easy Under-Basin Cabinet Instruction Manual

Model: 3276007141931

1. PRODUCT OVERVIEW

The SENSEA Easy Under-Basin Cabinet is designed to provide practical storage and enhance the aesthetic of your bathroom. This model features two spacious drawers with a soft-close system, offering convenient access and quiet operation. The cabinet is constructed from recycled and FSC-certified wood, reflecting a commitment to environmental sustainability. Its natural oak look complements various bathroom decors.

The cabinet is designed for wall mounting and includes four independently height-adjustable feet to ensure stability on uneven surfaces. It is compatible with SENSEA Easy washbasins of the same width.



Image 1.1: The SENSEA Easy Under-Basin Cabinet integrated into a bathroom environment.

2. SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Always follow the provided assembly instructions carefully during installation.
- Ensure you use appropriate screws, washers, and wall plugs suitable for your specific wall material. These are not included with the cabinet.
- The cabinet must be securely fastened to a non-load-bearing wall to prevent instability and the risk of tipping.
- Utilize the height-adjustable feet to achieve a stable and level installation.
- Be aware of potential pinch points when opening and closing the drawers. Keep hands clear.
- Do not overload the drawers. Distribute weight evenly.

3. SETUP AND INSTALLATION

3.1 Unpacking

Carefully unpack all components and verify that all parts listed in the assembly guide are present. Keep

packaging materials away from children.

3.2 Assembly

The cabinet is designed for self-assembly. Refer to the detailed assembly manual included in the product packaging for step-by-step instructions. Ensure you have the necessary tools before beginning assembly.

3.3 Wall Mounting

After assembly, the cabinet must be securely mounted to a non-load-bearing wall. Use screws, washers, and wall plugs appropriate for your wall type (e.g., plasterboard, concrete, brick). These fasteners are not supplied and must be purchased separately.

3.4 Adjusting Feet

The four feet of the cabinet are independently height-adjustable. After wall mounting, adjust the feet to ensure the cabinet is level and stable. This adjustment contributes to overall stability in conjunction with the wall fixation.




Image 3.1: Dimensional diagram of the SENSEA Easy Under-Basin Cabinet.

4. OPERATING INSTRUCTIONS

4.1 Drawer Functionality

The cabinet features two drawers. The top drawer is designed without cut-outs to maximize storage space for smaller items. The deeper bottom drawer offers ample capacity for larger items.



Image 4.1: Open drawers of the SENSEA Easy Under-Basin Cabinet showing storage capacity.

4.2 Soft-Close System

Both drawers are equipped with a soft-close mechanism. This system ensures that the drawers close gently and silently, preventing slamming and extending the lifespan of the cabinet.

4.3 Drawer Front Adjustment

The drawer fronts can be adjusted to align perfectly with your cabinet assembly. Refer to the detailed assembly manual for instructions on how to make these adjustments.

5. MAINTENANCE

5.1 Cleaning

- Wipe surfaces with a soft, damp cloth.
- Avoid using abrasive cleaners, harsh chemicals, or solvents, as these can damage the finish.
- Dry the cabinet immediately after cleaning to prevent moisture damage, especially in a bathroom environment.

5.2 General Care

- Periodically check all screws and fittings to ensure they remain tight. Retighten if necessary.
- Protect the cabinet from excessive moisture and direct water exposure.
- Avoid placing hot items directly on the surface without protection.

6. TROUBLESHOOTING

6.1 Instability / Wobbling

If the cabinet feels unstable or wobbles:

- Ensure the cabinet is securely mounted to the wall with appropriate fasteners.
- Adjust the height of the individual feet to level the cabinet on uneven floors.
- Check that all assembly screws are tightened.

6.2 Drawers Not Closing Smoothly

If drawers are stiff or not closing properly:

- Check for any obstructions within the drawer slides or behind the drawers.
- Ensure the drawer slides are clean and free of debris.
- Verify that the cabinet itself is level and square. Adjust feet or wall mounting if necessary.
- Consult the assembly manual for instructions on adjusting drawer fronts and slides.

7. SPECIFICATIONS

Brand	SENSEA
Model Number	3276007141931
Dimensions (L x W x H)	40 x 70 x 79.5 cm
Weight	19.5 kg
Material	Wood (Oak look), Recycled and FSC-certified
Color	Natural Oak Look (listed as 'Geel' / Yellow in some data, but product images and description indicate oak)
Mounting Type	Wall Mount
Special Features	2 Soft-close drawers, Adjustable feet, Lightweight
Manufacturer	ADEO
Country of Origin	Italy (Made from recycled wood)




Image 7.1: Product details including FSC certification and key dimensions.

8. WARRANTY AND SUPPORT

8.1 Warranty Information

Specific warranty details for the SENSEA Easy Under-Basin Cabinet are typically provided with your purchase documentation or can be found on the manufacturer's official website. Please retain your proof of purchase for any warranty claims.

8.2 Customer Support

For technical assistance, missing parts, or any questions regarding your SENSEA product, please contact the retailer where you purchased the item or refer to the official SENSEA/ADEO customer support channels available in your region. Contact information is usually provided in the product packaging or on the manufacturer's website.