



[Manuals.plus](#) /

› [Favourlite](#) /

› Favourlite Camping Lantern Instruction Manual

Favourlite 1-Pale Green

Favourlite Camping Lantern Instruction Manual

Model: 1-Pale Green

PRODUCT OVERVIEW

The Favourlite Camping Lantern is a versatile and powerful lighting solution designed for various outdoor and emergency situations. It features ultra-bright illumination, multiple lighting modes, and a long-lasting rechargeable battery that doubles as a portable power bank.



Image: The Favourlite Camping Lantern, pale green in color, demonstrating its ability to charge a smartphone via its USB port.

- **3000LM Ultra Bright & 360° Lighting Coverage:** Equipped with 92 high-brightness LED chips, providing 3000 lumens of 6500K light for comprehensive illumination without harsh shadows.
- **5 Lighting Modes:** Includes High, Medium, Low, Red On, and Red Strobe modes to adapt to different needs and environments.

- **4400mAh Rechargeable & Long Lasting:** Features a powerful 4400mAh battery, rechargeable via USB-C, offering 4-10 hours of continuous runtime. Functions as a portable charger for other devices.
- **Impact Resistant and IPX4 Water Resistant:** Built with anti-slip rubber and thickened shockproof materials, ensuring durability against impacts and water splashes.
- **Collapsible Hooks & Portable Design:** Lightweight (1.21lb) and compact, with two hidden hooks for easy hanging on backpacks, tents, or branches.

SETUP AND CHARGING

Before initial use, ensure the lantern is fully charged to maximize performance and battery life.

1. **Initial Charge:** Connect the included USB-C cable to the lantern's charging port and the other end to a compatible USB power source (e.g., wall adapter, computer USB port).
2. **Charging Indicator:** The battery indicator lights will illuminate to show the charging progress (25%, 50%, 75%, 100%). A full charge typically takes approximately 3 hours.
3. **Portable Charger Function:** To use the lantern as a power bank, connect your device's charging cable to the lantern's USB-A output port.


4400 mAh
RECHARGEABLE
BATTERY

Runtime

4-10 hours

Charging Time

3 hours



TPYE-C Fast Charging

PORTABLE
CHARGER



Image: The lantern displaying its 4400mAh rechargeable battery capacity, runtime, and charging time, alongside an illustration of its portable charger function.

OPERATING INSTRUCTIONS

The Favourlite Camping Lantern offers five distinct lighting modes to suit various needs. The power button controls all functions.

- Power On/Cycle Modes:** Press the power button once to turn on the lantern in High Brightness mode. Subsequent presses will cycle through the modes in the following order:
 - **High Brightness:** Maximum illumination for large areas.
 - **Medium Brightness:** Balanced light for general use.
 - **Low Brightness:** Dimmer light for ambient illumination or extended battery life.
 - **Red On:** Constant red light, ideal for preserving night vision during stargazing or photography.
 - **Red Strobe:** Flashing red light for signaling in emergency situations.

2. **Power Off:** To turn off the lantern, press the power button after the lantern has been in any single mode for more than 8 seconds. If you are cycling through modes, you must wait 8 seconds in the desired mode before pressing the button again to turn it off directly.
3. **Using Collapsible Hooks:** The lantern features two hidden hooks at the top. Gently pull them out to hang the lantern from tents, branches, backpacks, or other suitable fixtures. Push them back in when not in use for compact storage.

5 LIGHTING MODES

RED FLOOD BEAM MODE INCLUDE



Image: Visual representation of the lantern's five lighting modes, including white light at various intensities and red light for night vision and emergency signaling.

MAINTENANCE AND CARE

Proper maintenance ensures the longevity and optimal performance of your Favourlite Camping Lantern.

- **Cleaning:** Wipe the lantern with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the surface or internal components.
- **Storage:** Store the lantern in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, charge the battery to approximately 50% every 3-6 months to maintain battery health.

- **Water Resistance:** The lantern is IPX4 water resistant, meaning it can withstand splashes from any direction. Do not submerge the lantern in water.
- **Impact Resistance:** While designed to be impact-resistant (up to 1 meter drop), avoid unnecessary drops or rough handling to prevent damage.



Image: Demonstrations of the lantern's durability, showing it being used in rainy conditions and surviving a fall on rough ground.

TROUBLESHOOTING

If you encounter issues with your Favourlite Camping Lantern, please refer to the following common solutions:

- **Lantern does not turn on:**
 - Ensure the battery is fully charged. Connect the lantern to a power source and check the charging indicator lights.
 - Verify the power button is being pressed firmly.
- **Battery does not hold charge or drains quickly:**

- Ensure the charging cable and power adapter are functioning correctly. Try a different cable or adapter.
 - Avoid extreme temperatures during charging and operation, as this can affect battery performance.
 - For optimal battery life, avoid fully discharging the battery frequently.
- **Device not charging from lantern (power bank function):**
 - Ensure the lantern has sufficient battery charge.
 - Verify the charging cable connecting your device to the lantern is working and properly connected.
 - Some devices may require specific charging protocols; ensure compatibility.

If these steps do not resolve the issue, please contact customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Brand	Favourlite
Model Number	1
Color	Pale Green
Brightness	3000 Lumens
Battery Capacity	4400mAh Lithium-Ion
Charging Time	Approx. 3 hours (via USB-C)
Runtime	4-10 hours (depending on mode)
Water Resistance	IPX4 (Splash-proof)
Impact Resistance	Up to 1 meter (40 inches)
Dimensions (L x W x H)	4.13" x 4.13" x 7.09"
Item Weight	1.21 Pounds
Light Source Type	LED (COB panel with 92 chips)
Included Components	Camping Lantern, USB Cable

WARRANTY AND SUPPORT

For warranty information or technical support regarding your Favourlite Camping Lantern, please contact the manufacturer directly.

Manufacturer: lightbeoneus

Please refer to the product packaging or the official Favourlite website for the most current contact details and warranty terms.

IMPORTANT SAFETY INFORMATION

-
- Do not look directly into the LED light when it is on, as it can cause temporary vision impairment.
 - Keep out of reach of children.
 - Do not disassemble or modify the lantern. This may void the warranty and pose a safety risk.
 - Use only the provided or recommended charging cables and adapters.
 - Dispose of the product responsibly according to local regulations at the end of its lifespan.