

BLUETTI Trolly 2023

BLUETTI Trolley Cart (Model: Trolly 2023) Instruction Manual

For models: AC200P, AC200MAX, AC300, B300, B230, EB70, EB240, SP200, PV200, and other compatible BLUETTI power stations.

1. INTRODUCTION

This instruction manual provides essential information for the safe and efficient use of your BLUETTI Trolley Cart. Designed for portability and convenience, this anti-slip platform hand truck features universal wheels and a foldable design, making it ideal for transporting BLUETTI power stations and other heavy items up to 330 lbs. Please read this manual thoroughly before operating the trolley cart and retain it for future reference.

2. SAFETY INSTRUCTIONS

- **Weight Capacity:** Do not exceed the maximum load capacity of 330 lbs (150 kg). Overloading can cause damage to the cart and potential injury.
- **Stable Loading:** Always ensure items are securely placed on the platform and balanced to prevent tipping during transport.
- **Uneven Surfaces:** Exercise caution when moving the cart on uneven terrain, inclines, or stairs. The cart is designed for general use and may not perform optimally on very rough surfaces.
- **Folding Mechanism:** Keep hands and fingers clear of moving parts when folding or unfolding the cart to avoid pinching.
- **Children:** Keep the cart out of reach of children. This is not a toy.
- **Storage:** Store the cart in a dry, safe place when not in use.

3. PACKAGE CONTENTS

Verify that all items are present upon unpacking:

- 1 x BLUETTI Trolley Cart (Model: Trolly 2023)
- 1 x Instruction Manual (this document)

4. SETUP

4.1 Unfolding the Trolley Cart

1. Place the folded cart on a flat, stable surface.
2. Locate the handle release mechanism (often a button or lever) and press it to extend the handle upwards.
3. As the handle extends, the platform and wheels will automatically unfold into their operational position. Ensure all wheels are fully extended and locked into place.
4. Verify that the handle is securely locked at your desired height.



Figure 4.1: The BLUETTI Trolley Cart shown in both its compact, folded state and its fully extended, ready-to-use configuration. The image highlights the ease of transition between modes.



Figure 4.2: A visual representation of the cart's folding mechanism, demonstrating how it opens and closes in seconds for quick deployment and storage. An arrow indicates the direction of movement for unfolding.

4.2 Folding the Trolley Cart for Storage

1. Ensure the cart is empty and on a flat surface.
2. Press the handle release mechanism to retract the handle.
3. Gently push the handle downwards. The platform will fold inwards, and the wheels will retract automatically.

4. Once fully folded, the cart will be compact for easy storage.

5. OPERATING INSTRUCTIONS

5.1 Loading Items

- Place items centrally on the anti-slip platform.
- For multiple items, distribute weight evenly to maintain balance.
- Utilize the safety guardian feature to prevent items from slipping backward, especially with BLUETTI power stations.

MADE FOR BLUETTI POWER PLANT



Figure 5.1: The BLUETTI Trolley Cart supporting stacked BLUETTI AC300 and B300 power stations, demonstrating its compatibility and capacity for heavy equipment. The cart is positioned outdoors, ready for transport.

EASY TO USE



Open and Closes in Seconds

Figure 5.2: The BLUETTI Trolley Cart with power stations in an indoor setting, illustrating its use for moving heavy items within a home or workspace. The cart's compact design is also shown alongside the power stations.

5.2 Moving the Cart

- Grasp the padded handle firmly.
- Utilize the 360° universal wheels for easy maneuverability, especially around corners.
- Push or pull the cart smoothly. Avoid sudden jerks or movements.
- For heavy loads, ensure a clear path and proceed slowly.

POWER YOUR TRIP



Figure 5.3: The BLUETTI Trolley Cart transporting power stations in an outdoor environment, highlighting its utility for adventure, camping, or other outdoor activities where power sources need to be moved.

6. MAINTENANCE

- **Cleaning:** Wipe the cart with a damp cloth to remove dust and dirt. Avoid harsh chemicals that may damage the material.
- **Wheel Inspection:** Periodically check the wheels for debris or damage. Ensure they rotate freely.

- **Lubrication:** If wheels or folding mechanisms become stiff, apply a small amount of silicone-based lubricant.
- **Storage:** Store the cart in its folded position in a cool, dry place to prolong its lifespan.

7. TROUBLESHOOTING

- **Cart is difficult to fold/unfold:** Ensure no obstructions are present in the folding mechanism. Apply light lubricant if necessary.
- **Wheels do not roll smoothly:** Check for debris (hair, string, etc.) wrapped around the wheel axles. Clean as needed.
- **Cart feels unstable:** Verify that the load is centered and within the weight capacity. Ensure the handle is fully extended and locked.

8. SPECIFICATIONS

Feature	Specification
Brand	BLUETTI
Model	Trolly 2023
Material	Alloy Steel
Color	Black, Silver
Item Weight	13.6 Pounds (6.17 kg)
Wheel Type	Plastic, Rubber (Universal 360° wheels)
Load Capacity	330.7 Pounds (150 kg)
Number of Wheels	4
Product Dimensions (Folded)	26 x 16 x 3 inches (approximate)
Product Dimensions (Unfolded)	16.14 x 26.37 x 36.22 inches (W x L x H, max handle height)

MAXIMUM LOAD 330LBS



Figure 8.1: Detailed dimensions of the BLUETTI Trolley Cart in both unfolded and folded configurations, including height, width, and length measurements, and illustrating the maximum load capacity of 330 lbs.

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official BLUETTI website or contact their customer

service directly. Keep your purchase receipt as proof of purchase.

BLUETTI Official Website: www.bluettipower.com

© 2023 BLUETTI. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question