

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Ciays](#) /

› [Ciays 32 Inch Propane Fire Pit User Manual](#)

## Ciays CIFPT4B

# Ciays 32 Inch Propane Fire Pit User Manual

**Model:** CIFPT4B

**Brand:** Ciays

## IMPORTANT SAFETY INFORMATION

Please read and understand all safety warnings and instructions before assembling, operating, or servicing this fire pit. Failure to follow these instructions may result in property damage, personal injury, or death.

- Always use soapy water to check for gas leaks before each use and after any propane tank replacement.
- Refer to the reminder card for specific interface size and inspection instructions.
- Ensure proper ventilation when operating the fire pit; do not use in enclosed spaces.
- Keep children and pets at a safe distance from the fire pit during operation and while it is cooling down.
- Do not store propane cylinders indoors or in any enclosed area.
- This product is designed for outdoor use only.

## PRODUCT OVERVIEW

The Ciays 32 Inch Propane Fire Pit is a CSA-listed outdoor gas fire pit table designed to provide warmth and a focal point for your patio, deck, or garden gatherings. Its robust steel construction ensures durability for outdoor environments.



*A black square propane fire pit with a woven pattern on its sides, featuring a central fire pit with active flames and a removable lid resting beside it. The fire pit is made of steel and is designed for outdoor use.*

## KEY FEATURES

- **50,000 BTU Heat Output:** Provides substantial warmth, making it ideal for cooler evenings.
- **CSA-Listed:** Certified to meet North American safety standards for gas-fired appliances.
- **Durable Steel Construction:** Ensures long-lasting performance and resistance to outdoor elements.
- **Integrated Lid:** Converts the fire pit into a functional table surface when the fire is not in use.
- **Lava Rocks Included:** Enhances the flame appearance and aids in heat distribution.
- **External Fire Level Control:** Allows for easy adjustment of flame intensity and heat output.
- **Propane Tank Storage:** Designed to discreetly house a standard 20lb propane tank (not included) within the unit.



*A composite image showing a close-up of the fire pit's lid, which can cover the fire area for full table usage. Also shown are the included lava rocks and the external control knob for adjusting the flame.*



**Works With Stand 20lbs  
Propane Tank(Not Included)**

*The side panel of the fire pit table is open, revealing a standard 20lb propane tank stored neatly inside the unit. The fire pit is shown outdoors with ambient lighting.*

## **SETUP AND INSTALLATION**

For detailed step-by-step assembly instructions, please refer to the official Installation Manual (PDF) that came with your product. It is crucial to follow all steps precisely to ensure safe and proper operation.

### **Gas Connection Leak Test**

Before initial use and after any propane tank replacement, a gas connection leak test must be performed to ensure all connections are secure and leak-free.

1. Ensure the gas cylinder is the correct 1.3" (33mm) external threaded type and is properly installed.
2. Prepare a solution of soapy water (e.g., dish soap and water).
3. Apply the soapy water solution to all gas connections, including the regulator connection to the tank and the hose connection to the fire pit.
4. Slowly open the valve on the propane tank.
5. Observe the connections. If bubbles appear, there is a gas leak. Immediately close the propane tank valve, tighten the connections, and repeat the test. If leaks persist, do not use the fire pit and contact customer support. If no bubbles appear, the connection is secure.

## OPERATING INSTRUCTIONS

### Lighting the Fire Pit

1. Ensure the propane tank valve is fully open.
2. Turn the control knob on the fire pit to the "ON" position.
3. Press and hold the igniter button while slowly turning the control knob to the "LOW" setting.
4. Once the flame ignites, continue to hold the knob for 10-15 seconds to allow the thermocouple to heat up and engage the safety valve.
5. Release the knob. If the flame extinguishes, repeat the process.
6. Adjust the flame height using the control knob to your desired level.

### Turning Off the Fire Pit

1. Turn the control knob on the fire pit to the "OFF" position.
2. Close the valve on the propane tank.
3. Allow the fire pit to cool completely before covering or storing.



*A group of friends enjoying an evening around the Ciays 32 Inch Propane Fire Pit on a patio, with string lights overhead, illustrating the ambiance created by the product.*

## MAINTENANCE

Regular maintenance will help prolong the life and ensure the safe operation of your fire pit.

- **Cleaning:** Regularly clean the exterior surfaces with a soft cloth and mild detergent. Avoid abrasive cleaners that could damage the finish.
- **Hose and Connections:** Inspect the gas hose and all connections for any signs of wear, cuts, or leaks before each use. Replace damaged parts immediately.
- **Burner Area:** Keep the burner area clear of debris, dust, and any obstructions to ensure proper flame distribution.
- **Storage:** When not in use, especially during off-season or inclement weather, store the fire pit in a dry, covered area. Use the provided lid to protect the burner area from moisture and debris.

## TROUBLESHOOTING

### Fire Pit Does Not Ignite

- **Check Propane Tank:** Ensure the propane tank is not empty and its valve is fully open.
- **Gas Flow:** Verify that the gas hose is not kinked or obstructed.
- **Igniter:** Ensure the igniter is clicking and sparking. If not, check the battery (if applicable) or contact customer support. Some igniters require holding the knob down for a few seconds after turning to ignite.
- **Air Purge:** If the propane tank was recently connected, there might be air in the gas line. Try purging the air by holding the control knob down for a longer period (up to 30 seconds) during ignition attempts.

### Low Flame or Inconsistent Flame

- **Propane Level:** The propane tank may be running low. Replace or refill the tank.
- **Regulator Issue:** The regulator might be in bypass mode, which restricts gas flow. To reset, turn off the fire pit and propane tank, disconnect the regulator, wait a few minutes, then reconnect and slowly open the tank valve before attempting to light.
- **Burner Obstruction:** Clear any debris or foreign objects from the burner ports.

## SPECIFICATIONS

Attribute	Value
Brand	Ciays
Model Number	CIFPT4B
Product Dimensions	32"D x 32"W x 25"H
Material	Iron
Finish Type	Steel
Shape	Square
Item Weight	65.9 Pounds
Fuel Type	Liquefied Petroleum Gas
Heat Output	50,000 BTU

Attribute	Value
Color	Black
UPC	850032555531



*A visual representation of the fire pit table with key dimensions labeled: 32 inches in depth, 32 inches in width, and 24.8 inches in height, confirming its compact square design.*

## **WARRANTY AND SUPPORT**

For specific warranty information and customer support, please refer to the documentation included with your product or visit the official Ciays website. You can also contact Amazon Customer Service for further assistance.

### **Online Resources:**

- [Installation Manual \(PDF\)](#)
- [User Manual \(PDF\)](#)
- [Visit the Ciays Store on Amazon](#)

