

Ciays

Ciays 28 Inch Propane Fire Pit User Manual

Model: CIFPT3-N1 | UPC: 850032555548

IMPORTANT SAFETY INFORMATION

WARNING: For outdoor use only. Never use this appliance inside a house, building, garage, or any other enclosed area. Failure to follow these instructions could result in fire, explosion, or carbon monoxide poisoning, which could cause property damage, personal injury, or death.

- Keep children and pets away from the fire pit when in use.
- Maintain a safe distance from combustible materials.
- Always ensure proper ventilation.
- Do not store a spare LP cylinder under or near this appliance.
- Always check for gas leaks using soapy water before each use. Refer to the 'Gas Connection Leak Test' section for detailed instructions.
- Do not use the fire pit if any part has been submerged in water.
- Never leave the fire pit unattended when operating.
- Ensure the fire pit is on a level, non-combustible surface.

PRODUCT OVERVIEW

The Ciays 28 Inch Propane Fire Pit is a versatile outdoor appliance designed to provide warmth and ambiance to your patio, deck, or garden. This CSA-listed fire pit table features a durable steel construction and a powerful 50,000 BTU burner, making it ideal for gatherings and relaxation.

Key Features:

- **50,000 BTU Heat Output:** Provides substantial warmth for outdoor spaces.
- **Durable Steel Construction:** Ensures longevity and stability.
- **Integrated Lid:** Allows the fire pit to be converted into a full table when not in use.

- **Lava Rocks Included:** Enhances the flame appearance and heat distribution.
- **Easy-to-Use External Control:** Simple ignition and flame adjustment.
- **Compact 28-Inch Design:** Offers ample space for drinks and snacks while maintaining a manageable footprint.



Image: The Ciays 28 Inch Propane Fire Pit in operation, showcasing its square design and the flame from the lava rocks.

PACKAGE CONTENTS

Please ensure all components are present before beginning assembly. If any parts are missing or damaged, contact Ciays customer support.

- Fire Pit Table Unit
- Lava Rocks
- Fire Pit Lid
- User Manual (this document)
- Hardware for Assembly

SETUP

Assembly Instructions:

1. Carefully unpack all components and lay them out on a soft, clean surface to prevent scratches.
2. Follow the step-by-step diagrams provided in the separate assembly guide (if applicable) to connect the main body panels.
3. Securely attach the top table surface to the assembled base.
4. Place the lava rocks evenly around the burner area. Do not cover the igniter or burner holes.

Propane Tank Connection:

This fire pit is designed for use with a standard 20lb propane tank (not included).

1. Ensure the control knob on the fire pit is in the "OFF" position.
2. Open the access door on the fire pit table to reveal the propane tank compartment.
3. Place the 20lb propane tank upright inside the compartment.
4. Connect the regulator hose from the fire pit to the propane tank valve. Hand-tighten firmly.
5. Close the access door.

Gas Connection Leak Test:

Perform this test before initial use and after every tank change or if the fire pit has been moved.

1. Prepare a solution of soapy water (e.g., dish soap and water).
2. Ensure all fire pit control knobs are in the "OFF" position.
3. Slowly open the propane tank valve.
4. Apply the soapy water solution to all gas connections, including the regulator connection to the tank and the hose connections to the fire pit.
5. Observe for bubbles. If bubbles appear, there is a leak. Immediately close the propane tank valve and tighten the connection. Repeat the test. If bubbles persist, do not use the fire pit and contact customer support.
6. If no bubbles appear, the connection is secure.



Image: The Ciays fire pit with its side panel open, revealing the compartment for a standard 20lb propane tank.



Images: Visual guides for checking the gas cylinder fitting and performing a leak test with soapy water.

OPERATION

Lighting Instructions:

1. Ensure the fire pit is on a stable, level surface and clear of any obstructions.

2. Open the propane tank valve slowly.
3. Push in the control knob and turn it counter-clockwise to the "LOW" position.
4. While holding the knob in, press the igniter button repeatedly until the burner ignites. You should hear a clicking sound.
5. Once ignited, continue to hold the control knob in for 15-20 seconds to allow the thermocouple to heat up and engage the safety valve.
6. Release the control knob. The flame should remain lit.
7. If the flame extinguishes, repeat steps 3-6. If it fails to ignite after several attempts, refer to the Troubleshooting section.

Flame Adjustment:

Once the fire pit is lit, you can adjust the flame height by rotating the control knob between the "LOW" and "HIGH" settings. Turn clockwise for lower flame, counter-clockwise for higher flame.



Image: The fire pit generating heat, illustrating its 50,000 BTU output.



Image: Details of the fire pit, showing the removable lid for full table usage, the lava rocks, and the easy-to-use external control knob for flame adjustment.

Shutting Down:

1. Turn the control knob clockwise to the "OFF" position.
2. Close the valve on the propane tank.
3. Allow the fire pit and lava rocks to cool completely before covering or moving.

MAINTENANCE

Cleaning:

- Ensure the fire pit is completely cool before cleaning.
- Wipe exterior surfaces with a soft, damp cloth and mild soap. Do not use abrasive cleaners or solvents.
- Periodically inspect the burner and lava rocks for debris. Clear any blockages to ensure proper flame.
- Clean the igniter pin and thermocouple with a soft brush if they become dirty.

Storage:

- Disconnect the propane tank and store it in a well-ventilated area, away from direct sunlight and heat sources.
- Cover the fire pit with a weather-resistant cover (a compatible cover is often purchased separately, e.g., Saking Fire Pit Cover 28 inch).
- Store the fire pit in a dry, sheltered location during prolonged periods of non-use or harsh weather conditions.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Burner does not ignite	No gas flow; Igniter issue; Air in gas line	Check propane tank valve is open; Ensure tank is not empty; Perform leak test; Bleed air from line by holding control knob for 30 seconds before igniting; Check igniter battery (if applicable) or spark gap.
Low flame or flickering flame	Low gas pressure; Blocked burner holes; Regulator issue	Check propane tank level; Clean burner holes; Ensure regulator is properly connected and not damaged.
Flame goes out after releasing knob	Thermocouple not heating sufficiently; Faulty thermocouple	Hold knob in longer (15-20 seconds) after ignition; Ensure thermocouple is clean and positioned correctly in the flame; Contact support if issue persists.
Smell of gas	Gas leak	Immediately turn off gas at the tank; Perform a leak test; Do not operate if leak is detected. Contact qualified service personnel.

SPECIFICATIONS

Works With Stand 20lbs Propane Tank(Not Included)



Image: Diagram showing the dimensions of the 28-inch fire pit table.

Attribute	Detail
Brand	Ciays
Model Number	CIFPT3-N1
Product Dimensions	28"D x 28"W x 25"H
Material	Alloy Steel
Item Weight	57 Pounds
Fuel Type	Liquefied Petroleum Gas (Propane)
Heat Output	50,000 BTU
Color	Black
Shape	Square

Attribute	Detail
Certification	CSA-Listed

WARRANTY AND SUPPORT

Ciays products are manufactured to high-quality standards. For specific warranty information, including coverage details and duration, please refer to the warranty card included with your product or visit the official Ciays website. If you encounter any issues or require assistance with your fire pit, please contact Ciays customer support directly. Have your model number (CIFPT3-N1) and purchase information ready when contacting support.