

[Manuals.plus](#) /

› [Blulu](#) /

› Blulu Unfinished Wooden Christmas Trees Craft Manual

Blulu Unfinished Wooden Christmas Trees (20-Piece Set)

Blulu Unfinished Wooden Christmas Trees Craft Manual

Model: Unfinished Wooden Christmas Trees (20-Piece Set)

INTRODUCTION

This manual provides comprehensive instructions for the Blulu Unfinished Wooden Christmas Trees. These wooden trees are designed for various DIY craft activities, allowing for personalization through painting, drawing, and sculpting. Please read this manual thoroughly to ensure proper use and care of your product.

PRODUCT COMPONENTS

Each package contains the following items:

- 20 x Unfinished Wooden Christmas Trees



Image: A set of 20 unfinished wooden Christmas trees, with examples of painted red and green trees featuring snowflake patterns. These trees are ready for customization.

SETUP

Upon receiving your Blulu Unfinished Wooden Christmas Trees, please follow these steps:

1. **Unpack:** Carefully remove all 20 wooden trees from their packaging.
2. **Inspect:** Examine each tree for any signs of damage or imperfections. The trees are designed with a smooth surface and a sturdy round base for stability.
3. **Prepare Workspace:** Set up a clean, dry, and well-ventilated area for your crafting activity.



Image: A detailed view of an unfinished wooden Christmas tree, highlighting its approximate height of 2.2 inches (5.7 cm) and width of 1.4 inches (3.6 cm). The image also illustrates the smooth wooden material and stable round base.

OPERATING INSTRUCTIONS: CUSTOMIZATION

These unfinished wooden trees are ideal for various artistic expressions. Follow these guidelines for customization:

1. **Choose Your Medium:** The smooth wood surface is suitable for paint (acrylic, watercolor, oil), markers, glitter, fabric, yarn, and other decorative materials.
2. **Apply Designs:** Use brushes, pens, or other tools to apply your desired colors and patterns. The natural wood color allows for a simple style, or you can fully transform them.
3. **Drying:** Allow sufficient drying time for any applied wet mediums before handling or further decoration.
4. **Finishing Touches:** Once dry, you can add embellishments like small beads, ribbons, or sealants to protect your artwork.



Image: An adult and a child engaged in painting the unfinished wooden Christmas trees, demonstrating a common method of customization for these craft items.

MAINTENANCE AND CARE

To ensure the longevity of your wooden Christmas trees, observe the following care instructions:

- **Storage:** Store the wooden trees in a ventilated and dry place when not in use. Avoid damp environments, as moisture can lead to deformation or mold growth.
- **Cleaning:** If necessary, gently wipe the surface with a dry or slightly damp cloth. Avoid harsh chemicals or excessive moisture.
- **Handling:** Handle with care to prevent dents or scratches to the wood surface, especially if they are decorated.

TROUBLESHOOTING

Addressing common concerns:

- **Mold Growth:** If mold appears on the wooden trees, it is likely due to exposure to damp conditions. To address this, bleach can be used for cleaning. Ensure the trees are thoroughly dried in a well-ventilated area afterward.
- **Surface Irregularities:** While the trees are designed to be smooth, minor natural wood variations may occur. These can often be smoothed with fine-grit sandpaper before decoration, if desired.

SPECIFICATIONS

Feature	Detail
Material	Wood
Brand	Blulu

Feature	Detail
Item Dimensions (L x W x H)	2.24 x 1.42 x 1.02 inches (approx. 5.7 x 3.6 x 2.6 cm)
Shape	Tree
Number of Pieces	20
Item Weight	10.4 ounces (total for 20 pieces)
ASIN	B09GXKD8DJ

WARRANTY AND SUPPORT

For any questions or concerns regarding your Blulu Unfinished Wooden Christmas Trees, please refer to the retailer's return policy or contact Blulu customer support through their official channels. Specific warranty details are not provided with this product.

© 2025 Blulu. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question