

[Manuals.plus](#) /

› [QFX](#) /

› QFX PBX-8008SM TWS Bluetooth 8" Woofers Rechargeable Portable Speakers with AC Adapter and Microphone, Black 1 speaker, 1 mic, 1 stand User Manual

QFX PBX-8008SM

QFX PBX-8008SM TWS Bluetooth Portable Speaker User Manual

Model: PBX-8008SM

INTRODUCTION

Thank you for purchasing the QFX PBX-8008SM TWS Bluetooth Portable Speaker. This manual provides essential information for the safe and efficient operation of your speaker. Please read it thoroughly before use and retain it for future reference.

The PBX-8008SM is a versatile portable audio system featuring dual 8-inch woofers, Bluetooth connectivity, True Wireless Stereo (TWS) pairing, LED party lights, and a rechargeable battery. It includes a wired microphone and a speaker stand for enhanced usability.

SAFETY INFORMATION

- Do not expose the unit to extreme temperatures, humidity, or direct sunlight.
- Keep the speaker away from water or other liquids.
- Do not attempt to disassemble or modify the speaker. Refer all servicing to qualified personnel.
- Use only the specified charging adapter.
- Ensure proper ventilation around the speaker during operation.
- Avoid placing heavy objects on the speaker.

WHAT'S IN THE BOX

Verify that all items are present upon unboxing:

- QFX PBX-8008SM Portable Speaker
- Wired Microphone
- Speaker Stand

- AC Adapter (USB 5V)



Image: The QFX PBX-8008SM speaker, a wired microphone, and a speaker stand, representing the contents of the product package.

PRODUCT OVERVIEW: CONTROLS AND PORTS

Familiarize yourself with the control panel and various input/output ports on your speaker.



Image: Detailed view of the speaker's rear control panel, highlighting the Volume Control, AUX Input, USB Port, Microphone Input, and True Wireless Stereo (TWS) functionality.

- **Volume Control:** Rotary knob to adjust the master volume.
- **Power Switch:** ON/OFF switch for the speaker.
- **Mode Button:** Cycles through input modes (Bluetooth, AUX, USB, FM Radio).
- **LED Switch:** Toggles the LED party lights.
- **Previous/Next Buttons:** Navigates tracks in Bluetooth/USB mode, or stations in FM mode.
- **Play/Pause Button:** Controls playback. Long press for TWS pairing.
- **AUX Input:** 3.5mm jack for connecting external audio devices.
- **USB Port:** For USB drive playback.
- **MIC Input:** 6.35mm jack for connecting the wired microphone.
- **DC 5V Input:** Charging port for the speaker.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided AC adapter to the DC 5V input port on the speaker and plug it into a power outlet. The charge indicator LED will illuminate during charging and turn off when fully charged.





Image: The speaker next to an icon representing a rechargeable battery, emphasizing its portable and rechargeable nature.

2. Assembling the Speaker Stand

The speaker comes with a collapsible stand for optimal sound projection. Extend the legs of the stand and secure them firmly. Place the speaker onto the top pole of the stand, ensuring it is stable.



Image: The QFX PBX-8008SM speaker positioned next to its included microphone and speaker stand.

3. Connecting the Microphone

Insert the microphone cable into the "MIC IN" port on the speaker's control panel.

OPERATING INSTRUCTIONS

1. Power On/Off

Flip the Power Switch to the "ON" position to turn on the speaker. Flip it to "OFF" to power down.

2. Bluetooth Pairing

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED.
2. Enable Bluetooth on your mobile device and search for "QFX PBX-8008SM".
3. Select the speaker from the list to connect. A confirmation tone will sound upon successful pairing.

3. True Wireless Stereo (TWS) Function

The TWS function allows you to pair two PBX-8008SM speakers for a true stereo sound experience.

1. Ensure both speakers are powered on and in Bluetooth mode, but not connected to any device.
2. On one of the speakers (this will be the master speaker), long press the "Play/Pause" button. It will emit a pairing tone.
3. The two speakers will automatically connect to each other. A confirmation tone will sound once TWS pairing is successful.
4. Now, connect your mobile device to the master speaker via Bluetooth as described in step 2. Audio will play through both speakers in stereo.



Image: An illustration demonstrating the True Wireless Stereo (TWS) feature, showing two speakers wirelessly connected for an immersive audio experience.

4. AUX Input

Connect an external audio device (e.g., smartphone, MP3 player) to the "AUX IN" port using a 3.5mm audio cable. The speaker will automatically switch to AUX mode, or you can press the "Mode" button to select AUX.

5. USB Playback

Insert a USB flash drive containing MP3 audio files into the "USB" port. The speaker will automatically switch to USB mode and begin playing the first track. Use the "Previous/Next" and "Play/Pause" buttons to control playback.

6. FM Radio

Press the "Mode" button until "FM" is displayed. Long press the "Play/Pause" button to auto-scan and save available FM stations. Use the "Previous/Next" buttons to navigate between saved stations.

7. LED Party Lights

Press the "LED SW" button to toggle the integrated LED party lights on or off.



Image: The speaker displaying its colorful LED party lights, designed to enhance the atmosphere of events.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the speaker. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No power	Battery is depleted; Power switch is OFF.	Charge the speaker; Ensure power switch is ON.
No sound	Volume too low; Incorrect input mode; Device not connected.	Increase volume; Press MODE button to select correct input; Reconnect device.
Bluetooth not connecting	Speaker not in pairing mode; Device Bluetooth OFF; Speaker too far.	Ensure speaker is in Bluetooth mode; Turn on device Bluetooth; Move device closer to speaker (within 30 ft).
TWS pairing failed	Speakers already connected to a device; Incorrect pairing procedure.	Disconnect speakers from any devices; Follow TWS pairing steps carefully.
Microphone not working	Microphone not fully plugged in; Microphone volume too low.	Ensure microphone is securely plugged into MIC IN port; Adjust microphone volume.

SPECIFICATIONS

Feature	Detail
Model Number	PBX-8008SM
Speaker Type	Portable Bluetooth PA System
Woofer Size	Dual 8 inches
Connectivity	Bluetooth, AUX (3.5mm), USB, FM Radio
Special Features	True Wireless Stereo (TWS), LED Party Lights, Microphone Input
Power Source	Rechargeable Lithium Ion Battery, AC Adapter (USB 5V)
Dimensions (L x W x H)	9.76 x 7.91 x 20.2 inches
Item Weight	6.94 pounds
Included Accessories	Wired Microphone, Speaker Stand, AC Adapter



Image: The speaker shown with its approximate dimensions: 19.7 inches in height, 9.7 inches in width, and 7.4 inches in depth.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official QFX website or contact their customer service directly. You can also find additional resources and a downloadable PDF user manual at the following link:

[Download Official User Manual \(PDF\)](#)

For more information about QFX products, visit the official QFX store on Amazon:

[Visit QFX Store](#)

