

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [alilo](#) /

> [alilo Talking Pen D3C User Manual](#)

alilo D3C

alilo Talking Pen D3C User Manual

Model: D3C

INTRODUCTION

Welcome to the alilo Talking Pen D3C user manual. This guide provides detailed instructions for setting up, operating, and maintaining your alilo Talking Pen and its accompanying learning materials. The alilo Talking Pen is designed to enhance early childhood learning through interactive audio books, flash cards, and recording functions, suitable for toddlers aged 3-6 years.

WHAT'S IN THE BOX

Best Learning & Education Gift

Great Value for Money



Image: The alilo Talking Pen D3C package contents, including the pen, books, cards, and accessories.

Upon opening your alilo Talking Pen D3C package, you should find the following items:

- 1 x alilo Interactive Reading Pen
- 3 x Nursery Rhyme Books
- 1 x Alphabet Card / Piano Card
- 100 x Enlightenment Cards (Flash Cards)
- 540 x Recording Stickers
- 1 x User Manual (this document)
- 1 x Type-C USB Cable

PRODUCT OVERVIEW

The alilo Talking Pen D3C is an electronic learning toy designed for interactive engagement. It features a touch-sensitive pen that reads aloud content from specially designed books and cards. Key features include:

- **Interactive Reading:** The pen reads words, phrases, and plays sounds when touched to

designated areas on books and cards.

- **Pre-stored Content:** Includes nursery rhymes, stories, and sleeping music for diverse learning and entertainment.
- **Voice Recording Function:** Allows users to record and play back their own voices using special stickers.
- **Rechargeable Battery:** Provides up to 6 hours of use on a single charge.
- **Portable Design:** Compact and lightweight for use at home or on the go.



Image: Diagram illustrating the Kid-Friendly Controls of the alilo Talking Pen D3C, including power, volume, play/pause, home, recording buttons, USB port, speaker, and soft silicone ears.

SETUP

1. Charging the Talking Pen

Before first use, fully charge the alilo Talking Pen. Use the provided Type-C USB cable to connect the pen to a USB power adapter (not included) or a computer's USB port.



Image: The alilo Talking Pen D3C connected to a laptop via a USB-C cable for charging, illustrating its rechargeable feature.

- A full charge provides up to 6 hours of continuous use.
- The indicator light on the pen will show charging status (e.g., red for charging, green for fully charged).

2. Customizing Content (Optional)

The alilo Talking Pen allows for content updates by downloading new files. Connect the pen to a computer using the Type-C USB cable to manage or add content.



Image: The alilo Talking Pen D3C connected to a laptop, demonstrating the customizable content feature where new audio files can be added.

- Refer to the official alilo website for available content updates and instructions on how to transfer files.

OPERATING INSTRUCTIONS

1. Basic Pen Functions

- **Power On/Off:** Press and hold the power button (usually marked with a power symbol) to turn the pen on or off.
- **Play/Pause:** Press the play/pause button to start or stop audio playback.
- **Volume Control:** Use the volume up (+) and volume down (-) buttons to adjust the audio level. Hold the volume up button to repeat the last audio.
- **Home Button:** Press the home button to return to the main menu or switch modes.
- **Recording:** Press the recording button to initiate the recording function.
- **Previous/Next:** Use the arrow buttons to navigate between tracks or content.

2. Using with Nursery Rhyme Books

The alilo Talking Pen interacts with the included nursery rhyme books. Simply touch the pen to images, words, or designated icons on the pages to hear the corresponding audio.

Endless Fun & Learning

3 Talking Books for Multi-Sensory Play



Image: A child interacting with a nursery rhyme book using the alilo Talking Pen, which reads content aloud when touched to the page.

- **Nursery Rhymes:** Touch the nursery rhyme icon to play the song.
- **Games:** Touch the game icon to activate interactive learning games related to the page content.
- **Lyrics:** Touch the lyrics icon to hear the full lyrics of the song.
- **Tips:** Touch the tips icon for parental guidance or additional information.
- **Record:** Touch the record icon to record your own voice for specific sections.

3. Using with Flash Cards

The 100 enlightenment flash cards cover various categories. Touch the pen to the image or word on the card to hear its pronunciation and associated sounds.

99 Talking Flash Cards

Immersive Word Learning



Image: A child using the alilo Talking Pen to interact with flash cards, learning words and sounds.

4. Using Piano Card and ABC Card

The included Piano Card allows for musical exploration, while the ABC Card helps with alphabet learning.

Piano Card

Play Songs
Play the Piano
Instrument Sounds



ABC Card

Play ABC Songs
Learn the Letters
Letter Finding Game



Image: A child playing the Piano Card and learning letters with the ABC Card using the alilo Talking Pen.

- **Piano Card:** Touch the keys to play piano notes or instrument icons to hear different sounds.
- **ABC Card:** Touch letters to hear their pronunciation and associated words. Engage in letter-finding games.

5. Using Recording Stickers

The 540 recording stickers allow you to personalize your learning experience by recording your own audio for any object or image.

Fun Recording stickers

Make Anything Interactive



Image: A four-step guide demonstrating how to use the recording stickers: 1. Press Record Button, 2. Click on the Sticker to Start Recording, 3. Stick it on Anything, 4. Click to Play the Recording.

1. Press the **Record** button on the pen.
2. Touch an unused recording sticker with the pen to begin recording your voice.
3. Speak clearly into the pen's microphone.
4. Touch the sticker again to stop recording.
5. Stick the recorded sticker onto any object or image. When the pen touches this sticker, it will play your recorded voice.

6. Child Lock Feature

The child lock feature prevents accidental pressing of other function buttons during reading or play, ensuring uninterrupted engagement.

Nursery Rhymes



01 A,A, Apple	18 Goosey Goosey Gande)	35 One Potato, Two Potato
02 A Sailor Went to Sea	19 Happy Birthday to You	36 Polly Put the Kettle
03 ABC Song	20 Head and Shoulders Knees and Toes	37 Rain, Rain Go Away
04 After My Bath	21 Head Shoulders Knees and Toes	38 Ring Around the Rosie
05 Alphabet Song (Slower)	22 Hello, Hello, How Are You	39 Row, Row, Row Your Boat
06 Apples and Bananas	23 Humpty Dumpty	40 The Ants Go Marching
07 Are You sleeping copy	24 I love My Daddy	41 The Farmer in the Dell
08 Baa Baa Black Sheep	25 I Love My Mommy	42 The More We Get Together
09 B-1-N-G-0	26 I'm a Big Kid Now	43 The Wheels on the Bus - ERICA
10 Brush Your Teeth	27 I'm a Little Teapot	44 This is The Way We Go to School
11 Circle song	28 I'm H-A-P-P-Y	45 Walking Walking
12 Clap Your Hands	29 London Bridge	46 We Wish You a Merry Christmas
13 Colors Freeze Dance Game!	30 Mary Had a Little Lamb	47 Sleeping Bunnies
14 Counting sheep	31 Miss Polly Had A Dolly	
15 Days of the Week	32 Mulberry Bush	
16 Five Little Monkeys	33 Finger Family	
17 Friends Friends 123	34 One Finger, One Thumb	

Image: A close-up view of the alilo Talking Pen D3C highlighting the child lock switch, designed to prevent accidental button presses.

- To activate/deactivate the child lock, press and hold the Volume Down (-) button.

PRE-STORED CONTENT

The alilo Talking Pen D3C comes with a variety of pre-loaded audio content to enrich the learning experience:

Nursery Rhymes

Great Bang for the buck

PACKAGE

Manual	x1
Type-C USB Cable	x1
Reading Pen	x1
Nursery Rhyme Books	x3
Alphabet / Piano Card	x1
Flash Cards	x100
Recording Stickers	x540

Image: A comprehensive list of 47 nursery rhymes pre-loaded onto the alilo Talking Pen D3C, such as "ABC Song" and "Head, Shoulders, Knees and Toes."

The pen includes 47 popular nursery rhymes. These can be accessed through the nursery rhyme books or directly from the pen's internal memory.

Stories



Image: A list of 16 stories pre-loaded onto the alilo Talking Pen D3C, including classic tales like "The Sleeping Beauty" and "Snow White."

16 engaging stories are pre-loaded, offering narrative content for listening and comprehension.

Sleeping Music



Image: A list of 14 sleeping music tracks pre-loaded onto the alilo Talking Pen D3C, featuring lullabies and classical pieces like "Brahms Lullaby" and "Twinkle, Twinkle Little Star."

14 soothing sleeping music tracks are available to help relax and calm children.

MAINTENANCE

Cleaning

- Wipe the alilo Talking Pen with a soft, dry cloth.
- Do not use liquid cleaners or immerse the pen in water.
- Keep the books and cards dry and clean to ensure proper functionality.

Storage

- Store the pen, books, and cards in a cool, dry place away from direct sunlight and extreme temperatures.
- Ensure the pen is turned off when not in use to preserve battery life.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Pen does not turn on.	Low battery.	Charge the pen using the provided USB-C cable.
Pen does not read content accurately.	Pen not positioned correctly; dirty sensor.	Ensure the pen's tip is directly touching the designated area. Clean the pen's optical sensor with a soft, dry cloth.
No sound or low volume.	Volume too low; pen muted.	Increase the volume using the '+' button. Ensure the pen is not in child lock mode if volume adjustment is unresponsive.
Recording function not working.	Incorrect procedure; recording stickers used up.	Follow the recording instructions carefully. Ensure you are using an unused recording sticker.
Pen reports "no memory card" error.	Internal memory issue.	Contact customer support for assistance. This may indicate a hardware issue.

SPECIFICATIONS

- **Model:** D3C
- **Product Dimensions:** 6.77 x 1.85 x 0.1 inches
- **Item Weight:** 2.53 pounds
- **Recommended Age:** 36 months - 6 years
- **Battery:** 1 Lithium Ion battery (included)
- **Battery Life:** Up to 6 hours (approx.)
- **Charging Port:** Type-C USB
- **Manufacturer:** alilo

WARRANTY AND SUPPORT

alilo provides a 1-year warranty for the Talking Pen D3C. For any questions, technical support, or warranty claims, please contact alilo customer service.

- **Warranty Period:** 1 year from the date of purchase.
- **Customer Service:** Available 24/7 for quick replies. Please refer to your purchase platform (e.g., Amazon Message Center) for contact details.




Image: An illustration detailing alilo's service commitments, including Amazon US Fast Delivery, 24 Hours Online Customer Service, and Accurate Ad Description. Note: The product description states a 1-year warranty, which is reflected in the text above.