Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SoBuy FBT106-W

SoBuy FBT106-W Mobile Printer Stand and Storage Cabinet User Manual

Model: FBT106-W | Brand: SoBuy

1. Product Overview

The SoBuy FBT106-W is a versatile mobile printer stand and storage cabinet designed to optimize your workspace. This unit features a robust construction with multiple storage options, including open compartments, a drawer, and a cabinet with a door. Its mobile design, equipped with 360° swivel casters, allows for easy repositioning within your office, home, or studio environment. It is suitable for holding a printer, storing office supplies, documents, and other accessories, helping to maintain an organized and efficient area.





Figure 1: SoBuy FBT106-W Mobile Printer Stand with storage.

2. Setup and Assembly

The SoBuy FBT106-W mobile printer stand requires assembly. The package includes all necessary accessories, illustrated assembly instructions, and numbered parts to facilitate the process. It is recommended to follow the provided instructions carefully for correct and stable construction.

- **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list in the instruction manual.
- **Identify Parts:** Each component is numbered. Match these numbers with the assembly diagrams.
- **Follow Step-by-Step Instructions:** Assemble the unit according to the illustrated guide. Pay close attention to the orientation of parts, especially drawer slides and hinges.
- **Attach Casters:** Securely attach the four 360° swivel casters to the base. Two of these casters are equipped with brakes for stability.
- **Tighten Fasteners:** Ensure all screws and fasteners are securely tightened for structural integrity. White hole stickers are provided to cover visible screw heads for a clean finish.




Figure 2: Dimensional diagram for assembly reference.

3. Operating Instructions

The SoBuy FBT106-W is designed for ease of use and versatile storage.

- **Printer Placement:** Place your printer on the top surface of the stand. Ensure the printer's weight does not exceed the maximum load capacity of 50 kg (110 lbs).
- **Drawer Usage:** The top drawer provides enclosed storage for smaller office supplies such as pens, staplers, paper clips, and sticky notes.



Figure 3: Drawer for small office supplies.

- **Open Compartments:** Utilize the open shelves for easy access to paper reams, notebooks, or other frequently used items.



Figure 4: Open compartments for paper and documents.

- **Cabinet Storage:** The lower cabinet with a door offers discreet storage for binders, larger files, or other items you wish to keep out of sight.



Figure 5: Cabinet for larger items or discreet storage, showing a caster.

- **Mobility:** To move the stand, unlock the brakes on the two braked casters (if engaged). Guide the stand to its desired location. To secure it, engage the brakes on the casters.

4. Maintenance

To ensure the longevity and appearance of your SoBuy FBT106-W printer stand, follow these simple maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft cloth lightly dampened with water. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Spills:** Promptly clean any spills to prevent staining or damage to the particle board material.
- **Inspection:** Periodically check all fasteners and tighten them if necessary to maintain structural stability.
- **Caster Care:** Keep casters free of debris to ensure smooth movement.

5. Troubleshooting

If you encounter any issues with your SoBuy FBT106-W printer stand, consider the following:

- **Stability Issues:** If the stand feels wobbly, re-check all assembly screws and ensure they are fully tightened. Verify that the casters are securely attached.
- **Drawer/Door Malfunction:** If a drawer or door does not operate smoothly, check for obstructions or ensure that the slides/hinges were installed correctly during assembly. Refer to the assembly instructions.
- **Casters Not Rolling:** Check for debris (hair, lint) wrapped around the caster wheels. Clean as necessary. Ensure caster brakes are disengaged.

For problems not resolved by these steps, please contact SoBuy customer support.

6. Specifications

Feature	Detail
Model Number	FBT106-W
Brand	SoBuy
Color	White
Material	PB (E1 Particle Board)
Overall Dimensions (L x W x H)	50 x 40 x 75 cm (19.7 x 15.7 x 29.5 inches)
Item Weight	19.3 kg (42.5 lbs)
Maximum Load Capacity	50 kg (110 lbs)
Features	3 open compartments, 1 drawer, 1 door, 4 swivel casters (2 with brakes)
Recommended Use	Office, Home Office, Studio, Living Room, Kitchen

7. Warranty and Support

For any questions regarding assembly, missing parts, or product defects, please contact SoBuy customer support directly. Retain your purchase invoice as proof of purchase for warranty claims or support inquiries.
Delivery information provided by the seller indicates orders are typically processed within one business day, with delivery times ranging from 3-5 working days via carriers such as UPS, DPD, or DHL.
For further assistance, please visit the SoBuy Brand Store or contact the seller directly through your purchase platform.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09GYLWFD3

More documents and user manuals: **https://manuals.plus/**