

[Manuals.plus](#) /

› [Diesel](#) /

› Diesel Mr. Daddy 2.0 Chronograph Watch DZ7459 Instruction Manual

Diesel DZ7459

Diesel Mr. Daddy 2.0 Chronograph Watch DZ7459 Instruction Manual

Model: DZ7459

[Overview](#)

[Setup](#)

[Operating Instructions](#)

[Maintenance
Support](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty &](#)

1. PRODUCT OVERVIEW

The Diesel Mr. Daddy 2.0 DZ7459 is a men's chronograph watch featuring a 57mm stainless steel case, a black dial with multiple time zones, and a two-tone stainless steel bracelet. It is powered by a quartz movement and offers chronograph functionality along with a 24-hour display.



Image 1.1: Front view of the Diesel Mr. Daddy 2.0 DZ7459 watch, showcasing its distinctive large black dial with gold-tone hands and markers, and multiple sub-dials for chronograph and dual time functions.

2. INITIAL SETUP

2.1 Unpacking

Carefully remove the watch from its packaging. Inspect the watch for any visible damage. Retain the original packaging for future storage or warranty purposes.



Image 2.1: The red Diesel watch box, designed for safe storage and presentation of the timepiece.

2.2 Setting the Time and Date

1. **Main Time:** Pull out the main crown (center right) to position 2. Rotate the crown to set the hour and minute hands. Push the crown back in to position 1 to start the watch.
2. **Date:** Pull out the main crown to position 1. Rotate the crown clockwise or counter-clockwise to adjust the date. Push the crown back in to position 0.
3. **Additional Time Zones:** The Mr. Daddy 2.0 features multiple sub-dials for additional time zones. These are typically set using the smaller crowns or pushers located around the main crown. Refer to the specific markings on your watch dial (e.g., "TIME 2", "TIME 3", "TIME 4") and corresponding adjusters.






Image 2.2: Side view of the watch case, highlighting the main crown (center) and the two pushers (top and bottom) used for setting time, date, and operating chronograph functions.

2.3 Adjusting the Bracelet

The stainless steel bracelet can be adjusted by adding or removing links. This procedure typically requires specialized tools and is best performed by a professional jeweler to ensure proper fit and avoid damage to the bracelet or clasp.





Image 2.3: Rear view of the watch, displaying the two-tone stainless steel bracelet and the deployant clasp with the "DIESEL" logo engraved.

3. OPERATING INSTRUCTIONS

3.1 Chronograph Function

The chronograph function allows for precise timing of events. It is operated using the pushers located on either side of the main crown.

- **Start/Stop:** Press the top pusher to start the chronograph. Press it again to stop.
- **Reset:** While the chronograph is stopped, press the bottom pusher to reset all chronograph hands to zero.

3.2 Water Resistance

This watch is water-resistant up to 30 meters (3 ATM). This means it is suitable for everyday use and can withstand splashes or brief immersion in water. It is **not** suitable for swimming, showering, or diving. Ensure the crown is fully pushed in before any contact with water.

4. CARE AND MAINTENANCE

- **Cleaning:** Wipe the watch case and bracelet regularly with a soft, dry cloth to remove dirt and perspiration. For stainless steel, a slightly damp cloth can be used, followed by a dry cloth.
- **Avoid Chemicals:** Do not expose the watch to harsh chemicals, solvents, or detergents, as these can damage the case, crystal, or seals.
- **Temperature Extremes:** Avoid exposing the watch to extreme temperatures (hot or cold) or sudden temperature changes, which can affect the movement and water resistance.
- **Magnetic Fields:** Keep the watch away from strong magnetic fields, such as those produced by speakers, refrigerators, or mobile phones, as this can affect timekeeping accuracy.
- **Battery Replacement:** When the watch battery runs low, the second hand may start to jump every few seconds (End-of-Life indicator). Replace the battery promptly by a qualified watch technician to prevent leakage and damage to the movement.


5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch stops or loses time	Low battery	Replace battery by a professional.
Watch hands do not move after setting	Crown not fully pushed in	Ensure the crown is pushed all the way into position 0.

Problem	Possible Cause	Solution
Chronograph hands do not reset to zero	Requires calibration	Consult a professional watch repair service for calibration.
Condensation inside the watch	Exposure to extreme temperature changes or compromised water resistance	Seek immediate professional service to prevent internal damage.

6. PRODUCT SPECIFICATIONS

- **Model Number:** DZ7459
- **Movement:** Quartz Chronograph
- **Case Material:** Stainless Steel
- **Case Diameter:** 57 mm
- **Case Thickness:** 14 mm
- **Dial Color:** Black
- **Crystal Material:** Mineral
- **Band Material:** Stainless Steel (Two-tone)
- **Band Width:** 28 mm
- **Band Length:** 205 mm
- **Clasp Type:** Deployant Clasp
- **Water Resistance:** 30 meters (3 ATM) - Splash resistant, not suitable for swimming or diving.
- **Special Features:** Chronograph, 24-hour display, Dual time zones
- **Weight:** 142 grams



45 MM



51 MM



57 MM



Image 6.1: Visual comparison of watch sizes on a wrist, illustrating the substantial 57mm diameter of the Mr. Daddy 2.0 model.

7. WARRANTY AND SUPPORT

Diesel watches are typically covered by a limited warranty against defects in materials and workmanship. The duration and terms of the warranty may vary by region and retailer. Please refer to the warranty card included with your purchase or visit the official Diesel website for detailed warranty information.

For technical support, service, or warranty claims, please contact your authorized Diesel retailer or the official Diesel customer service. Keep your proof of purchase and warranty card readily available.

Official Diesel Website: www.diesel.com

