

[Manuals.plus](#) /

› [adidas](#) /

› Adidas Z.N.E. 01 Active True Wireless Earbuds User Manual

adidas Z.N.E. 01 (Model 1005989)

Adidas Z.N.E. 01 Active True Wireless Earbuds User Manual

Model: Z.N.E. 01 (1005989)

INTRODUCTION

The Adidas Z.N.E. 01 Active True Wireless Earbuds are designed to provide a high-quality audio experience for individuals with an active lifestyle. These earbuds offer a secure and comfortable fit, along with resistance to sweat and splashes, making them suitable for various activities and environments. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your earbuds.

WHAT'S IN THE BOX

Upon unboxing your Adidas Z.N.E. 01 earbuds, please verify that all components are present:

- Adidas Z.N.E. 01 Earbuds
- Charging Case
- USB-C Charging Cable
- Silicon Ear Sleeves (various sizes)
- Quick Start Guide
- Legal & Safety Information



Image: All components included with the Adidas Z.N.E. 01 earbuds.

SETUP

Charging the Earbuds and Case

Before initial use, fully charge your Adidas Z.N.E. 01 earbuds and their charging case. The earbuds provide approximately 5 hours of playtime on a single charge, with the charging case extending total playtime to 25 hours.

- **Earbud Charging:** Place the earbuds into the charging case. They will begin charging automatically. It takes approximately 1.5 hours to fully recharge the earbuds from the charging case.
- **Case Charging:** Connect the USB-C charging cable to the charging port on the case and to a power source. The charging case takes approximately 2 hours to fully charge via USB-C. Wireless charging time may vary depending on the charging pad used.
- **Quick Charge:** A 15-minute charge provides approximately 1 hour of playtime.



Image: Earbuds charging inside the case, indicated by a green light.

Bluetooth Pairing

To connect your earbuds to a device:

1. Ensure the earbuds are in the charging case and the case has sufficient battery.
2. Open the charging case. The earbuds will enter pairing mode.
3. On your device (smartphone, tablet, etc.), navigate to the Bluetooth settings.
4. Select "Adidas Z.N.E. 01" from the list of available devices.
5. Once connected, the earbuds are ready for use. The Bluetooth 5.2 connectivity offers a range of up to 10 meters.

OPERATING INSTRUCTIONS

Wearing the Earbuds

The Adidas Z.N.E. 01 earbuds are designed for an in-ear fit. Select the appropriate silicon ear sleeves for a comfortable and secure seal. A proper fit is crucial for optimal sound quality and to ensure the earbuds stay in place during physical activity.



Image: Earbuds worn in-ear for active use.

Touch Controls

The earbuds feature capacitive touch controls for managing audio playback and calls. Specific functions include:

- **Music Control:** Play, pause, skip tracks.
- **Call Management:** Receive and end calls.

Refer to the included Quick Start Guide for detailed instructions on specific touch gestures and their corresponding functions.

MAINTENANCE

Cleaning

To maintain optimal performance and hygiene, regularly clean your earbuds and charging case. Use a soft, dry, lint-free cloth. Avoid using abrasive materials or harsh chemicals. For the ear sleeves, they can be gently wiped with a damp cloth and mild soap, then thoroughly dried before reattaching.

Water Resistance

The Adidas Z.N.E. 01 earbuds are rated IPX4 for water resistance, meaning they are resistant to splashes from any direction. The charging case is rated IPX3, offering protection against spraying water. This makes them suitable for workouts and light rain, but they are not designed for submersion in water.



SWEAT-PROOF AND SPLASH-PROOF

SWEAT-PROOF AND SPLASH-PROOF IPX4 RATING

Image: Earbud demonstrating sweat and splash resistance.

TROUBLESHOOTING

If you encounter issues with your Adidas Z.N.E. 01 earbuds, consider the following common solutions:

- **No Sound/Connectivity Issues:**

- Ensure earbuds are charged.
- Verify Bluetooth is enabled on your device and the earbuds are paired.
- Try unpairing and re-pairing the earbuds.
- Ensure no other devices are interfering with the Bluetooth connection.

- **Charging Problems:**

- Check the USB-C cable and power adapter for damage.
- Ensure the charging contacts on the earbuds and inside the case are clean and free of debris.

- **Unresponsive Touch Controls:**
 - Ensure your fingers are clean and dry.
 - Restart the earbuds by placing them in the case and closing it for a few seconds, then reopening.

For more detailed troubleshooting or persistent issues, please refer to the official Adidas Headphones app or the comprehensive support resources available on the Adidas website.

SPECIFICATIONS

Adidas Z.N.E. 01 Technical Specifications

Category	Specification	Value
Audio	Drivers	12 mm
	Driver Type	Dynamic
	Driver Impedance	32 Ω
	Driver Sensitivity	93 dB SPL (179 mV @ 1 KHz)
	Frequency Response	20Hz - 20kHz
	Codec	SBC, AptX
Battery	Playtime (Earbuds)	5 hours
	Total Playtime (with Case)	25 hours
	Quick Charge	15 min for 1 hour playtime
	Full Recharge Time	Earbuds: 1.5 hrs (from case), Case: 2 hrs (USB-C)
Connectivity & Controls	Wireless Connectivity	Bluetooth 5.2
	Bluetooth Range	10 m
	Touch Controls	Yes, capacitive sensor
	Touch Control Functions	Control music, Receive/end calls
	Microphone	2 (1 per earbud)
	Active Noise Cancelling	No
	Awareness Mode	No
Physical	Earbud Weight	0.14 oz (approx. 4g)
	Case Weight	1.4 oz (approx. 40g)
	Color	Dark Grey
	Water Resistance	Earbuds: IPX4, Case: IPX3
App	Mobile Application	Adidas Headphones (iOS & Android)



Image: Technical specifications overview.

WARRANTY AND SUPPORT

Your Adidas Z.N.E. 01 earbuds are covered by a manufacturer's warranty. Please refer to the 'Legal & Safety Information' document included in your product packaging for specific warranty terms and conditions, including duration and coverage details. For customer support, product registration, or to access additional resources, visit the official Adidas website or contact their customer service department.

For returns, a 30-day return policy typically applies, but this may vary based on your retailer and region. Always consult your purchase receipt and retailer's return policy for precise information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question