

[Manuals.plus](#) /

› [Hasbro](#) /

› Star Wars The Black Series Darth Maul Toy 6-Inch-Scale The Clone Wars Collectible Action Figure User Manual

Hasbro F4356

User Manual

STAR WARS THE BLACK SERIES DARTH MAUL ACTION FIGURE

Brand: Hasbro | Model: F4356

1. PRODUCT OVERVIEW

The Star Wars The Black Series Darth Maul action figure is a highly detailed, 6-inch scale collectible inspired by the character from The Clone Wars series. This figure features premium articulation and decoration, allowing for dynamic posing and display. It is designed for collectors and fans aged 4 and up.

Darth Maul, a deadly and agile Sith Lord, is known for his formidable combat skills and his iconic double-bladed lightsaber. This figure captures his menacing ferocity and intricate design.



Image 1.1: The Darth Maul action figure with his signature double-bladed lightsaber, showcasing the figure's detailed sculpt and paint application.

2. SAFETY INFORMATION

WARNING: Small parts may be generated. Not for children under 3 years.

Please ensure all small accessories are kept away from young children to prevent choking hazards. This product is intended for ages 4 and up.

3. WHAT'S IN THE BOX

Upon opening the package, you should find the following components:

- One (1) Darth Maul 6-inch action figure
- One (1) double-bladed lightsaber accessory

4. SETUP

Follow these steps for the initial setup of your Darth Maul action figure:

1. **Unboxing:** Carefully remove the figure and its accessory from the packaging. Retain packaging for future storage if desired.
2. **Accessory Attachment:** The double-bladed lightsaber accessory can be held in the figure's hands. Gently slide the hilt of the lightsaber into the figure's grip. Ensure a secure fit without forcing the accessory, which could cause damage.



Image 4.1: Darth Maul figure with lightsaber attached, ready for display or play.

5. OPERATING THE FIGURE (ARTICULATION AND POSING)

The Darth Maul action figure features multiple points of articulation for dynamic posing. Exercise care when adjusting joints to prevent damage.

- **Head:** The head can rotate and tilt, allowing for expressive poses.
- **Shoulders:** Ball joints at the shoulders allow for a wide range of motion, including rotation and outward movement.
- **Elbows and Wrists:** Articulated elbows and rotating wrists enable various arm and weapon-holding positions.
- **Torso:** The torso typically features an ab crunch and waist swivel for upper body flexibility.
- **Hips and Thighs:** Ball joints at the hips allow for leg movement forward, backward, and outward. Thigh swivels provide additional rotation.
- **Knees and Ankles:** Double-jointed knees and articulated ankles (with rocker pivots) allow for deep stances and stable footing.

Experiment with different joint movements to recreate iconic scenes or create new action poses for your figure.



Image 5.1: The figure demonstrating articulation with a single-bladed lightsaber configuration.

6. MAINTENANCE AND CARE

To ensure the longevity and appearance of your action figure, follow these care guidelines:

- **Cleaning:** Dust the figure regularly with a soft, dry cloth or a soft-bristled brush. For stubborn dirt, lightly dampen a cloth with water (no harsh chemicals) and gently wipe the affected area. Avoid excessive moisture.
- **Storage:** Store the figure away from direct sunlight, extreme temperatures, and high humidity to prevent discoloration, warping, or degradation of materials. Keep it in a cool, dry place.
- **Handling:** Handle the figure by its main body parts rather than small accessories or delicate joints. Avoid dropping the figure or applying excessive force to its limbs.
- **Accessories:** Store accessories in a safe place when not in use to prevent loss or damage.

7. TROUBLESHOOTING

If you encounter any issues with your action figure, consider the following common solutions:

- **Stiff Joints:** If a joint feels stiff, gently try to move it. Avoid forcing it. In some cases, very slight warmth (e.g., from a hairdryer on a low setting, held at a safe distance) can temporarily soften the plastic, but proceed with extreme caution to avoid melting or deforming the figure.
- **Loose Joints:** Over time, some joints may become loose. For minor looseness, a small amount of clear nail polish or a specialized joint-tightening fluid can be applied to the joint and allowed to dry, creating more friction.
- **Bent Accessories:** If the lightsaber blade or other flexible parts become bent, carefully apply gentle heat (e.g., warm water or a hairdryer on low) to the affected area, reshape it, and then cool it quickly (e.g., with cold water) to set the new shape.
- **Figure Not Standing:** Ensure the figure's feet are flat on the surface and its weight is evenly distributed. Adjust leg and ankle articulation to find a stable stance.

8. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Product Dimensions	5 x 9 x 2 inches
Item Weight	3.87 ounces
ASIN	B09H1FR4J1
Item Model Number	F4356
Manufacturer Recommended Age	4 years and up
Release Date	January 7, 2023
Manufacturer	Hasbro

9. WARRANTY AND SUPPORT

This product is manufactured by Hasbro. For information regarding product warranty, returns, or customer support, please refer to the official Hasbro website or contact their customer service department directly.

Please retain your proof of purchase for any warranty claims or support inquiries.