Beyblade F3334

Beyblade Burst QuadDrive Cosmic Vector Battle Set Instruction Manual

Model: F3334

1. Introduction

This manual provides essential instructions for the assembly, operation, and maintenance of your Beyblade Burst QuadDrive Cosmic Vector Battle Set. This set introduces QuadDrive technology, allowing for 4-in-1 top configurations to enhance strategic gameplay.

The set includes the Cosmic Vector Beystadium, two right/left-spin launchers, two Path Diverters, and two right-spin QuadDrive tops: Destruction Belfyre B7 G01 QD01 TS18-Q A01 and Magma Ifritor I7 G03 QD06 TA21-Q B01.



Image 1.1: Complete Beyblade Burst QuadDrive Cosmic Vector Battle Set.

2. What's in the Box

Carefully unpack all contents and verify that all items are present:

- 1x Beyblade Burst QuadDrive Cosmic Vector Beystadium
- 2x QuadDrive Tops (Destruction Belfyre B7, Magma Ifritor I7)
- 2x Right/Left-Spin Launchers
- 2x Path Diverters
- 1x Instruction Sheet (this manual)



Image 2.1: Packaging and contents of the Battle Set.

3. Safety Information

WARNING: CHOKING HAZARD – Small parts may be generated. Not for children under 3 years.

- Do not lean over the Beystadium when tops are in play.

- Do not use the Beystadium on tables or other elevated surfaces to prevent falls.
- Tops may bounce up and strike the eye or face. Always play in a clear, open area.
- Keep small parts away from young children and pets.

4. Setup

4.1. Beystadium Assembly

1. Place the main Beystadium base on a flat, stable surface.
2. Attach the clear plastic cover to the Beystadium base, ensuring it snaps securely into place.
3. Insert the two Path Diverters into their designated slots within the Beystadium. These can be adjusted to alter battle dynamics.

4.2. Launcher Assembly

The set includes two right/left-spin launchers. These are pre-assembled and ready for use. Ensure the ripcord is fully inserted into the launcher before use.

4.3. QuadDrive Top Configuration

Each QuadDrive top can be configured in four distinct ways: Core, Apex, Core+, and Apex+ modes. These modes change the top's performance characteristics.

1. To change modes, carefully detach the performance tip and energy layer from the core disk.
2. Reattach the components in the desired configuration. Refer to the diagrams on the product packaging for visual guidance on each mode.
3. Ensure all parts are securely clicked into place before launching.



Image 4.1: QuadDrive top configuration guide from product packaging.

5. Operating Instructions

5.1. Attaching the Top to the Launcher

1. Hold the launcher firmly.
2. Align the top's prongs with the slots on the launcher.
3. Twist the top clockwise until it locks securely onto the launcher.

5.2. Launching a Beyblade Burst Top

1. Stand at the edge of the Beystadium.
2. Hold the launcher over the Beystadium, aiming for the center.
3. Pull the ripcord swiftly and firmly to launch the top into the Beystadium.



Image 5.1: Proper technique for launching a Beyblade top.

5.3. Battle Gameplay

The objective is to out-spin your opponent's top, burst it into pieces, or knock it out of the Beystadium.

- **Quad Levels:** The Cosmic Vector Beystadium features Quad Levels that influence top movement and battle outcomes.
- **Path Diverters:** Utilize the Path Diverters to create intense ricochets and strategic takedowns against opposing tops.
- **QuadDrive Advantage:** Experiment with the 4-in-1 top configurations to gain a strategic advantage in battles.



Image 5.2: Two players battling with Beyblade Burst tops.

5.4. Beyblade Burst App Integration

Scan the code located on your QuadDrive tops to unlock them for virtual battles within the Beyblade Burst app. The app provides an additional platform for competitive play and tracking your Beymastery journey.

6. Maintenance

- **Cleaning:** Wipe the Beystadium and tops with a dry or slightly damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store all components in a cool, dry place away from direct sunlight. Keep tops and launchers organized to prevent loss or damage.
- **Inspection:** Periodically inspect tops and launchers for wear and tear. Replace damaged components if necessary to ensure optimal performance and safety.

7. Troubleshooting

- **Top not spinning correctly:** Ensure the top is securely attached to the launcher. Verify the ripcord is fully inserted and pulled with sufficient force. Check for any debris obstructing the top's spin.
- **Launcher jamming:** Ensure the ripcord is straight and not twisted. Do not force the ripcord if it feels stuck; gently pull it out and reinsert.
- **Tops bursting too easily:** This is a feature of Beyblade Burst. Experiment with different top configurations (Core, Apex, Core+, Apex+) to find a balance that suits your play style.
- **Beystadium unstable:** Ensure the Beystadium is placed on a flat, level surface. Check that the clear cover and Path Diverters are securely attached.

8. Specifications

Feature	Detail
Product Dimensions	3.56 x 17.75 x 14 inches
Item Weight	7 ounces
Model Number	F3334
ASIN	B09H1MJV4K
Manufacturer Recommended Age	8 years and up
Release Date	January 1, 2022
Manufacturer	Hasbro

9. Warranty and Support

For product support, replacement parts, or warranty inquiries, please contact Hasbro customer service directly. Refer to the contact information provided on the product packaging or visit the official Beyblade website for further assistance.
Please retain your proof of purchase for any warranty claims.

© 2024 Beyblade. All rights reserved. Beyblade Burst and all related terms are trademarks of Hasbro, Inc.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question