

[Manuals.plus](#) /

> [Domo](#) /

> DOMO DO7325F Fan Heater - 2000W User Manual

Domo DO7325F

DOMO DO7325F Fan Heater

MODEL: DO7325F - 2000W



Front view of the DOMO DO7325F fan heater, featuring a black protective grille and a white casing. The DOMO logo is visible on the front.

Introduction

This manual provides essential information for the safe and efficient operation of your DOMO DO7325F fan heater. Please read these instructions carefully before using the appliance and retain them for future reference. The DOMO DO7325F is a portable electric fan heater designed to provide supplemental heating

for rooms up to 16-20 m². It features two heat settings, a fan-only function, and an adjustable thermostat.

Important Safety Instructions

- Always ensure the heater is placed on a stable, flat surface.
- Do not cover the heater during operation to prevent overheating.
- Keep flammable materials at least 1 meter (3 feet) away from the heater.
- Do not use the heater in bathrooms, laundry areas, or similar wet locations.
- Unplug the heater when not in use or before cleaning.
- This appliance is equipped with tip-over protection and overheat safety shut-off features.

Product Overview

The DOMO DO7325F fan heater is designed for ease of use and portability. It includes a robust casing and intuitive controls.



Rear view of the DOMO DO7325F fan heater, highlighting the air intake grille and the integrated handle for easy transport.

Key Components:

- **Control Knobs:** Two rotary knobs for power/mode selection and thermostat adjustment.
- **Indicator Light:** Illuminates when the heater is operating.
- **Front Grille:** Protects the heating element and fan, directs airflow.
- **Rear Air Intake:** Allows air to be drawn into the unit.
- **Integrated Handle:** For convenient carrying.

Setup

Follow these steps to set up your fan heater:

1. **Unpack:** Carefully remove the heater from its packaging. Retain packaging for storage.
2. **Placement:** Place the heater on a firm, level, heat-resistant surface. Ensure there is at least 1 meter (3 feet) of clear space around the heater to allow for proper air circulation and to prevent fire hazards. Do not place it directly under a power outlet.
3. **Power Connection:** Ensure the heater is switched to the 'OFF' position (mode knob). Plug the power cord into a suitable 230V AC wall outlet. Do not use extension cords or power strips with this appliance.



The DOMO DO7325F fan heater positioned on a small table in a living room, demonstrating appropriate placement away from furniture.

Operating Instructions

Your DOMO DO7325F fan heater features two control knobs for easy operation.



Close-up view of the control panel, illustrating the thermostat knob (MIN to MAX) and the mode selector knob (OFF, FAN, LOW, HI).

1. **Power/Mode Selection:** Use the right-hand knob to select the desired operating mode:
 - **OFF:** Turns the heater off.
 - **FAN:** Activates the fan without heat, providing cool air circulation.
 - **LOW:** Provides low heat output (approximately 1000W).

- **HI:** Provides high heat output (approximately 2000W).
2. **Thermostat Adjustment:** Use the left-hand knob to set the desired room temperature. Turn the knob clockwise from MIN to MAX. The heater will operate until the set temperature is reached, then cycle on and off to maintain it. For continuous heating, set the knob to MAX.
 3. **Indicator Light:** The red indicator light will illuminate when the heater is actively producing heat. It will turn off when the heater cycles off due to the thermostat reaching the set temperature.

Safety Features:

- **Overheat Protection:** If the heater overheats, it will automatically shut off. Unplug the unit, allow it to cool for 30 minutes, and clear any obstructions before restarting.
- **Tip-Over Protection:** The heater will automatically shut off if it is accidentally knocked over. Place it upright on a stable surface to resume operation.

Maintenance

Regular maintenance ensures optimal performance and longevity of your heater.

1. **Cleaning:** Always unplug the heater from the power outlet and allow it to cool completely before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
2. **Air Intake:** Periodically clean the rear air intake grille with a vacuum cleaner attachment to remove dust and lint, which can impede airflow and cause overheating.
3. **Storage:** When not in use, store the heater in a cool, dry place, preferably in its original packaging. Ensure the power cord is neatly wrapped and not kinked.

Troubleshooting

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
Heater does not turn on.	No power, mode knob set to OFF, or safety feature activated.	Check power outlet, ensure mode knob is on FAN, LOW, or HI. If safety feature activated, unplug, cool, and check for obstructions.
No heat produced in LOW/HI mode.	Thermostat set too low, or overheat protection activated.	Increase thermostat setting. If overheat protection, follow steps above.
Heater cycles on and off frequently.	Room temperature reached thermostat setting.	This is normal operation. If continuous heat is desired, set thermostat to MAX.
Unusual noise or smell.	Dust accumulation, or internal issue.	Unplug and clean air intake. If problem persists, discontinue use and contact support.

Specifications

Technical details for the DOMO DO7325F fan heater.

Feature	Detail
Model Number	DO7325F
Brand	Domo
Power	2000 Watts
Voltage	230 Volts
Number of Power Levels	3 (Fan, Low Heat, High Heat)
Dimensions (L x W x H)	19.2 x 12 x 26 cm
Weight	1.06 Kilograms
Recommended Room Size	16 - 20 m ²
Cord Length	170 cm
Safety Features	Overheat Protection, Tip-over Safety Shut-off
Color	Black

Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Domo website. Keep your proof of purchase for any warranty claims.

If you encounter issues not covered in this manual, please contact Domo customer service for assistance.