

[Manuals.plus](#) /

› [EszkozTA](#) /

› EszkozTA Phone Camera Remote Control User Manual

## EszkozTA P1

# EszkozTA Phone Camera Remote Control User Manual

Model: P1

## INTRODUCTION

---

The EszkozTA Phone Camera Remote Control is designed to enhance your mobile photography and videography experience by providing convenient, hands-free shutter control. This wireless device allows you to capture photos and videos from a distance, making it ideal for group shots, selfies, vlogs, and stable tripod photography. It connects seamlessly with most smartphones and tablets via Bluetooth, offering ease of use and portability.

## PACKAGE CONTENTS

---

- 2 x Wireless Remote Shutter
- 2 x Adjustable Wrist Strap
- 1 x CR2032 Battery (pre-installed in each remote)
- 1 x User Manual (this document)



Image: The package includes two remote controls, each with an adjustable wrist strap, ready for use.

## SETUP

---

### Pairing Instructions

1. **Turn On the Remote:** Locate the ON/OFF switch on the right side of the remote shutter and slide it to the "ON" position. A blue LED indicator will flash, signifying it is ready for pairing.
2. **Enable Bluetooth on Your Device:** On your smartphone or tablet, navigate to your device's settings and ensure Bluetooth is turned "ON".

3. **Connect to "AB Shutter 3"**: While in your device's Bluetooth screen, look for "AB Shutter 3" in the list of available devices. Select it to initiate the pairing process.
4. **Confirm Connection**: Once successfully paired, your device will display "Connected" next to "AB Shutter 3" in the Bluetooth device list.
5. **Open Camera App**: Open your preferred built-in camera application on your device.

**Note for Android Users:** Do not rename "AB Shutter 3" after pairing, as this may void the warranty and cause the remote to malfunction.

## EASY OPERATRIION



Just by pushing the on/off of the remote, open your phone Bluetooth function on and fine the "ab shutter3" from the list, and select to connect.




Image: Visual guide for the easy pairing and connection process of the remote shutter with a smartphone.



Image: Detailed view of the remote control's features, including the battery compartment and power switch.

## OPERATING INSTRUCTIONS

---

### Taking Photos and Videos

Once paired and your camera app is open, you can use the remote control to capture images or start/stop video recording. The remote features two distinct buttons:

- One button is specifically marked for **iPhone/Camera 360 App** compatibility.
- The other button is designed for **Android** devices.

Simply push the appropriate button on the Bluetooth remote to trigger your device's camera shutter. For Instagram and Snapchat, a long press can initiate video recording, while a short press captures a photo.

The remote offers an operational distance of up to **50 feet (15 meters)**, providing flexibility for various shooting scenarios, including large group photos where you can be part of the picture.



## Easier to take a family photo

Remote control range extends to 50 feet/15m.

Note: the tripod do not include




Image: The remote control allows for easier family photos by enabling the photographer to join the group.

### Using the Adjustable Wrist Strap

Each remote comes with an adjustable wrist strap for added convenience and to prevent accidental drops or loss. To attach the strap, thread the small loop of the strap through the designated hole on the remote control. Then, pass the larger end of the strap through the small loop and pull it tight to secure the remote. The strap can be adjusted to fit various wrist sizes.

# How to Use the Hand Strap



Image: Step-by-step visual instructions for attaching the adjustable wrist strap to the remote.

# Compatible with Most Android IOS Devices



Image: The remote control is compatible with a wide range of Android and iOS devices.

## MAINTENANCE

---

### Battery Replacement

The remote control uses a CR2032 coin cell battery, which is included and pre-installed. When the remote's LED indicator no longer flashes or the remote fails to connect, it may be time to replace the battery. To replace, carefully open the battery slot (refer to the diagram on the remote or packaging for location) and insert a new CR2032 battery with the positive (+) side facing up.

### General Care

- Keep the remote control dry and away from moisture.
- Avoid exposing the device to extreme temperatures.
- Clean the remote with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.

## TROUBLESHOOTING

---

Problem	Possible Cause / Solution
Cannot take pictures with built-in camera app.	Some built-in camera apps may not fully support external Bluetooth shutters. Try downloading other compatible apps such as "Camera 360" from the Apple App Store or "A Better Camera" for Android from the Google Play Store.
Video not starting/stopping on Android device, but photos work.	This can be a compatibility issue with certain Android camera apps. Download "A Better Camera" for Android from the Google Play Store and use it for video recording.
Remote only adjusts phone volume after connection.	Your phone's camera settings might be configured to use volume buttons as the shutter. Find the setting in your phone camera app to change this behavior, allowing photos to be taken via the volume buttons (which the remote emulates).
Remote does not pair or connect.	Ensure the remote is turned ON and has a fresh battery. Make sure Bluetooth is enabled on your device and that "AB Shutter 3" appears in the list. If it doesn't appear, try turning the remote off and on again, or restarting your device's Bluetooth.

## SPECIFICATIONS

---

**Brand:** EszkozTA

**Model Number:** P1

**Color:** Black-Black

**Connectivity Technology:** Bluetooth

**Operational Distance:** Up to 50 feet (15 meters)

**Compatible Devices:** Android devices, iPhone, iPad, Tablets (Android 4.2.2 OS and up / Apple iOS 6.0 and up)

**Battery Type:** 1 x CR2032 (included)

**Item Weight:** 1.13 ounces

**Package Dimensions:** 5.39 x 3.39 x 0.67 inches

**Special Feature:** Lightweight, Adjustable Wrist Strap

## WARRANTY AND SUPPORT

---

Your EszkozTA Phone Camera Remote Control comes with a **15-month warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the quality of your product.

For any questions, concerns, or issues encountered while using our product, please do not hesitate to contact us. Our customer support team is available to assist you.

Contact information for support can typically be found on the product packaging or the retailer's website where the product was purchased.

