

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [foxydry](#) /

› [foxydry Pro Heated Ceiling Clothes Dryer User Manual](#)

foxydry PRO-150

foxydry Pro Heated Ceiling Clothes Dryer User Manual

Model: PRO-150

INTRODUCTION

Thank you for choosing the foxydry Pro Heated Ceiling Clothes Dryer. This innovative and space-saving solution is designed to efficiently dry your laundry indoors. With its remote-controlled operation, integrated heating and ventilation system, and durable construction, the foxydry Pro offers convenience and reliability. Please read this manual carefully before installation and use to ensure safe and optimal performance.

SAFETY INFORMATION

- Always ensure the product is installed by a qualified professional to prevent electrical hazards or structural damage.
- Do not overload the dryer. The maximum weight capacity is 35 kg (77 lbs).
- Keep hands and loose clothing clear of moving parts during operation.
- Do not operate the dryer if any part is damaged or if it is not functioning correctly.
- Ensure the power supply is disconnected before performing any maintenance or cleaning.
- This appliance is for indoor use only.

COMPONENTS AND PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- foxydry Pro Main Unit
- Wireless Remote Control
- Mounting Hardware (screws, anchors)
- User Manual (this document)



Image: The foxydry Pro main unit, showing its extendable bars and the wireless remote control.

SETUP AND INSTALLATION

The foxydry Pro can be installed on either the ceiling or a suitable wall. Professional installation is highly recommended due to electrical connections and structural requirements.


Installation Steps (Overview):

- 1. Choose Location:** Select a suitable ceiling or wall area with adequate structural support and access to a power outlet. Ensure sufficient clearance for the unit to descend.
- 2. Mounting:** Securely attach the main unit to the ceiling or wall using the provided mounting hardware. Follow the detailed instructions in the separate installation guide for precise measurements and drilling.
- 3. Electrical Connection:** Connect the unit to the main power supply. This step must be performed by a certified electrician.
- 4. Remote Pairing:** Once powered, pair the wireless remote control with the unit according to the instructions in the remote control section.



Image: The foxydry Pro installed in a kitchen, demonstrating its discreet ceiling-mounted design when retracted.

OPEN



A **+ B** **+ B**

PRO 150 ▶ 160 cm/62.99 in 40 cm/15.74 in 40 cm/15.74 in

PRO 120 ▶ 122 cm/48.03 in 40 cm/15.74 in 40 cm/15.74 in



**Fast
drying**

CLOSED




Image: A diagram illustrating the open and closed dimensions of the foxydry Pro, including its maximum drop of 1.80 meters and extended bar length.




Image: A diagram showing the foxydry Pro with its extendable bars, indicating the additional 40 cm (15.7 inches) on each side for larger items.

OPERATING INSTRUCTIONS

The foxydry Pro is operated using the provided wireless remote control.

Remote Control Functions:

- **Up/Down Buttons:** Control the vertical movement of the drying rack. The unit can descend up to 1.80 meters (70.86 inches) from the ceiling and can be stopped at any intermediate height.
- **Light Button:** Activates or deactivates the integrated LED panel light. This provides excellent illumination for your laundry area.
- **Fan Button:** Turns on the ventilation fans. The fans circulate ambient air to aid in drying.
- **Heat Button:** Activates the warm air function. This system accelerates drying, especially in colder conditions.

Drying Features:

- **Extendable Bars:** The unit features two double tubes that can be extended by 40 cm (15.7 inches) on each side, providing extra space for large items such as sheets, blankets, or jackets. The maximum extended length is 2 meters.
- **Hanger Positions:** There are 24 dedicated positions for hanging clothes with hangers, ideal for shirts and delicate garments.



Image: The foxydry Pro highlighting its integrated LED light and the numerous positions for clothes hangers.

dry quickly with
warm or fresh ventilation



Made
in Italy



Image: A close-up of the foxydry Pro indicating its warm and fresh ventilation capabilities for quick drying.



**Extra space
for large items**



**Fast
drying**

Image: The foxydry Pro with its side bars extended, providing additional space for drying large items.



Fast
drying

Image: A detailed view of the foxydry Pro's extendable bars mechanism.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your foxydry Pro.

- **Cleaning:** Wipe the unit's surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure the unit is powered off before cleaning.
- **Inspection:** Periodically check the cables and moving parts for any signs of wear or damage. If any issues are found, contact customer support.
- **Ventilation Grilles:** Keep the ventilation grilles clear of dust and lint to ensure efficient airflow.



Durable materials

Image: A close-up view of the foxydry Pro highlighting its construction from durable materials like steel and aluminum.

TROUBLESHOOTING

If you encounter any issues with your foxydry Pro, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit does not respond to remote control.	Low remote battery, unit not powered, remote not paired.	Replace remote batteries. Check power supply to the unit. Re-pair remote control.
Unit does not move smoothly.	Overloaded, obstruction, mechanical issue.	Reduce load. Check for obstructions. Contact customer support if issue persists.
Fans or heating not working.	Power issue, internal fault.	Check power supply. Contact customer support.

Problem	Possible Cause	Solution
LED light not working.	Power issue, LED fault.	Check power supply. Contact customer support.

If the problem persists after attempting these solutions, please contact foxydry customer support.

SPECIFICATIONS

Feature	Detail
Brand	foxydry
Model Number	PRO-150
Color	Silver
Product Dimensions (L x W x H)	160 x 52 x 30 cm (63 x 20.5 x 11.8 inches)
Maximum Weight Capacity	35 Kilograms (77 lbs)
Material	Stainless Steel, Aluminum
Special Features	Warm Ventilation, Space-saving, Remote Control, LED Light, Extendable Bars
Item Weight	18 Kilograms (39.7 lbs)
Country of Origin	Italy

WARRANTY AND SUPPORT

The foxydry Pro comes with a product guarantee. For specific warranty terms and conditions, please refer to the documentation included with your purchase or visit the official foxydry website. For technical support, spare parts, or any inquiries, please contact foxydry customer service through their official channels.

You can visit the foxydry brand store on Amazon for more information: [foxydry Amazon Store](#)