Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EGLO 99663

EGLO Nuvano 3-Light LED Pendant Lamp User Manual

Model: Nuvano (99663)

Introduction

Thank you for choosing the EGLO Nuvano 3-Light LED Pendant Lamp. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions carefully before installation and retain them for future reference.
This modern pendant lamp features a black metal design with golden inner surfaces, providing warm white LED illumination suitable for dining rooms and living areas.

Important Safety Information

Always disconnect power at the main fuse or circuit breaker before installation, maintenance, or changing light sources.

- Installation should be performed by a qualified electrician in accordance with local wiring regulations.
- Ensure the mounting surface can support the weight of the fixture.
- Do not connect the fixture to an ungrounded electrical system.
- Use only GU10 LED bulbs as specified.
- Do not exceed the maximum wattage of 4.5W per bulb.
- This product is designed for indoor use only.
- Keep packaging materials away from children.

For detailed safety information, please refer to the official safety document:Safety Information (PDF).

Package Contents

Verify that all components are present and undamaged before proceeding with installation.

- 1 x EGLO Nuvano 3-Light LED Pendant Lamp
- 3 x GU10 LED Light Sources (4.5W, 3000K, 345 Lumen each)
- 1 x Mounting Hardware Kit

- 1 x Assembly Manual (this document)

Setup and Installation

This section outlines the steps for installing your EGLO Nuvano pendant lamp. While the product is largely pre-assembled, professional installation is recommended for electrical connections.

Tools Required (Not Included):

- Screwdriver (Phillips and/or Flathead)
- Wire Strippers
- Drill (if mounting holes are not pre-existing)
- Pencil
- Measuring Tape
- Safety Glasses

Installation Steps:

1. **Prepare for Installation:** Turn off the power at the circuit breaker or fuse box to the junction box where the fixture will be installed.
2. **Unpack the Fixture:** Carefully remove all components from the packaging. Inspect for any damage.
3. **Determine Mounting Location:** This pendant lamp is designed for ceiling installation, specifically semi-flush mounting. Ensure the chosen location is structurally sound and can support the fixture's weight.
4. **Attach Mounting Bracket:** Secure the mounting bracket to the ceiling junction box using the provided screws. Ensure it is firmly attached.
5. **Adjust Pendant Length:** The pendant cords can be adjusted to your desired hanging height. Loosen the set screws in the canopy to adjust the cord length, then tighten them securely.
6. **Make Electrical Connections:**
    - Connect the fixture's live wire (usually black or brown) to the live wire from the ceiling (usually black or red).
    - Connect the fixture's neutral wire (usually white or blue) to the neutral wire from the ceiling (usually white or black).
    - Connect the fixture's ground wire (usually green/yellow or bare copper) to the ground wire from the ceiling.
    - Ensure all connections are secure with wire nuts and insulated.
7. **Mount the Fixture:** Carefully lift the fixture and attach the canopy to the mounting bracket using the provided screws. Ensure the canopy sits flush against the ceiling.
8. **Install Light Sources:** Insert the included GU10 LED bulbs into their respective sockets by aligning the pins and twisting gently until secure.
9. **Restore Power:** Turn the power back on at the circuit breaker. Test the light fixture.



Figure 1: Product Dimensions. This image displays the overall dimensions of the EGLO Nuvano 3-light pendant lamp, showing a length of 98.5 cm (38.78 inches) and a maximum height of 110 cm (43.31 inches).



Figure 2: EGLO Nuvano Pendant Lamp. A clear view of the EGLO Nuvano 3-light LED pendant lamp, showcasing its black and gold design with three individual light shades.

Operation

The EGLO Nuvano pendant lamp is designed for simple operation and offers dimmable functionality.

Turning On/Off:

Operate the lamp using a standard wall switch connected to the fixture's electrical circuit. Ensure the switch is compatible with LED lighting.

Dimming Functionality:

This fixture is dimmable. To utilize the dimming feature, you must connect it to a compatible dimmer switch (not included) designed for LED lighting. Follow the dimmer switch manufacturer's instructions for installation and operation.

Light Characteristics:

- **Light Source:** Integrated GU10 LED bulbs (3 included)
- **Light Color:** Warm White
- **Color Temperature:** 3000 Kelvin
- **Brightness:** 345 Lumens per bulb (1035 Lumens total)
- **Wattage:** 4.5 Watts per bulb (13.5 Watts total)



Figure 3: Nuvano Lamp in Dining Setting. The EGLO Nuvano pendant lamp illuminating a modern dining area, showcasing its aesthetic appeal and warm light output.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your EGLO Nuvano pendant lamp.

Cleaning:

- **Always disconnect power before cleaning.**
- Wipe the fixture with a soft, dry, or slightly damp cloth.
- Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- Avoid spraying cleaning solutions directly onto the fixture.

Light Source Replacement:

The included LED bulbs are designed for long life. If replacement is necessary:

1. Turn off power to the fixture at the circuit breaker.
2. Allow the bulb to cool completely before handling.
3. Gently twist and pull the old GU10 bulb from its socket.
4. Insert a new GU10 LED bulb (max 4.5W) by aligning the pins and twisting gently until secure.
5. Restore power and test the new bulb.

Troubleshooting

If you encounter issues with your EGLO Nuvano pendant lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	• No power to the fixture. • Loose wiring connection. • Faulty bulb.	• Check circuit breaker/fuse. • Verify all electrical connections (ensure power is off first). • Replace bulb with a known working GU10 LED.
Light flickers or dims unexpectedly.	• Incompatible dimmer switch. • Loose bulb connection. • Faulty bulb.	• Ensure dimmer is LED compatible. • Tighten bulb in socket. • Replace bulb.
Humming noise from fixture.	• Incompatible dimmer switch. • Loose wiring.	• Ensure dimmer is LED compatible. • Check wiring connections (ensure power is off first).

If the problem persists after trying these solutions, please contact EGLO customer support or a qualified electrician.

Specifications

Brand	EGLO
Model Name	NUVANO
Model Number	99663
ASIN	B09H39DW59
Color	Black, Gold
Material	Metal
Style	Modern
Product Dimensions (L x W x H)	98.5L x 22.5W x 110H centimeters
Weight	2843 Grams
Room Type	Dining Room, Living Room
Usage	Residential Indoor
Power Source	Corded Electric
Special Features	Dimmable
Control Method	Touch (via compatible dimmer switch)

Light Source	LED
Number of Light Sources	3
Voltage	230 VAC
Light Color	Warm White
Color Temperature	3000 Kelvin
Total Wattage	13.5 Watts (3 x 4.5W per bulb)
Lamp Fitting	GU10
Brightness	1035 Lumens (3 x 345 Lumens per bulb)
Water Resistance Level	Not Water Resistant
Mounting Type	Suspension, Semi-flush mount
Country of Origin	China

Warranty and Support

Warranty Information:

This EGLO Nuvano pendant lamp comes with a**2-year limited warranty** from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use. It does not cover damage caused by improper installation, misuse, accidents, or unauthorized modifications.
Please retain your proof of purchase for warranty claims.

Customer Support:

For technical assistance, warranty claims, or any questions regarding your EGLO product, please contact EGLO customer support through their official website or the retailer where you purchased the product.
You can find more information about EGLO products and support at:www.eglo.com

© 2023 EGLO. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09H39DW59

More documents and user manuals: **https://manuals.plus/**