Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

havit MS626GT

Havit MS626GT Wireless Mouse User Manual

Model: MS626GT

Introduction

Thank you for choosing the Havit MS626GT 2.4GHz Wireless Mouse. This manual provides essential information for setting up, operating, and maintaining your new wireless mouse. Please read this manual carefully before use to ensure optimal performance and longevity of your device.

Product Overview

The Havit MS626GT is a compact and portable wireless mouse designed for comfortable and efficient use with personal computers and laptops. It features 2.4GHz wireless connectivity and a 1200 DPI optical sensor for precise tracking.





Figure 1: Havit MS626GT Wireless Mouse (Top View)
This image displays the Havit MS626GT wireless mouse from a top-down perspective. The mouse is predominantly black with striking red accents along its sides and around the scroll wheel. The Havit brand logo is visible towards the bottom of the mouse body. The design is ambidextrous, suitable for both left and right-handed users.

Components:

- **Left Click Button:** Standard primary click function.
- **Right Click Button:** Standard secondary click function.
- **Scroll Wheel:** For vertical scrolling and middle-click function.
- **Optical Sensor:** Located on the underside for tracking movement.
- **Battery Compartment:** Located on the underside for battery insertion.
- **USB Receiver:** Small dongle for wireless connection (typically stored inside the mouse).

Setup

1. **Install Battery:**

   Locate the battery compartment on the underside of the mouse. Open the cover and insert one AA battery (not included), ensuring correct polarity (+/-). Close the battery compartment cover securely.

2. **Connect USB Receiver:**

   Remove the USB receiver from its storage slot, usually located near the battery compartment. Plug the USB receiver into an available USB port on your computer or laptop.

3. **Power On:**

   The mouse should automatically power on once the battery is installed and the USB receiver is connected. If there is an on/off switch, ensure it is in the "ON" position. Your computer should automatically detect and install the necessary drivers.

Note: For optimal performance, ensure the mouse is within the effective range of the USB receiver (typically up to 10 meters).

Operating Instructions

Basic Functions:

- **Left Click:** Press the left button to select items, open links, or activate functions.
- **Right Click:** Press the right button to open context menus or access additional options.
- **Scroll Wheel:** Roll the wheel up or down to scroll through documents or web pages. Press the wheel down for middle-click functionality (e.g., opening links in new tabs).

DPI (Dots Per Inch):

The Havit MS626GT operates at a fixed 1200 DPI, providing a balanced sensitivity for general office and personal computer use. This means the cursor will move 1200 pixels for every inch the mouse moves on your surface.

Maintenance

- **Cleaning:**

  To clean the mouse, gently wipe its surface with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the internal components. Do not use harsh chemicals or abrasive cleaners.

- **Battery Replacement:**

  When the mouse performance degrades or the cursor becomes erratic, it may be time to replace the battery. Follow the battery installation steps in the "Setup" section.

- **Storage:**

  When not in use for extended periods, it is recommended to remove the battery to prevent leakage. Store the mouse and USB receiver in a cool, dry place, away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Mouse not responding.	Low battery; USB receiver not connected; Mouse not powered on.	Replace battery; Ensure USB receiver is firmly plugged in; Check if mouse is switched on.
Cursor erratic or lagging.	Low battery; Interference; Dirty optical sensor; Unsuitable surface.	Replace battery; Move mouse closer to receiver; Clean optical sensor; Use a mouse pad or smooth, non-reflective surface.

Problem	Possible Cause	Solution
Wireless connection issues.	Receiver too far; Interference from other wireless devices.	Reduce distance between mouse and receiver; Move other wireless devices away.

Specifications

Brand:	Havit
Model:	MS626GT
Connectivity:	2.4GHz Wireless
DPI:	1200 DPI
Buttons:	3 (Left, Right, Scroll Wheel Click)
Hand Orientation:	Ambidextrous
Power Source:	Battery Powered (1x AA, not included)
Compatible OS:	Linux, Windows XP (and generally newer Windows versions)
Hardware Platform:	Laptop, Personal Computer
Item Weight:	Approximately 50g
Color:	Black X Red

Warranty and Support

Havit products are designed and manufactured to the highest quality standards. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty card included with your purchase or visit the official Havit website for detailed warranty terms and conditions.
For technical support, troubleshooting assistance, or warranty claims, please contact Havit customer service through their official channels. Keep your purchase receipt as proof of purchase.
Disclaimer: Product specifications and appearance are subject to change without prior notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09H4NSXB6

More documents and user manuals: **https://manuals.plus/**