

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [SOULYI](#) /
- › [SOULYI Biometric Gun Safe Model B09H5KKDBK Instruction Manual](#)

SOULYI B09H5KKDBK

SOULYI Biometric Gun Safe Instruction Manual

Model: B09H5KKDBK

1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your SOULYI Biometric Gun Safe, Model B09H5KKDBK. This safe is designed to provide secure storage for firearms, featuring multiple quick access methods including biometric fingerprint recognition, a digital keypad, and traditional key access. It is constructed from hardened alloy steel and is certified by the California Department of Justice for safety standards.



Image 1.1: The SOULYI Biometric Gun Safe in pink, featuring a biometric scanner and digital keypad.

2. SAFETY INFORMATION

Your safety and the security of your firearms are paramount. Please read and adhere to all safety guidelines.

- **DOJ Certified:** This gun safe meets the stringent safety standards of the California Department of Justice, ensuring robust protection against unauthorized access.
- **Pry-Resistant Construction:** The safe features a whole-body pry-resistant design with a lid edge that overlaps the interior box, preventing tool penetration. The construction utilizes 1.5 mm alloy steel for the box and 3 mm for the door sheet, with reinforcing steel on the sides.
- **Child Safety:** Always store firearms securely in the safe to prevent access by children and unauthorized individuals.
- **Secure Placement:** Ensure the safe is placed in a location that minimizes the risk of theft or unauthorized access. Utilize the included security cable to anchor the safe to a fixed object when possible.

CAPACITY OF EACH MODEL



Image 2.1: Screenshot of a document indicating DOJ certification for a similar lock box model.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x SOULYI Biometric Gun Safe
- 2 x Backup Keys
- 4 x AA Batteries (may be included separately or pre-installed)
- 1 x Steel Security Cable
- 1 x Clip (for security cable)
- DIY Diamond Stickers (for customization, optional use)



Image 3.1: Visual representation of the items included with the SOULYI gun safe, including the safe, keys, batteries, security cable, and decorative stickers.

4. SETUP

4.1 Battery Installation

1. Locate the battery compartment, typically on the inside of the safe door or a designated panel.
2. Insert 4 AA batteries, ensuring correct polarity (+/-).
3. Close the battery compartment securely.

4.2 Fingerprint Registration

The safe can store up to 100 unique fingerprints for quick access.

1. Press the fingerprint set button. The indicator light will turn blue with two beeps.
2. Place your finger (part 1) fully on the scanner. Success is indicated by one beep and the indicator light remaining blue.
3. Repeat step 2 for part 2 of your finger.
4. Repeat step 2 for part 3 of your finger.
5. Repeat step 2 for part 4 of your finger.
6. After the fourth successful scan, fully cover the scanner with your finger. A long beep and a green indicator light confirm successful fingerprint registration.



Image 4.1: Diagram illustrating the five steps for registering a fingerprint on the SOULYI gun safe.

4.3 Digital Keypad Setup

You can set a 3 to 8-digit password for keypad access.

1. Refer to the detailed instructions in the included quick start guide for specific steps on setting your digital password.
2. Choose a memorable but secure code.
3. Test the new code multiple times to ensure it is correctly programmed.

4.4 Key Access

Two spare keys are provided for traditional access. These keys can be used as a backup in case of battery failure or if you forget your codes/fingerprints.



Image 4.2: Close-up of the specialized H-shaped keys for manual access to the safe.

5. OPERATION

5.1 Opening the Safe

- **Fingerprint:** Place a registered finger on the biometric scanner. The safe will unlock within 0.1 seconds if the fingerprint is recognized.
- **Digital Keypad:** Enter your programmed 3-8 digit password on the electronic keypad.
- **Key:** Insert one of the backup keys into the keyhole and turn to unlock.




Image 5.1: The interior of the SOULYI gun safe, showing ample space for firearms and an internal light.

5.2 Silent Mode

The safe features separate switches to turn off light and sound indicators. This allows for discreet access in emergency situations and helps conserve battery power.

5.3 Low Battery Warning

The safe is equipped with a low battery warning system. When batteries are low, the indicator light will signal, prompting you to replace them. Always replace all 4 AA batteries simultaneously to ensure optimal performance.



6. INSTALLATION AND PLACEMENT

The compact size of the SOULYI gun safe allows for versatile placement in various locations, including offices, bedrooms, closets, under car seats, or bedside tables. To enhance security, use the provided steel security cable.

- **Security Cable:** Loop the high-strength steel security cable around a solid, immovable object (e.g., car seat frame, bed frame) and secure it to the safe. This prevents the safe from being easily removed.
- **Optimal Placement:** Choose a location that is discreet and easily accessible to authorized users, but out of reach and sight of children.

State of California Department of Justice



ROB BONTA
Attorney General

HOME ABOUT MEDIA CAREERS REGULATIONS RESOURCES PROGRAMS CONTACT

Approved Safety Devices

Approved Safety Device

Manufacturer: Ningbo Shuyi Security Technology Co., LTD
Model: SSZ-01
Type: Lock Box
Description:
The device is for firearms with a trigger guard that is under 12.6 in long and 8.2 in wide. The thickness for the firearms should be under 2.76 in.

Tested Firearm

Firearms Manufacturer: N. American Arms
Firearm Model: NAA22LR
Firearm Caliber: .22 LR
Firearm Barrel Length: 1 1/8"

***DOJ CERTIFICATION
NOT EVERYONE QUALIFIED***

[Back to search results](#)

Image 6.1: The SOULYI gun safe secured in a car using the security cable, demonstrating its portability and car travel safety feature.

Easy to hide
Stay away from children




Image 6.2: The SOULYI gun safe discreetly placed on a shelf in a closet, illustrating its ease of concealment.

7. MAINTENANCE

- **Cleaning:** Wipe the exterior of the safe with a soft, dry cloth. Avoid abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries promptly when the low battery warning is activated. Use only new AA alkaline batteries.
- **Key Storage:** Store backup keys in a secure location away from the safe and out of reach of unauthorized individuals.

8. TROUBLESHOOTING

- **Fingerprint Reader Not Responding:** Ensure your finger is clean and dry. Try re-registering your fingerprint if issues persist. If the reader consistently fails, try using a different registered finger or the digital keypad/key.
- **Safe Not Opening with Registered Fingerprint:** Ensure full contact of the finger with the scanner. If multiple attempts fail, the safe may lock out for a short period. Use the digital keypad or backup key.

- **Digital Keypad Not Responding:** Check battery levels. Ensure you are entering the correct 3-8 digit code.
- **Lid Has Slight Play/Rattles:** While the safe is designed for pry-resistance, minor movement in the lid when shut may occur. This does not compromise the security of the locking mechanism.
- **Foam Padding Detachment:** The internal foam padding may detach over time. This can be re-secured with appropriate adhesive if desired. Consider adding additional foam for a tighter fit for your firearms.
- **Safe Not Powering On:** Check battery installation and replace with fresh batteries if necessary.

9. SPECIFICATIONS

Feature	Detail
Brand	SOULYI
Model	B09H5KKDBK
Product Dimensions	10.6"D x 14.1"W x 3.2"H
Lock Type	Biometric (Fingerprint), Digital Keypad, Key
Color	Biometric & Pink
Capacity	0.17 Cubic Feet (Accommodates up to 3 standard handguns)
Material	Alloy Steel (Box: 1.5mm, Door: 3mm)
Special Features	Fingerprint Sensor, Portable, Silent Mode, Low Battery Warning
Mounting Type	Freestanding, Tabletop (with security cable option)
Item Weight	14.08 pounds (6.4 Kilograms)
Power Source	4 AA Batteries (required)
Water Resistance Level	Not Water Resistant



VS

Not every gun safe
can stand a bullet

Image 9.1: Diagram illustrating the internal dimensions and capacity of the safe, showing it can hold multiple handguns.

10. WARRANTY AND SUPPORT

For any issues or questions regarding your SOULYI Biometric Gun Safe, please contact customer service. We are committed to providing support and will assist you as quickly as possible.

Refer to your purchase documentation or the SOULYI brand store on Amazon for specific warranty details and contact information.

[Visit the SOULYI Store on Amazon](#)