



Manuals.plus /

› ZdalaMit /

› ZdalaMit AKB74815301 Remote Control User Manual for LG Soundbars

ZdalaMit AKB74815301

ZdalaMit AKB74815301 Remote Control User Manual

Replacement Remote Control for LG Soundbars

1. INTRODUCTION

This manual provides instructions for the ZdalaMit AKB74815301 replacement remote control. This remote is designed to be compatible with various LG Soundbar models, offering a direct replacement without the need for complex programming.

Compatible LG Soundbar Models:

- S55A3-D
- LAS454B
- S45A1-D
- LAS453B
- SH3B
- SPH3B-W
- SH3K
- SJ4Y
- SPH4B-W
- LAS485B



Image 1.1: The AKB74815301 remote control in use with an LG Soundbar.

2. SETUP

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open it.
3. Insert two (2) AAA 1.5V alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Power Supply:

**2 PCS AAA Size
Alkaline Battery**

Image 2.1: Battery compartment for AAA batteries.

2.2 Initial Use

The ZdalaMit AKB74815301 remote control is pre-programmed and does not require any additional setup or pairing with your LG Soundbar. Once batteries are installed, it is ready for immediate use.

3. OPERATING INSTRUCTIONS

Point the remote control directly at your LG Soundbar and press the desired button to perform a function. Ensure there are no obstructions between the remote and the soundbar.





Image 3.1: Front view of the AKB74815301 Remote Control.

3.1 Button Functions

- **Power ():** Turns the soundbar on or off.
- **F (Function/Source):** Cycles through input sources (e.g., Optical, Bluetooth, HDMI).
- **VOL + / -:** Increases or decreases the main volume level.
- **Mute ():** Mutes or unmutes the sound.
- **STANDARD:** Activates the standard sound effect mode.
- **VOICE:** Activates the voice enhancement sound effect mode.

- **CINEMA:** Activates the cinema sound effect mode.
- **DRC ON / OFF:** Toggles Dynamic Range Control on or off.
- **WOOFER LEVEL + / -:** Adjusts the subwoofer level.
- **AUTO POWER ON / OFF:** Toggles the auto power function on or off.

4. MAINTENANCE

4.1 Battery Replacement

Replace batteries when the remote control's response becomes inconsistent or stops working. Always replace both AAA batteries simultaneously with new ones.

4.2 Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Avoid using liquid cleaners, solvents, or abrasive materials, as these can damage the remote's surface or internal components.

4.3 Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, it is recommended to remove the batteries to prevent leakage.

5. TROUBLESHOOTING

- **Remote not responding:**
 - Ensure batteries are inserted correctly with the correct polarity.
 - Replace old batteries with new AAA alkaline batteries.
 - Check for any obstructions between the remote control and the soundbar's sensor.
 - Ensure you are within the effective operating range of the soundbar.
- **Intermittent response:**
 - This may indicate low battery power. Replace batteries.
 - Ensure the remote's infrared emitter is clean and unobstructed.

6. SPECIFICATIONS

Feature	Detail
Model Number	AKB74815301
Brand	ZdalaMit
Power Supply	2 x 1.5V AAA Alkaline Batteries
Product Dimensions	6 x 2 x 0.5 inches
Item Weight	1.3 ounces
Color	Black
Special Feature	Pre-Programmed (No pairing required)
Max Supported Devices	1 (LG Soundbar)



Image 6.1: Remote control dimensions.

7. WARRANTY INFORMATION

No specific warranty information is provided with this product. For details regarding returns or replacements, please refer to the retailer's policy where the product was purchased.

8. SUPPORT

If you encounter any issues or have questions regarding the ZdalaMit AKB74815301 remote control that are not covered in this manual, please contact the seller or manufacturer for assistance.

