

KEiD KD-V01

KEiD KD-V01 CD Player Home Stereo System Instruction Manual

1. INTRODUCTION

Thank you for purchasing the KEiD KD-V01 CD Player Home Stereo System. This versatile audio system combines a slot-in CD player, Bluetooth connectivity, FM radio, and multiple input options (USB, SD, AUX) into a single, elegantly designed unit. It delivers rich, high-fidelity sound suitable for various home audio needs, including music playback and enhancing TV audio. This manual provides essential information for safe operation, setup, and maintenance of your device.



Image: The KEiID KD-V01 CD Player Home Stereo System positioned on a shelf in a living space, showcasing its retro wooden design.

2. IMPORTANT SAFETY INFORMATION

Please read all safety instructions carefully before using this product. Keep this manual for future reference.

- **Power Source:** Only use the provided power adapter. Ensure the voltage matches the requirements specified on the unit.
- **Ventilation:** Do not block any ventilation openings. Allow adequate space around the unit for proper airflow to prevent overheating.
- **Water and Moisture:** Do not expose the unit to rain, moisture, or dripping/splashing liquids. Do not place objects filled with liquids, such as vases, on the unit.
- **Heat:** Keep the unit away from heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Cleaning:** Unplug the unit from the power outlet before cleaning. Use a dry, soft cloth only. Do not use liquid

cleaners or aerosol cleaners.

- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel. Opening the unit may expose you to dangerous voltage or other hazards.
- **Object and Liquid Entry:** Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock.
- **Placement:** Place the unit on a stable, flat surface. Avoid placing it in direct sunlight or near strong magnetic fields.

3. PACKAGE CONTENTS

Please check that all items listed below are included in your package:

- KEiiD KD-V01 CD Player Home Stereo System
- Remote Control
- Power Adapter
- RCA Audio Cable (for AUX connection)
- User Manual

4. PRODUCT OVERVIEW

The KEiiD KD-V01 features a user-friendly interface with physical controls and a clear LCD display. Below is an overview of its main components and features.

One for All Media Resources

Retro look, Furniture style, Solidly built



Know its big size before ordering: 28 inch width, weighted 20 lb.



**All formats audio
CDs**



**Bluetooth
wireless stereeming**



**Full band
FM radio**



**3.5mm, RCA
AUX line in**



**USB / SD flash
drive playback**



**Remote
control**



**Dimmer/
night mode**



**Random/Repeat
play options**

AM radio does not work on this device, Please do not order if you ned AM function

Image: Front view of the KEiiD KD-V01 system, highlighting its various features including CD player, Bluetooth, FM radio, USB/SD, AUX, and remote control functionality.

Front Panel Controls and Display

- **5-inch LCD Display:** Shows current mode, track information, radio frequency, and other relevant data.
- **CD Slot:** For inserting and ejecting audio CDs.
- **Control Knobs/Buttons:** For power, volume, mode selection, playback control (play/pause, skip), and menu navigation.
- **USB Port:** For connecting USB flash drives.
- **SD Card Slot:** For inserting SD memory cards.
- **AUX Input (3.5mm):** For connecting external audio devices.

Rear Panel Connections

- **FM Antenna:** For radio reception.
- **RCA AUX Input:** For connecting devices via RCA audio cables.
- **Power Input:** For connecting the power adapter.

Remote Control

The included remote control allows for convenient operation of all functions from a distance.

5. SETUP

5.1 Unpacking

Carefully remove the unit and all accessories from the packaging. Retain the packaging for future transport or storage.

5.2 Placement

Place the KEiiD KD-V01 on a stable, flat surface. Ensure there is adequate space around the unit for ventilation. The full wooden enclosure contributes to rich Hi-Fi sound, and its design makes it a suitable addition to various home environments.



Image: The KEiD KD-V01 system placed in a living room, illustrating its ability to fill the space with sound.

5.3 Power Connection

1. Connect the power adapter to the DC input port on the rear of the unit.
2. Plug the power adapter into a wall outlet.

5.4 Antenna Connection

Extend the FM antenna fully for optimal radio reception. Adjust its position if reception is poor.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off

Press the **Power** button on the front panel or remote control to turn the unit on or off.

6.2 Mode Selection

Press the **Mode** button on the front panel or remote control to cycle through available input sources: CD, Bluetooth, FM Radio, USB, SD, and AUX.

6.3 CD Playback

1. Select **CD** mode.
2. Gently insert an audio CD into the slot until it is pulled in automatically. The display will show "Loading" and then track information.
3. Playback will begin automatically. Use the **Play/Pause**, **Skip Forward**, and **Skip Backward** buttons on the unit or remote to control playback.
4. To eject the CD, press the **Eject** button.

6.4 Bluetooth Operation

The system supports Bluetooth for wireless audio streaming and hands-free calls.

1. Select **Bluetooth** mode. The display will show "BT" or "Pairing".
2. On your smartphone or tablet, enable Bluetooth and search for available devices.
3. Select "KEiID KD-V01" from the list to pair. Once connected, the unit will confirm with an audible tone or display "Connected".
4. You can now stream audio wirelessly from your device. Use the unit's controls or your paired device to manage playback.
5. For hands-free calls, the built-in microphone allows you to answer calls directly through the system.

Wireless streaming with your phone via Bluetooth

Built-in mic for handsfree calls.



Image: A smartphone wirelessly connected to the KEiID KD-V01 system via Bluetooth, displaying music playback.

6.5 FM Radio

The unit features a full-band FM radio (87.5-108 MHz).

1. Select **FM Radio** mode.
2. Use the **Scan** button to automatically search and save available stations. The unit supports up to 12 presets.
3. Use the **Tune** buttons to manually adjust the frequency or cycle through saved presets.

Note: This device does not support AM radio functionality.

6.6 USB/SD Playback

The system supports playback from USB flash drives and SD cards.

1. Insert a USB flash drive into the USB port or an SD card into the SD card slot.
2. Select **USB** or **SD** mode.

3. The display will show folder and track information. Use the navigation buttons to browse and select desired audio files (MP3 format supported).

6.7 AUX Input

Connect external audio devices using the 3.5mm AUX input or the RCA AUX input.

1. Connect your external audio device (e.g., laptop, smartphone, TV with analog audio output) to the unit using a 3.5mm audio cable or the provided RCA audio cable.
2. Select **AUX** mode.
3. Audio from your connected device will now play through the KEiID KD-V01. Control playback from your external device.

7. SOUND SETTINGS

The KEiID KD-V01 allows for personalized audio adjustments to suit your preferences.

- **Bass, Midrange, Treble Adjustment:** Navigate to the sound settings menu using the remote or front panel controls. You can adjust the bass, midrange, and treble levels by +/- 9dB.
- **Volume Control:** Use the volume knob on the front panel or the **Volume +/-** buttons on the remote control to adjust the overall sound level.

Full range rich sound driven by 4 inch bass and 1 inch dome-silk tweeter

Slot-in CD player



Image: An internal view of the KEiiD KD-V01 system, illustrating the high-quality silk dome tweeter and 4-inch bass speaker components.

8. MAINTENANCE

8.1 Cleaning

To maintain the appearance and performance of your unit:

- Always unplug the unit before cleaning.
- Use a soft, dry cloth to wipe the exterior surfaces.
- Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.
- For the CD slot, use a specialized CD lens cleaner if necessary.

9. TROUBLESHOOTING

If you encounter any issues with your KEiiD KD-V01, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power	Power adapter not connected; Power outlet faulty.	Ensure power adapter is securely connected to the unit and a working outlet.
No sound	Volume too low; Incorrect mode selected; Cables not connected properly.	Increase volume. Select the correct input mode (CD, BT, FM, USB, SD, AUX). Check all audio cable connections.
CD skipping or not playing	CD is dirty, scratched, or inserted incorrectly; Unit's CD mechanism issue.	Clean the CD with a soft cloth. Try a different CD. Ensure the CD is inserted correctly. If the issue persists with multiple CDs, contact support.
Bluetooth pairing failure	Bluetooth not enabled on device; Unit not in pairing mode; Device too far.	Ensure Bluetooth is enabled on your device and the unit is in Bluetooth mode. Move devices closer. Try restarting both devices.
Poor FM reception	Antenna not extended or positioned correctly; Weak signal in area.	Fully extend and adjust the FM antenna. Try repositioning the unit.
Remote control not working	Batteries are dead or inserted incorrectly; Obstruction between remote and unit.	Replace remote control batteries. Ensure batteries are inserted with correct polarity. Remove any obstructions.

10. SPECIFICATIONS

Feature	Detail
Model Number	KD-V01
Brand	KEiiD
Product Dimensions (L x W x H)	71.12 x 21.84 x 16 cm (28 x 8.6 x 6.3 inches)
Item Weight	9.07 kg (20 lbs)
Power Source	Corded Electric
Connectivity Technology	Auxiliary, USB, Bluetooth
Supported Audio Formats	CD, MP3
FM Radio Frequency	87.5-108 MHz (No AM radio support)
Compatible Devices	Laptop, Smartphone
Display	5-inch LCD
Sound Adjustment	+/- 9dB for Bass, Midrange, Treble

11. WARRANTY AND SUPPORT

11.1 Product Warranty

The KEiiD KD-V01 CD Player Home Stereo System comes with a**1-year warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use.

11.2 After-Sales Service

For any questions, technical assistance, or warranty claims, please contact KEiiD customer support. Our after-sales service team aims to respond within **12 hours** to address your concerns.

Please refer to the contact information provided on the product packaging or the official KEiiD website for the most up-to-date support channels.

© 2024 KEiiD. All rights reserved. KEiiD and the KEiiD logo are trademarks of KEiiD.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question