Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SoBuy FSR96-W

SoBuy FSR96-W Shoe Bench with Seat Instruction Manual

Brand: SoBuy | Model: FSR96-W

1. Introduction

Thank you for choosing the SoBuy FSR96-W Shoe Bench with Seat. This versatile piece of furniture is designed to enhance your entryway or bedroom with both seating and storage solutions. It features two storage compartments under the seat and additional shelving behind doors, providing ample space for shoes, gloves, books, and other items. Constructed from durable PB (E1) material with a comfortable PU upholstered seat, this bench is built for longevity and ease of maintenance.

Please read this manual carefully before assembly and use to ensure proper installation and safe operation of your new shoe bench.



Image 1.1: The SoBuy FSR96-W Shoe Bench providing seating and storage in an entryway.

2. Safety Information

- **Maximum Load Capacity:** The maximum weight capacity for this bench is 150 kg (approximately 330 lbs). Do not exceed this limit to prevent damage or injury.
- Ensure all screws and fasteners are securely tightened during assembly. Periodically check and re-tighten as necessary.
- Do not stand on the bench. Use it only for sitting or storing items.
- Keep small parts and packaging materials away from children to avoid choking hazards.
- Place the bench on a flat, stable surface to prevent tipping.

3. Setup and Assembly

Assembly is required for this product. Detailed assembly instructions are included in the product packaging. Please follow these instructions carefully, step-by-step, to ensure correct and safe assembly.

Assembly Tips:

- It is recommended to assemble the bench with two people, although it can be done by one person.
- Lay out all components and hardware before starting. Verify all parts are present against the parts list in the included manual.
- The screw holes are not pre-threaded. When inserting screws, they will create their own thread in the wood. Be careful to align screws straight and avoid overtightening, especially if using an electric screwdriver, as the material is engineered wood, not solid wood.
- Once assembled, adjust the door hinges to ensure proper alignment of the doors with the bench structure.



Image 3.1: A screwdriver, a common tool for assembly.



Image 3.2: Detail of hinges, which may require adjustment for door alignment.

4. Operating Instructions

Using the Seat:

The upholstered seat provides a comfortable spot for sitting, ideal for putting on or taking off shoes. Ensure the bench is stable before sitting. The seat is designed for two people.



Image 4.1: Detail of the comfortable upholstered seat.

Using the Storage Compartments:

- **Under-Seat Storage:** Lift the upholstered seat sections to access two hidden storage compartments. These are perfect for smaller items like gloves, scarves, or shoe care products.
- **Side Cabinets:** Open the two side doors to reveal enclosed storage space, suitable for shoes or other personal belongings.
- **Open Shelves:** The central section features open shelves, ideal for displaying decorative items or storing frequently accessed shoes.



Image 4.2: Hidden storage compartments under the seat.



Image 4.3: Side cabinets and open shelves for shoe storage.

5. Maintenance

To maintain the appearance and longevity of your SoBuy FSR96-W Shoe Bench, follow these simple care instructions:

- **Cleaning:** Wipe the surfaces with a dry cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Cushion Care:** The PU upholstery is durable and easy to clean. For spills, gently blot with a damp cloth and mild soap, then wipe dry.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Avoid Moisture:** Keep the bench away from excessive moisture or direct sunlight to prevent warping or discoloration.

6. Troubleshooting

Common Issues and Solutions:

- **Doors Not Aligning:** If a door does not align perfectly after assembly, adjust the hinges. Most furniture hinges allow for minor adjustments (up/down, left/right, in/out) using a screwdriver. Refer to the specific hinge adjustment instructions in your assembly manual.
- **Wobbly Bench:** Ensure the bench is placed on a level surface. Check all assembly screws and tighten any that are loose.
- **Difficulty with Screws:** If screws are difficult to insert, ensure they are aligned straight with the pilot hole. Do not force them, as this can strip the wood.

7. Specifications



Image 7.1: Product dimensions overview.

Feature	Detail
Product Dimensions (L x W x H)	100 x 34 x 48 cm (39.4 x 13.4 x 18.9 inches)
Material	Engineered Wood (PB E1), Polyurethane (PU) upholstery
Color	White (Bench), Grey (Cushion)
Weight	Approximately 24 kg (52.9 lbs)
Maximum Weight Capacity	150 kg (330 lbs)
Number of Storage Compartments	2 under-seat, 2 behind doors, 2 open shelves
Assembly Required	Yes
Country of Origin	China

8. Warranty and Support

SoBuy is committed to providing innovative and modern furniture solutions. For any questions or suggestions regarding your product, please do not hesitate to contact us. We will do our best to meet your needs and answer your questions.

- **Return Policy:** This product is returnable within 30 days of receipt. Please refer to the retailer's return policy for detailed information.
- **Customer Support:** For assistance, please contact SoBuy-IT customer service. Contact details can typically be found on the retailer's website or within your purchase documentation.

Note: Specifications are subject to change without notice.

© 2023 SoBuy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09H7C1GFV

More documents and user manuals: **https://manuals.plus/**