

Mintu JT5000SF6SS (and compatible GE models)

Mintu Bake Element Replacement Manual

For General Electric Wall Ovens (Models including JT5000SF6SS, JT5500BL5TS, etc.)

1. INTRODUCTION

This manual provides comprehensive instructions for the safe and effective replacement of the bake element in compatible General Electric wall ovens. The Mintu Bake Element is designed as a direct replacement to restore proper heating function to your appliance. Please read all instructions carefully before beginning the installation process.

For a complete list of compatible models, please refer to the product description or consult the manufacturer's specifications.

2. SAFETY INFORMATION

WARNING: Risk of Electric Shock and Injury.

- Always disconnect power to the oven at the circuit breaker or fuse box before attempting any service or repair. Failure to do so can result in serious injury or death.
- Wear appropriate personal protective equipment, such as work gloves, to prevent cuts or scrapes.
- Ensure the oven has completely cooled down before handling any internal components.
- If you are unsure about any step, consult a qualified appliance technician.
- Keep children and pets away from the work area.

3. PRODUCT OVERVIEW

The Mintu Bake Element is a heating component responsible for generating heat from the bottom of the oven cavity. It typically consists of a metal heating coil encased in a protective sheath, with electrical terminals for connection.




Figure 3.1: Full view of the Mintu Bake Element. This image shows the complete heating coil design, which is crucial for even heat distribution within the oven.



Figure 3.2: Close-up view of the electrical terminals on the bake element. These terminals connect the element to the oven's power supply, allowing it to heat up.

4. SETUP AND INSTALLATION

This section outlines the steps for replacing the bake element. Ensure all safety precautions are followed.

1. **Disconnect Power:** Locate the circuit breaker for your oven and turn it OFF. Verify that the oven is completely without power before proceeding.
2. **Access Oven Interior:** Open the oven door. Remove any oven racks to provide clear access to the bake element.
3. **Locate Bake Element:** The bake element is typically located at the bottom of the oven cavity. It is usually held in place by a few screws.
4. **Remove Mounting Screws:** Using a screwdriver, carefully remove the screws that secure the bake element to the back wall of the oven. There are usually two screws.

5. **Gently Pull Element Forward:** Once the screws are removed, gently pull the element forward a few inches. This will expose the electrical terminals at the back.
6. **Disconnect Electrical Wires:** Carefully disconnect the two electrical wires from the terminals of the old bake element. It is recommended to take a photo of the wiring configuration before disconnecting to ensure correct re-connection. If the wires retract into the wall, you may need to use needle-nose pliers to retrieve them.
7. **Remove Old Element:** Once the wires are disconnected, carefully remove the old bake element from the oven cavity.
8. **Install New Element:** Connect the electrical wires to the terminals of the new Mintu Bake Element. Ensure the connections are secure.
9. **Secure New Element:** Carefully push the new element back into place, aligning the mounting holes. Reinsert and tighten the mounting screws.
10. **Replace Oven Racks:** Place the oven racks back into their original positions.
11. **Restore Power:** Go back to the circuit breaker and turn the power to the oven ON.
12. **Test Functionality:** Turn on the oven to a bake setting (e.g., 350°F or 175°C) and observe if the new bake element heats up properly. You should see it glow red.

5. OPERATING CONSIDERATIONS

After replacing the bake element, the oven should operate as normal. No special operating procedures are required for the new element itself. Continue to use your oven according to its original manufacturer's instructions.

- Allow the oven to preheat fully before placing food inside for optimal cooking results.
- Monitor the oven's temperature during the first few uses after replacement to ensure consistent heating.

6. MAINTENANCE

The bake element itself requires minimal maintenance. However, general oven cleaning practices will help prolong the life of all oven components, including the element.

- **Regular Cleaning:** Clean the oven interior regularly to prevent grease and food residue buildup, which can affect heating efficiency and potentially damage components.
- **Avoid Direct Contact:** Do not allow food or cleaning agents to directly contact the bake element. Wipe up spills promptly once the oven has cooled.
- **Self-Cleaning Cycle:** If your oven has a self-cleaning cycle, follow your oven's manufacturer guidelines. Ensure the element is clear of debris before initiating the cycle.

7. TROUBLESHOOTING

If you encounter issues after replacing the bake element, consider the following common problems and solutions:

Problem	Possible Cause	Solution
Oven not heating at all.	No power to the oven; element not connected properly; faulty new element.	Check circuit breaker. Verify electrical connections to the element. If power is present and connections are good, the new element may be defective (rare).
Oven heats unevenly.	Element not fully seated; other oven components failing.	Ensure the element is securely mounted and not bent. This issue is less likely to be caused by a new bake element unless it's physically damaged.

Problem	Possible Cause	Solution
Element not glowing red.	Element not receiving power.	Confirm power is on and connections are secure. Allow sufficient time for preheating.

If troubleshooting steps do not resolve the issue, it is recommended to contact a certified appliance repair technician.

8. SPECIFICATIONS

- **Product Type:** Bake Element Replacement
- **Brand:** Mintu
- **Part Number:** JT5000SF6SS (Primary listed model, compatible with many others)
- **Compatibility:** Designed for various General Electric wall oven models (e.g., JT5000SF6SS, JT5500BL5TS, JT5500BL6TS, JT5500DF1BB, etc. - refer to product listing for full list).
- **Material:** Durable metal alloy heating coil
- **Date First Available:** September 28, 2021

9. WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support for your Mintu Bake Element, please refer to the original product packaging or contact the seller directly through the platform where the purchase was made. Keep your proof of purchase for warranty claims.

For general inquiries or to explore other products from Mintu, visit the [Mintu Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question