Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Vistefly M303

Vistefly M303 Robot Vacuum Cleaner and Mop User Manual

Model: M303

1. Introduction

Thank you for choosing the Vistefly M303 Robot Vacuum Cleaner and Mop. This manual provides essential information for the safe operation, maintenance, and troubleshooting of your device. Please read it thoroughly before use and keep it for future reference.
The Vistefly M303 is designed to provide efficient and convenient floor cleaning with its 2-in-1 vacuuming and mopping capabilities, smart navigation, and app/voice control features.

2. Important Safety Instructions

To reduce the risk of injury or damage, read these safety instructions carefully and keep them at hand when setting up, using, and maintaining the robot.

- Do not operate the robot in environments with open flames or fragile objects.
- Ensure the robot is used on dry surfaces. Do not use it in wet environments or where there is standing water.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not pick up large debris, sharp objects, or liquids with the robot.
- Only use the original charging dock and power adapter provided by the manufacturer.
- Supervise children and pets when the robot is operating.
- Before use, clear the area of any loose cables, small objects, or anything that could entangle the robot.

3. Package Contents

Verify that all components are present and in good condition:



Image: Overview of the Vistefly M303 Robot Vacuum Cleaner and its accessories, including the main unit, charging dock, remote control, side brushes, cleaning tool, and user manual.

- Vistefly M303 Robot Vacuum Cleaner and Mop
- Charging Dock
- Power Adapter
- Remote Control
- Side Brushes (2 pairs)
- Cleaning Tool
- Dustbin
- Water Tank with Mopping Pad
- Boundary Strips
- User Manual

4. Setup and Installation

4.1 Charging Dock Placement

Place the charging dock against a wall in an open, uncluttered area. Ensure there is at least 1 meter (3 feet) of clear space in front of the dock and 0.5 meters (1.5 feet) on either side.



Image: The Vistefly M303 robot vacuum automatically returning to its charging dock when battery is low or cleaning is complete.

4.2 Initial Charging

Before first use, fully charge the robot. Place the robot on the charging dock, ensuring the charging contacts align. The indicator light on the robot will show charging status. A full charge takes approximately 4-5 hours.

4.3 Installing Side Brushes

Press the left and right side brushes into their respective slots on the bottom of the robot until they click into place.

4.4 Setting Up Boundary Strips

Use the included boundary strips to create virtual walls and restrict the robot from entering certain areas, such as pet feeding zones or areas with delicate items.



Image: The Vistefly M303 robot vacuum detecting and avoiding an area marked by boundary strips, preventing it from entering restricted zones.

5. Operating Instructions

5.1 Powering On/Off

Press and hold the power button on the robot for 3 seconds to turn it on or off.

5.2 Cleaning Modes

The Vistefly M303 offers various cleaning modes:

- **Auto Cleaning:** The robot intelligently navigates and cleans the entire floor area.
- **Spot Cleaning:** The robot cleans a specific area in a spiral pattern.
- **Edge Cleaning:** The robot cleans along walls and furniture edges.

- **Vacuuming & Mopping (2-in-1):** Attach the water tank and mopping pad for simultaneous vacuuming and wet mopping.



Image: Illustration of the Vistefly M303's dual functionality, demonstrating both vacuuming with adjustable suction levels and mopping with adjustable water flow.

5.3 Smart Navigation and Obstacle Avoidance

Equipped with intelligent gyroscope technology, the M303 follows an efficient linear cleaning pattern, ensuring thorough coverage. Its advanced sensors prevent accidental falls from stairs and reduce collisions with furniture.



Image: Comparison showing the Vistefly M303's intelligent linear cleaning path versus a random cleaning pattern, highlighting its efficient navigation.



Image: The Vistefly M303 robot vacuum demonstrating its anti-collision sensors to avoid furniture and anti-fall sensors to prevent falling down stairs.

5.4 Carpet Boost Function

The robot automatically detects carpets and increases suction power to 3000Pa for deeper cleaning. Once it leaves the carpet, it returns to normal suction power.



Image: The Vistefly M303 robot vacuum automatically increasing its suction power when transitioning from hard floor to carpet, indicated by a red line for maximum suction.

5.5 Control Options

Control your Vistefly M303 using the following methods:

- **Remote Control:** Use the included remote for basic functions like starting, stopping, changing modes, and sending the robot back to the charging dock.
- **Mobile App:** Download the Vistefly app (available on iOS and Android) to access advanced features, schedule cleanings, view cleaning maps, adjust suction/water levels, and monitor battery status.
- **Voice Control:** The robot is compatible with Amazon Alexa and Google Assistant. Connect your robot to your smart home system for convenient voice commands.



Image: The Vistefly M303 robot vacuum cleaner displayed with its remote control and a smartphone showing the control app interface, along with a water tank accessory.



Image: The Vistefly M303 robot vacuum cleaner next to a smart speaker, illustrating its compatibility with Amazon Alexa and Google Assistant for voice control.

5.6 Battery and Recharging

The M303 features a 2600mAh lithium battery, providing up to 120 minutes of cleaning time per charge. When the battery is low or cleaning is complete, the robot will automatically return to its charging dock.

6. Maintenance and Care

Regular maintenance ensures optimal performance and extends the lifespan of your Vistefly M303.

6.1 Emptying the Dustbin

Empty the dustbin after each use. Press the release button to remove the dustbin, open it, and discard the collected debris.

6.2 Cleaning Filters

Tap out the HEPA filter every few weeks. The foam filter can be rinsed with water, but ensure it is completely dry before reinserting.

6.3 Cleaning Brushes

Regularly remove hair and debris from the main brush and side brushes using the provided cleaning tool. Replace side brushes if they become worn or damaged.

6.4 Cleaning Sensors and Charging Contacts

Wipe the anti-drop sensors, anti-collision sensors, and charging contacts on both the robot and the charging dock with a clean, dry cloth to ensure proper function.

6.5 Cleaning the Water Tank and Mopping Pad

After mopping, empty any remaining water from the tank and rinse it. Remove and clean the mopping pad. Allow both to air dry completely before storage.

7. Troubleshooting

If you encounter issues with your Vistefly M303, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Robot does not power on.	Low battery; Power button not pressed correctly.	Charge the robot fully; Press and hold the power button for 3 seconds.
Robot cannot find charging dock.	Charging dock obstructed; Robot too far from dock.	Ensure clear space around dock; Manually place robot near dock.
Suction power is weak.	Dustbin full; Filter clogged; Brushes tangled.	Empty dustbin; Clean/replace filter; Clean brushes.
Robot gets stuck frequently.	Too many obstacles; Sensors dirty.	Clear the cleaning area; Clean all sensors.
Mopping function not working.	Water tank empty; Mopping pad not attached correctly.	Fill water tank; Ensure mopping pad is securely attached.

8. Specifications

Feature	Detail
Model	M303
Brand	Vistefly
Suction Power	Up to 3000Pa
Battery Capacity	2600mAh Lithium-ion

Feature	Detail
Run Time	Up to 120 minutes
Charging Time	Approx. 4-5 hours
Dimensions (L x W x H)	32 x 32 x 7.5 cm (12.6 x 12.6 x 3 inches)
Weight	5 kg (11 lbs)
Control Methods	Remote Control, Mobile App, Voice Control (Alexa, Google Assistant)
Special Features	2-in-1 Vacuum & Mop, Automatic Carpet Boost, Anti-Collision, Anti-Fall, Boundary Strip Support

9. Warranty and Support

Vistefly provides a standard warranty for this product. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, troubleshooting assistance, or spare parts, please contact Vistefly customer service through the contact information provided on our official website or the product packaging.
For the most up-to-date support information, visit the official Vistefly website.

© 2024 Vistefly. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09HBJ3LTM

More documents and user manuals: **https://manuals.plus/**