realme RMA2007

realme Bluetooth Pocket Speaker RMA2007 User Manual

1. Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your realme Bluetooth Pocket Speaker, model RMA2007. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

2. Package Contents

- realme Bluetooth Pocket Speaker
- Type-C Charging Cable
- User Guide

3. Product Features

- 3W Dynamic Bass Boost Speaker for enhanced audio.
- Dedicated Bass Radiator for deeper bass.
- Up to 6 hours of battery life on a single charge.
- Gaming Mode for low-latency audio.
- Stereo Pairing capability for connecting two speakers.
- IPX5 water resistance, protecting against splashes and light rain.
- Compact and lightweight design (113g) for portability.
- USB Type-C charging port.
- Bluetooth wireless connectivity with a maximum range of 10 meters.

4. Controls and Indicators

The realme Bluetooth Pocket Speaker features intuitive controls and indicators for easy use. Refer to the images below for a visual guide to the speaker's components.



Angled view of the realme Bluetooth Pocket Speaker, highlighting the control buttons on the side.



Side view of the speaker, clearly showing the power button, function button, and LED indicator.



Bottom view of the speaker, displaying the rubber feet for stability and product certification information.

Button Functions:

- **Power Button:** Press and hold for 2 seconds to power on/off. Press and hold for 10 seconds to reset to factory settings.
- **Function Button (M):**
  - Press once: Play/Pause, Answer a call, End a call.
  - Press and hold for 1 second: Decline an incoming call.
  - Press and hold for 3 seconds: Enter pairing mode.
  - Double-press: Next track.
  - Triple-press: Last track.
  - Double-press (while powered on): Activate Gaming Mode.
- **LED Indicator:** Provides status updates (e.g., pairing, charging, power on/off).

5. Setup and Pairing

Initial Setup:

1. **Charge the Speaker:** Before first use, fully charge the speaker using the provided Type-C charging cable. Connect the cable to the speaker's charging port and a compatible USB power source. The LED indicator will show charging status.
2. **Power On:** Press and hold the Power button for 2 seconds until the LED indicator lights up, indicating the speaker is powered on.

Bluetooth Pairing:

1. Ensure the speaker is powered on and in pairing mode (LED will blink). If not, press and hold the Function button for 3 seconds to enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for available Bluetooth devices and select "realme Pocket Speaker" from the list.
4. Once connected, the LED indicator will show a steady light, and you will hear an audible confirmation.

Stereo Pairing (TWS - True Wireless Stereo):

To achieve a stereo sound experience, you can pair two realme Bluetooth Pocket Speakers together.

1. Ensure both speakers are powered off.
2. Press and hold the Power button and the Function button simultaneously on both speakers for 2 seconds to enter stereo pairing mode.
3. The speakers will automatically connect to each other. The green LED indicates the left channel, and the red LED indicates the right channel.
4. Once paired, connect your device to one of the speakers via Bluetooth as described above.
5. To quit stereo pairing mode, press and hold the Power button and the Function button simultaneously for 2 seconds on either speaker.

6. Operation

Music Playback:

- Press the Function button once to play or pause music.
- Double-press the Function button for the next track.
- Triple-press the Function button for the last track.

Call Handling:

- Press the Function button once to answer an incoming call.
- Press the Function button once to end an active call.
- Press and hold the Function button for 1 second to decline an incoming call.

Gaming Mode:

Double-press the Function button while the speaker is powered on to activate Gaming Mode, which reduces audio latency for a better gaming experience.

7. Charging

The realme Bluetooth Pocket Speaker is equipped with a 600mAh battery, providing approximately 6 hours of playback time. To charge the speaker:

1. Locate the USB Type-C charging port on the side of the speaker, protected by a rubber latch.
2. Open the rubber latch and insert the provided Type-C charging cable.
3. Connect the other end of the cable to a standard USB power adapter (5V/1A recommended) or a computer's USB port.
4. The LED indicator will show the charging status. Once fully charged, the LED will change color or turn off depending on the specific model's indicator behavior.



Front view of the realme Bluetooth Pocket Speaker, showcasing its compact design and branding.

8. Maintenance and Care

- **Cleaning:** Use a soft, dry cloth to clean the speaker. Avoid using harsh chemicals or abrasive materials.
- **Water Resistance:** The speaker is IPX5 water-resistant, meaning it can withstand splashes and light rain. Do not

submerge the speaker in water. Ensure the charging port cover is securely closed to maintain water resistance.

- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery:** To preserve battery life, charge the speaker regularly, even if not in frequent use. Avoid fully discharging the battery for extended periods.

9. Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
Cannot pair via Bluetooth.	Speaker not in pairing mode; device Bluetooth off; too far from device.	Ensure speaker is in pairing mode (blinking LED). Turn on device Bluetooth. Move speaker closer to device (within 10m). Reset speaker to factory settings if necessary.
No sound or low volume.	Volume too low on speaker or device; incorrect audio source.	Increase volume on both speaker and connected device. Check if the correct audio output is selected on your device.
Stereo pairing fails.	Incorrect pairing procedure.	Ensure both speakers are powered off before initiating stereo pairing. Follow the stereo pairing steps precisely.

10. Specifications

- **Model:** RMA2007
- **Output Power:** 3W RMS
- **Connectivity:** Bluetooth
- **Wireless Range:** Up to 10 meters
- **Battery:** 600mAh
- **Playback Time:** Approximately 6 hours
- **Charging Port:** USB Type-C
- **Water Resistance:** IPX5
- **Material:** Plastic
- **Dimensions:** 3.3D x 6.1W x 10.1H Centimeters
- **Weight:** 113 Grams
- **Control Method:** Touch buttons
- **Included Components:** Speaker, Type C Charging Cable, User Guide



Image illustrating the dimensions of the realme Bluetooth Pocket Speaker.

11. Product Overview Video

Watch this official product video for a visual overview of the realme Bluetooth Pocket Speaker, including its design and key features.

Your browser does not support the video tag.

This video provides a detailed look at the realme Pocket Bluetooth Speaker, showcasing its physical attributes and functionalities.

A short preview video highlighting the realme Bluetooth Pocket Speaker's portability and design.

Your browser does not support the video tag.

This short video offers a quick glimpse of the realme Pocket Bluetooth Speaker in use, emphasizing its compact size.

12. Warranty and Support

The realme Bluetooth Pocket Speaker (Model RMA2007) comes with a 1-year domestic warranty. For warranty claims or technical support, please refer to the contact information provided in the included User Guide or visit the official realme support website.

Manufacturer: GANZHOU DEHUIDA TECH CO. LTD, Ganzhou Dehuida Technology Co., Ltd, Anyuan District, Ganzhou, Jiangxi, China

Importer: Oppo Mobiles India Private Limited 5th Floor, Tower-B, Building No. 8, DLF Cyber City, Gurugram, Haryana-122002, India

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question