

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [BOROFONE](#) /

› [BOROFONE BR16 Portable Bluetooth Speaker User Manual](#)

## BOROFONE BR16

# BOROFONE BR16 Portable Bluetooth Speaker User Manual

Model: BR16

## INTRODUCTION

---

Thank you for choosing the BOROFONE BR16 Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your device. Please read it carefully before use to ensure optimal performance and longevity.

## PRODUCT OVERVIEW

---

### Package Contents

- BOROFONE BR16 Portable Bluetooth Speaker
- USB Charging Cable
- User Manual

### Speaker Components and Controls



**Image 1:** Rear view of the BOROFONE BR16 speaker, showing the power switch, USB-A port, Micro-USB charging port, TF card slot, and control buttons. The speaker's model and specifications are visible on the back label.



**Image 2:** Front view of the BOROFONE BR16 speaker, featuring a protective grille and the BOROFONE logo.



**Image 3:** Detailed view of the speaker's back label, displaying model number BR16, Wireless version V5.1, Input DC 5V/1A, Power 5W x 1, and Battery Rated Capacity 1200mAh, along with CE, FCC, RoHS, and CCC certifications.

- **Power Switch:** Located on the side/rear, used to turn the speaker ON/OFF.
- **Control Buttons:** (Red buttons on top) For playback control (play/pause, volume up/down, track skip) and mode selection.
- **USB-A Port:** For U disk (USB flash drive) playback.
- **Micro-USB Port:** For charging the speaker.
- **TF Card Slot:** For playing music from a MicroSD/TF card.

## SETUP

### Charging the Speaker

1. Connect the Micro-USB end of the provided charging cable to the speaker's Micro-USB port.
2. Connect the USB-A end of the cable to a USB power adapter (not included) or a computer's USB port.

3. The charging indicator light will illuminate. Charging typically takes approximately 3 hours.
4. Once fully charged, the indicator light may change or turn off. Disconnect the charging cable.



**Image 4:** The USB charging cable included with the speaker, featuring a standard USB-A connector and a Micro-USB connector.

## Powering On/Off

- To power on, slide the ON/OFF switch to the "ON" position. You will hear an audible prompt.
- To power off, slide the ON/OFF switch to the "OFF" position.

## OPERATING INSTRUCTIONS

---

### Bluetooth Mode

1. Ensure the speaker is powered on. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED light and an audible prompt.
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "BOROFONE BR16" from the list of devices.
4. Once paired, the LED indicator will stop flashing, and you will hear a confirmation sound.
5. You can now play audio from your device through the speaker.

*Note:* The speaker supports Bluetooth 5.1 for stable and efficient wireless connection.

## FM Radio Mode

1. Power on the speaker.
2. Press the Mode button (one of the red control buttons) to switch to FM radio mode.
3. Press and hold the Play/Pause button to automatically scan and save available FM stations.
4. Use the Volume Up/Down buttons (or track skip buttons) to navigate between saved stations.

## TF Card / U Disk Playback

1. Insert a TF (MicroSD) card into the TF card slot or a USB flash drive into the USB-A port.
2. The speaker will automatically detect the storage device and begin playing audio files.
3. Use the control buttons for playback (play/pause, next/previous track, volume).

## TWS (True Wireless Stereo) Function (If Supported)

If you have two BOROFONE BR16 speakers, you can pair them together for a True Wireless Stereo experience.

1. Ensure both BR16 speakers are powered on and not connected to any Bluetooth device.
2. On one speaker, press and hold the TWS pairing button (refer to specific button function if available, otherwise try Play/Pause or Mode button).
3. The speakers will attempt to pair with each other. Once successful, you will hear a confirmation sound.
4. Connect your device to one of the paired speakers via Bluetooth. Audio will now play in stereo through both speakers.

*Note:* The TWS function allows two speakers to act as left and right channels for a more immersive sound.

## MAINTENANCE

- Keep the speaker dry. Do not expose it to extreme temperatures or humidity.
- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid dropping or subjecting the speaker to strong impacts.
- When not in use for extended periods, charge the speaker at least once every three months to maintain battery health.

## TROUBLESHOOTING

Problem	Solution
Speaker does not turn on.	Ensure the battery is charged. Connect the speaker to a power source using the USB charging cable.
Cannot pair via Bluetooth.	<ul style="list-style-type: none"><li>◦ Ensure the speaker is in Bluetooth pairing mode (flashing LED).</li><li>◦ Make sure Bluetooth is enabled on your device.</li><li>◦ Move the speaker closer to your device.</li><li>◦ Forget "BOROFONE BR16" from your device's Bluetooth list and try pairing again.</li><li>◦ Restart both the speaker and your device.</li></ul>

Problem	Solution
No sound or low volume.	<ul style="list-style-type: none"> <li>◦ Increase the volume on both the speaker and your connected device.</li> <li>◦ Ensure the speaker is properly connected via Bluetooth or playing from a valid source (TF card/U disk).</li> <li>◦ Check if the audio source is paused or muted.</li> </ul>
FM radio reception is poor.	<ul style="list-style-type: none"> <li>◦ Move the speaker to an open area, away from obstructions or interference.</li> <li>◦ Rescan for stations by pressing and holding the Play/Pause button in FM mode.</li> </ul>

## SPECIFICATIONS

<b>Model</b>	BR16
<b>Brand</b>	BOROFONE
<b>Bluetooth Version</b>	5.1
<b>Chip</b>	JL AC6965E
<b>Battery Capacity</b>	1200mAh
<b>Charging Time</b>	Approximately 3 hours
<b>Music/Talk Time</b>	Approximately 4 hours
<b>Speaker Unit</b>	52mm x 1
<b>Output Power</b>	5W
<b>Dimensions</b>	100 x 84 x 47 mm (approx. 3.9 x 3.3 x 1.85 inches)
<b>Weight</b>	245g (approx. 0.54 lbs)
<b>Material</b>	Plastic
<b>Connectivity</b>	Bluetooth, FM Radio, TF Card, U Disk, TWS
<b>Compatible Devices</b>	Smartphones, Tablets, Laptops
<b>Control Method</b>	Physical Buttons
<b>Water Resistance</b>	Yes (Specific IP rating not provided, assume splash-proof)



**Image 5:** The BOROFONE BR16 speaker held in a hand, illustrating its compact and portable design with approximate dimensions of 3.6

inches (9 cm).

## WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the documentation provided with your purchase or contact your retailer.



**Image 6:** The official BOROFONE company logo.

