



[Manuals.plus](#) /

› [YAOHUIMI](#) /

› YAOHUIMI Replacement Remote Control User Manual for Kelvinator AC Air Conditioners (Models EPK09CRN2A, EPF12CRN2A, KWH26HRB)

YAOHUIMI A420210928-(R51)-13

YAOHUIMI Replacement Remote Control User Manual

For Kelvinator AC Air Conditioner Models: EPK09CRN2A, EPF12CRN2A, KWH26HRB

1. INTRODUCTION AND OVERVIEW

This manual provides instructions for the YAOHUIMI replacement remote control, designed for specific Kelvinator AC Air Conditioner models including EPK09CRN2A, EPF12CRN2A, and KWH26HRB. This remote offers an updated design and functionality, ensuring compatibility with your existing Kelvinator AC unit. Key features include a display that shows temperature in both Fahrenheit and Celsius, and a green backlight for improved visibility in low-light conditions.

Important Note: This is not a universal remote control. Please verify your air conditioner model or your original remote control model before use to ensure compatibility.



UPGRADE!

Display in Fahrenheit



Display in Celsius



°C ⇌ °F



GREEN BACKLIGHT



Image 1.1: Overview of the replacement remote control, emphasizing its upgraded features like Fahrenheit/Celsius display and green backlight.

2. SETUP

2.1 Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open.
3. Insert two new AAA batteries (not included), ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.

4. Replace the battery compartment cover, sliding it back into place until it clicks securely.

Once batteries are installed, the remote control is ready for use with your compatible Kelvinator AC unit. No complex pairing is typically required for this replacement model.

3. OPERATING INSTRUCTIONS

Familiarize yourself with the buttons and their functions as shown in the diagram below.



Image 3.1: Front view of the remote control, displaying all operational buttons and the digital screen.

Remote Control Button Functions

Button	Function
ON/OFF	Powers the air conditioner on or off.

Button	Function
MODE	Cycles through operating modes: AUTO, COOL, DRY, HEAT.
TEMP ▲ / ▼	Adjusts the set temperature up or down.
FAN SPEED	Cycles through fan speeds: HIGH, MED, LOW.
SWING	Activates or deactivates the automatic louver swing function.
SLEEP	Activates the sleep mode for comfortable nighttime operation.
TIMER ON	Sets a timer for the air conditioner to turn on automatically.
TIMER OFF	Sets a timer for the air conditioner to turn off automatically.
RESET	Resets certain settings or functions.
LOCK	Locks the remote control buttons to prevent accidental changes.
LED DISPLAY	Turns the AC unit's display LED on or off.
TURBO	Activates rapid cooling or heating for quick temperature changes.
AIR DIRECTION	Manually adjusts the air flow direction.

3.1 Temperature Display (Fahrenheit/Celsius)

This remote control supports displaying temperature in both Fahrenheit (°F) and Celsius (°C). The specific method to switch between these units may vary slightly depending on the AC unit, but typically involves pressing a combination of buttons (e.g., TEMP up and down simultaneously) or a dedicated button if present. Refer to your AC unit's manual for exact instructions if a dedicated button is not visible on the remote.

Display in both Fahrenheit and Celsius





Image 3.2: Close-up of the remote's display indicating temperature readings in both Fahrenheit and Celsius.

3.2 Green Backlight

The remote features a green backlight for easy operation in dimly lit environments. The backlight typically activates automatically when any button is pressed and remains on for a few seconds before fading out.




Image 3.3: The remote control's display illuminated with its green backlight, enhancing visibility.

4. MAINTENANCE

4.1 Battery Replacement

Replace batteries when the remote's display becomes dim or unresponsive. Always use new AAA batteries and dispose of old batteries responsibly according to local regulations.

4.2 Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's surface or internal components.

5. TROUBLESHOOTING

- **Remote not responding:**
 - Check if the batteries are inserted correctly with the correct polarity.
 - Replace old batteries with new ones.
 - Ensure there are no obstructions between the remote control and the AC unit's receiver.
 - Confirm the remote is compatible with your specific Kelvinator AC model (EPK09CRN2A, EPF12CRN2A, KWH26HRB).
- **Display is dim or blank:**
 - Replace the batteries.
- **Temperature unit not changing:**
 - Refer to your AC unit's original manual for specific instructions on how to toggle between Fahrenheit and Celsius, as this function is often controlled by the AC unit itself or a specific button combination on the remote.

6. SPECIFICATIONS

Feature	Detail
Brand	YAOHUIMI
Model Number	A420210928-(R51)-13
Compatibility	Kelvinator AC Air Conditioner models: EPK09CRN2A, EPF12CRN2A, KWH26HRB
Power Source	2 x AAA Batteries (not included)
Display Features	Fahrenheit (°F) and Celsius (°C) display, Green Backlight

7. WARRANTY INFORMATION

Specific warranty details for this replacement remote control may vary. Please refer to the seller's return policy or contact the manufacturer, YAOHUIMI, for detailed warranty information. Typically, replacement parts come with a limited warranty against manufacturing defects.

8. SUPPORT

For further assistance, technical support, or inquiries regarding this product, please contact the seller directly through the platform where the purchase was made. You may also visit the manufacturer's official website for additional resources.

Manufacturer: HUIMIKEJI

Brand: YAOHUI MI

© 2023 YAOHUI MI. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.