



Manuals.plus /

› YAOHUIMI /

› YAOHUIMI Replacement Remote Control User Manual for Hokkaido VIVAX Artica ELUXE Clima RG57A6/BGEF Air Conditioner (Model A420210928-(R51)-303)

## YAOHUIMI A420210928-(R51)-303

# YAOHUIMI Replacement Remote Control User Manual

For Hokkaido VIVAX Artica ELUXE Clima RG57A6/BGEF Air Conditioner (Model A420210928-(R51)-303)

## 1. INTRODUCTION

This manual provides detailed instructions for the YAOHUIMI Replacement Remote Control, model A420210928-(R51)-303. This remote is specifically designed to operate Hokkaido VIVAX Artica ELUXE Clima RG57A6/BGEF Air Conditioners. It features a clear display with green backlight and supports both Fahrenheit and Celsius temperature readings. Please read this manual thoroughly before use to ensure proper operation and to maximize the lifespan of your device.

## 2. COMPATIBILITY NOTICE

This remote control is not a universal remote. It is designed to be a direct replacement for the original remote control of specific Hokkaido VIVAX Artica ELUXE Clima RG57A6/BGEF Air Conditioner models. Before ordering or using, please verify that your air conditioner model or your original remote control model matches RG57A6/BGEF. Compatibility is crucial for correct functionality.

## 3. KEY FEATURES

- **Direct Replacement:** Functions as a direct replacement for Hokkaido VIVAX Artica ELUXE Clima RG57A6/BGEF Air Conditioner remotes.
- **Dual Temperature Display:** Displays temperature in both Fahrenheit (°F) and Celsius (°C).
- **Green Backlight:** Equipped with a green backlight for improved visibility and convenient operation in low-light conditions or at night.
- **Ergonomic Design:** Features a comfortable button layout for ease of use.



# UPGRADE!

Display in Fahrenheit



Display in Celsius



°C ⇌ °F



**GREEN BACKLIGHT**



Image: The remote control's display capabilities, including Fahrenheit and Celsius temperature units and the green backlight feature.

## 4. SETUP AND BATTERY INSTALLATION

To begin using your replacement remote control, you will need to install batteries. This remote typically requires two AAA batteries (not included).

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.

After battery installation, the remote is ready for use. No programming is typically required for this replacement remote.



Image: The overall layout of the remote control, illustrating the various buttons and the digital screen.

## 5. OPERATING INSTRUCTIONS

The remote control provides various functions to manage your air conditioner. Below is a guide to the main buttons and their operations:

## Display in both Fahrenheit and Celsius





Image: A close-up of the remote control, clearly showing the labels for each button.


- **ON/OFF Button:** Press to turn the air conditioner on or off.
- **MODE Button:** Cycles through operating modes such as AUTO, COOL, DRY, HEAT, and FAN.
- **TEMP ▲ / ▼ Buttons:** Adjusts the desired temperature setting upwards or downwards.
- **FAN SPEED Button:** Changes the fan speed (e.g., AUTO, LOW, MED, HIGH).
- **SWING Button:** Activates or deactivates the automatic swing function of the air conditioner's louvers.
- **SLEEP Button:** Engages the sleep mode, which adjusts temperature and fan speed for comfortable sleep.
- **TIMER ON / TIMER OFF Buttons:** Sets a timer for the air conditioner to turn on or off automatically.
- **RESET Button:** Used to reset certain settings or functions.
- **LOCK Button:** Locks the remote control to prevent accidental changes.
- **LED DISPLAY Button:** Controls the LED display on the air conditioner unit.
- **TURBO Button:** Activates a rapid cooling or heating function for quick temperature changes.
- **AIR DIRECTION Button:** Adjusts the direction of the airflow.

Point the remote control directly at the air conditioner's receiver when operating. Ensure there are no obstructions between the remote and the unit.

## 6. DISPLAY INFORMATION

The remote control features a clear digital display that provides essential information about your air conditioner's settings.

- **Temperature Display:** The remote can show the set temperature in either Fahrenheit (°F) or Celsius (°C). The unit can be switched between these two scales.
- **Green Backlight:** The display is illuminated with a green backlight, making it easy to read the settings in dark environments. This feature enhances usability during nighttime operation.



**GREEN BACKLIGHT**

Image: A detailed view of the remote's display, highlighting the green backlight feature and temperature reading.



Image: An illustration demonstrating how the temperature is displayed in both Fahrenheit and Celsius on the remote's screen.

## 7. TROUBLESHOOTING

---

If you encounter issues with your remote control, please refer to the following common troubleshooting steps:

- **Remote Not Responding:**

- Check if the batteries are correctly inserted with the correct polarity (+/-).
- Replace old batteries with new ones. Weak batteries are a common cause of remote control malfunction.
- Ensure there is a clear line of sight between the remote control and the air conditioner's receiver. Remove any obstructions.

- **Air Conditioner Not Responding:**

- Confirm that the air conditioner unit is powered on and receiving electricity.
- Verify that the remote control model is indeed compatible with your specific air conditioner model (RG57A6/BGEF).

- **Display Issues:**

- If the display is dim or flickering, replace the batteries.
- If the backlight is not working, ensure batteries are fresh.

## 8. SPECIFICATIONS

---

<b>Brand</b>	YAOHUIMI
<b>Model Number</b>	A420210928-(R51)-303
<b>Compatible AC Models</b>	Hokkaido VIVAX Artica ELUXE Clima RG57A6/BGEF
<b>Controller Type</b>	Button Control
<b>Special Features</b>	Fahrenheit/Celsius Display, Green Backlight
<b>Power Source</b>	2 x AAA Batteries (not included)

## 9. WARRANTY AND SUPPORT

---

For information regarding warranty coverage, returns, or technical support, please refer to the seller or the platform where the product was purchased. Specific warranty terms and support channels are typically provided by the retailer or manufacturer at the time of purchase.