

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [YAOHUIMI](#) /

> [YAOHUIMI Replacement Remote Control User Manual for Milexus RG51M5/EU & MRCOOL RG51M5/EU AC Air Conditioner](#)

**YAOHUIMI A420210928-(R51)-415**

# YAOHUIMI Replacement Remote Control User Manual

For Milexus RG51M5/EU & MRCOOL RG51M5/EU AC Air Conditioners

## INTRODUCTION

---

This manual provides detailed instructions for the YAOHUIMI replacement remote control, designed for use with Milexus RG51M5/EU and MRCOOL RG51M5/EU air conditioning units. This remote offers an updated design with features such as a green backlight and display in both Fahrenheit and Celsius. Please ensure your AC unit model matches the compatible models listed before use.



# UPGRADE!

Display in Fahrenheit



Display in Celsius



°C ⇌ °F



**GREEN BACKLIGHT**



Image: The replacement remote control, showcasing its green backlight and dual temperature display capabilities (Fahrenheit and Celsius).

## SETUP

### 1. Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open.
3. Insert two new AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.

**Note:** This remote control is a direct replacement and typically does not require pairing. It should function immediately after battery installation with compatible AC units.

## OPERATING INSTRUCTIONS

Familiarize yourself with the buttons and their functions for optimal use of your air conditioner.





Image: A clear view of the remote control's front panel, detailing the layout of all operational buttons and the digital display.

- **ON/OFF Button:** Press to turn the air conditioner unit on or off.
- **MODE Button:** Cycles through available operating modes: AUTO, COOL, DRY, HEAT.
- **TEMP ▲ / ▼ Buttons:** Adjusts the desired temperature setting. The display shows temperature in both Fahrenheit and Celsius.
- **FAN SPEED Button:** Selects fan speed: AUTO, HIGH, MED (Medium), LOW.
- **SWING Button:** Activates or deactivates the automatic louver swing function for air direction.
- **SLEEP Button:** Engages the sleep mode, which adjusts temperature for comfortable sleep and energy saving.
- **TIMER ON / TIMER OFF Buttons:** Sets the timer for the unit to turn on or off automatically. Refer to your AC unit's manual for specific timer programming.
- **RESET Button:** Resets the remote control settings.
- **LOCK Button:** Locks the remote control to prevent accidental changes.
- **LED DISPLAY Button:** Toggles the LED display on the AC unit (if applicable).
- **TURBO Button:** Activates maximum cooling or heating for rapid temperature change.
- **AIR DIRECTION Button:** Manually adjusts the air flow direction.

### Temperature Display (Fahrenheit/Celsius)

The remote control features a display that can show temperature in both Fahrenheit (°F) and Celsius (°C).

## Display in both Fahrenheit and Celsius





Image: The remote's digital screen displaying temperature readings in both Fahrenheit and Celsius, indicating its dual-unit capability.

### Green Backlight

The remote control is equipped with a green backlight for easy operation in low-light conditions. The backlight activates automatically when buttons are pressed.




Image: A detailed view of the remote control's display, clearly showing the green backlight feature in action.

## MAINTENANCE

### Battery Replacement

Replace batteries when the remote control's display becomes dim or unresponsive. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

Remove batteries if the remote control will not be used for an extended period to prevent leakage and damage.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote not responding	Dead or incorrectly inserted batteries. Obstruction between remote and AC unit. Remote out of range.	Replace batteries, ensuring correct polarity. Remove any obstructions. Move closer to the AC unit.

Problem	Possible Cause	Solution
Display is dim or blank	Low battery power.	Replace batteries.
AC unit not responding to commands	Remote control not compatible with AC unit. AC unit's infrared receiver is blocked or faulty.	Verify AC unit model compatibility (Milexus RG51M5/EU or MRCOOL RG51M5/EU). Ensure AC unit's receiver is clear. Consult AC unit's manual for troubleshooting its receiver.

## SPECIFICATIONS

---

**Model Number:** A420210928-(R51)-415

**Compatible AC Units:** Milexus RG51M5/EU, MRCOOL RG51M5/EU

**Power Source:** 2 x AAA Batteries (not included)

**Connectivity Technology:** Infrared

**Special Features:** Green Backlight, Fahrenheit/Celsius Display

**Brand:** YAOHUIMI

**Manufacturer:** HUIMIKEJI

## WARRANTY AND SUPPORT

---

Information regarding warranty and customer support for this specific replacement remote control is not provided in the product details. Please refer to the seller or manufacturer (YAOHUIMI / HUIMIKEJI) for any warranty claims or technical assistance.