

[Manuals.plus](#) /

› [Makethrone](#) /

› Makethrone X-Bows Lite Ergonomic Mechanical Gaming Keyboard User Manual

Makethrone X-Bows Lite

Makethrone X-Bows Lite Ergonomic Mechanical Gaming Keyboard User Manual

MODEL: B09HGG4M21

1. Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your Makethrone X-Bows Lite Ergonomic Mechanical Gaming Keyboard. Please read thoroughly to ensure optimal performance and longevity of your device.

2. Package Contents

Verify that all items are present in your package:

- Makethrone X-Bows Lite Ergonomic Mechanical Gaming Keyboard
- USB-C Cable
- Keycap Puller
- User Manual (this document)



Image: The Maketheone X-Bows Lite keyboard, its USB-C cable, and a keycap puller. The image also displays the keyboard's dimensions (34.5cm x 13.8cm) and labels for various function keys, including multimedia controls, backlight speed, and brightness adjustments.

3. Product Overview

The Maketheone X-Bows Lite is an 80% ergonomic mechanical gaming keyboard designed for comfort and performance. It features a unique butterfly layout, Gateron Black mechanical switches, and white backlighting.

Key Features:

- **Ergonomic Butterfly Layout:** Designed to reduce wrist strain and promote a natural typing posture.
- **Premium Build Quality:** Constructed with an aluminum alloy base and durable plastic keycaps.
- **USB-C Wired Connectivity:** Ensures a stable and responsive connection.
- **Tactile Gateron Black Switches:** Provide a smooth and responsive typing experience with a 50 million keystroke lifespan.
- **White Backlighting:** Features 16 movement effects for customizable illumination.



Image: The Maketheone X-Bows Lite keyboard, black in color, positioned on a white desk. A laptop and a computer monitor are visible in the background, indicating a typical desktop setup.

4. Setup

The Maketheone X-Bows Lite keyboard is designed for plug-and-play functionality, requiring no additional drivers for basic operation.

1. Locate the USB-C port on the back of your keyboard.
2. Connect one end of the provided USB-C cable to the keyboard's USB-C port.
3. Connect the other end of the USB-C cable to an available USB port on your computer.
4. Your operating system will automatically detect and install the necessary drivers. The keyboard is ready for use once detected.

5. Operating Instructions

5.1 Basic Key Functions

The keyboard features a standard 86-key layout with an ergonomic split design. All keys function as labeled for typing and command input.

5.2 Backlighting Control

The keyboard includes white backlighting with 16 movement effects. Use the following keys to adjust the backlighting:

- **Brightness +:** Increases backlight brightness.
- **Brightness -:** Decreases backlight brightness.
- **Backlight Speed +:** Increases the speed of backlight effects.
- **Backlight Speed -:** Decreases the speed of backlight effects.

Specific key combinations for changing backlight effects may be indicated on the keycaps or require referring to the keyboard's quick guide.

5.3 Multimedia Keys

Access multimedia and system functions using the **Fn** key in combination with the designated F-keys. Refer to the keycap legends for specific functions:

- **Fn + F1:** Media
- **Fn + F2:** Volume Down
- **Fn + F3:** Volume Up
- **Fn + F4:** Mute
- **Fn + F5:** Stop
- **Fn + F6:** Play Last Song
- **Fn + F7:** Play Next Song
- **Fn + F8:** Play/Pause
- **Fn + F9:** Launch Mail
- **Fn + F10:** Launch Homepage
- **Fn + F11:** Launch Search
- **Fn + F12:** Launch Calculator
- **Fn + Home:** Home
- **Fn + End:** End


6. Ergonomic Guidelines

The X-Bows Lite keyboard is designed with an ergonomic butterfly layout to promote a more natural hand and wrist position, reducing strain during extended use.


- **Natural Hand Alignment:** Position your hands so that your fingers naturally align with the split key layout. This helps minimize ulnar deviation (bending of the wrist sideways).
- **Optimal Typing Angle:** The keyboard features a built-in 6-degree tilt. Utilize this angle to maintain a neutral wrist posture, avoiding excessive wrist extension.
- **Relaxed Shoulders and Arms:** Ensure your shoulders are relaxed and your elbows are close to your body. Your forearms should be roughly parallel to the floor.



Other



Other



X-Bows



Naturally Align to the
Extension of Fingers



Reducing the Stress on Hands and Wrists

Image: A diagram illustrating the difference in hand and wrist alignment between standard keyboards and the X-Bows ergonomic design. The X-Bows layout shows a more natural, straight alignment of the wrists and forearms, reducing stress.




Image: A side profile of the X-Bows Lite keyboard, highlighting its 6-degree ergonomic tilt. Labels point to the 'Aluminum alloy base' and 'Premium plastics keycaps', demonstrating the keyboard's construction.

7. Maintenance

Proper maintenance ensures the longevity and optimal performance of your keyboard.

- **Cleaning:** Regularly dust the keyboard with a soft brush or use compressed air to remove debris from between keycaps. For deeper cleaning, gently wipe the keycaps with a slightly damp, lint-free cloth. Avoid using harsh chemicals or abrasive materials.
- **USB-C Port Care:** Ensure the USB-C port on the keyboard and cable remains free of dust and debris. Avoid applying excessive force when plugging or unplugging the cable to prevent damage to the port.
- **Storage:** When not in use for extended periods, store the keyboard in a clean, dry environment away from direct sunlight and extreme temperatures.

8. Troubleshooting

If you encounter issues with your keyboard, refer to the following troubleshooting steps:

- **Keyboard Not Responding:**
 - Ensure the USB-C cable is securely connected to both the keyboard and your computer.
 - Try connecting the keyboard to a different USB port on your computer.
 - Test the keyboard on another computer to determine if the issue is with the keyboard or your system.
 - Restart your computer.
- **Backlighting Not Working or Dim:**
 - Press the 'Brightness +' key repeatedly to increase the backlight intensity.
 - Verify that the keyboard is properly connected and receiving power.
- **Intermittent Connection or Disconnections:**
 - Check the USB-C cable for any visible damage. A faulty cable can cause intermittent connections. Try using a different, known-good USB-C cable.
 - Ensure the USB-C port on the keyboard is clean and free of debris.
 - Avoid bending or stressing the USB-C cable at the connection points.

9. Specifications

Feature	Detail
Brand	Maketheone
Model	X-Bows Lite
ASIN	B09HGG4M21
UPC	008574012214
Compatible Devices	PC
Connectivity Technology	USB-C (Wired)
Keyboard Description	Gaming
Special Features	Backlit, Ergonomic
Color	Black
Backlighting Color Support	Single Color (White)
Style	Retro
Material	Plastic (Keycaps), Aluminum Alloy (Base)
Number of Keys	86
Switch Type	Tactile (Gateron Black Switches)
Hand Orientation	Ambidextrous
Manufacturer	MakeTheOne

10. Warranty and Support

For detailed warranty information, technical support, or service inquiries, please visit the official Maketheone website or contact their customer support directly. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2023 Maketheone. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question