

## REDMOND MMF-9103

# REDMOND MMF-9103 Electric Milk Frother User Manual

Model: MMF-9103

## INTRODUCTION

---

Thank you for choosing the REDMOND MMF-9103 Electric Milk Frother. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

## IMPORTANT SAFETY INSTRUCTIONS

---

- Read all instructions before using the appliance.
- Do not immerse the main unit (base with power cord) in water or other liquids. Only the stainless steel jug is detachable and washable.
- Ensure the voltage of your power outlet matches the rating on the appliance.
- Do not operate the appliance with a damaged cord or plug.
- Keep hands and utensils out of the jug during operation to prevent injury or damage.
- Always use the frother on a flat, stable, heat-resistant surface.
- Do not overfill the jug beyond the MAX indicator to prevent overflow.
- This appliance is for household use only.

## PRODUCT COMPONENTS

---

- Main Unit (Base with control panel and power cord)
- Stainless Steel Jug with Handle
- Transparent Lid
- Frothing Whisk (removable)

# Be Your Personal Barista

Latte, cappuccino, hot chocolate. You name it, we've got it.



Heat & Froth



Heat & Blend



Room temp froth



Hot chocolate



Image: Overview of the REDMOND MMF-9103 Milk Frother showing the main unit, detachable jug, and whisk.

## SETUP

1. **Unpack:** Carefully remove all packaging materials and components from the box.
2. **Clean:** Before first use, wash the stainless steel jug, lid, and frothing whisk with warm soapy water. Rinse thoroughly and dry completely. Do not immerse the main unit in water.
3. **Assemble:** Insert the frothing whisk onto the shaft at the bottom of the jug. Place the jug securely onto the main unit.
4. **Placement:** Place the frother on a dry, flat, and stable surface near a power outlet.

# Small Beak to Aid Pouring

No matter how thick the froth is, no more stain on the jug.



Image: The detachable jug and whisk of the REDMOND Milk Frother, ready for cleaning or assembly.

## OPERATING INSTRUCTIONS

---

The REDMOND MMF-9103 offers 4 functions accessible via its one-touch control panel.

# Detachable Jug

Clean easier and use more frequently

Hand wash



Dish washer safe



Image: Close-up of the REDMOND Milk Frother's control panel with four function buttons.

## General Operation:

1. Ensure the frothing whisk is correctly inserted into the jug.
2. Pour milk or desired liquid into the jug. Observe the MIN/MAX indicators for appropriate fill levels. For optimal froth, use whole milk with fat content >3%.
3. Place the lid on the jug.
4. Plug the frother into a 120V power outlet.
5. Select your desired function by pressing the corresponding button on the control panel. The indicator light will illuminate.
6. The frother will automatically stop when the process is complete. A beep sound will indicate completion.

## Function Modes:

- **Hot Airy Milk Froth:** Ideal for lattes and cappuccinos. Fill milk up to the "MAX Frothing level" (150ml). Press the Hot Froth button (usually top-left, indicated by a frothing icon).
- **Hot Creamy Milk:** For hot milk or blending. Fill milk up to the "MAX Blending level" (300ml). Press the Hot Creamy Milk button (usually top-right, indicated by a cup icon).
- **Cold Fluffy Froth:** For iced lattes or macchiatos. Fill milk up to the "MAX Frothing level" (150ml). Press the Cold Froth button (usually bottom-right, indicated by a snowflake icon).
- **Hot Chocolate:** For rich hot chocolate. Add milk and chocolate powder up to the "MAX Blending level" (300ml).

Press the Hot Chocolate button (usually bottom-left, indicated by a chocolate bar icon).

# Large Capacity

**MAX**   
blending level

**MAX**   
frothing level

**MIN**  
frothing level



Image: Close-up of the inside of the jug showing MIN, MAX Frothing, and MAX Blending level indicators.

Your browser does not support the video tag.

Video: Official REDMOND Milk Frother demonstration showing various functions and ease of use.

## MAINTENANCE & CLEANING

Proper cleaning ensures the longevity and optimal performance of your frother.

1. **Unplug:** Always unplug the appliance from the power outlet before cleaning.
2. **Detachable Jug:** The stainless steel jug is detachable and dishwasher safe for easy cleaning. It can also be hand-washed with warm soapy water.
3. **Frothing Whisk:** Remove the whisk from the jug and rinse it under running water. Use a soft brush if necessary to remove any residue.
4. **Main Unit:** Wipe the exterior of the main unit with a soft, damp cloth. Do not immerse the main unit in water or any other liquid.
5. **Drying:** Ensure all parts are completely dry before reassembling or storing the frother.



Image: The detachable jug of the REDMOND Milk Frother shown in a dishwasher, highlighting its dishwasher-safe feature.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Frother does not turn on.	Not plugged in; power outage; jug not correctly placed.	Ensure frother is securely plugged in. Check power supply. Re-seat the jug firmly on the base.
Milk is not frothing or froth is poor.	Incorrect milk type (e.g., skim milk for hot froth); insufficient milk; whisk not properly installed.	Use whole milk (fat content >3%) for best frothing results. Ensure milk is between MIN and MAX frothing lines. Check if the whisk is securely attached.
Milk overflows.	Jug overfilled.	Do not fill milk above the MAX indicator line for frothing or blending.
Burnt milk smell/residue.	Residue from previous use; milk left too long.	Clean the jug thoroughly after each use. Do not leave milk in the frother for extended periods.

## SPECIFICATIONS

---

- **Brand:** REDMOND
- **Model:** MMF-9103
- **Material:** Plastic, Stainless Steel
- **Color:** White
- **Dimensions (W x H):** 4.8" x 8.6"
- **Weight:** 2.7 Pounds
- **Capacity:** 10 Fluid Ounces (300ml) for heating; 5 Fluid Ounces (150ml) for frothing
- **Power Source:** Corded Electric
- **Voltage:** 120 Volts
- **Wattage:** 550 Watts
- **Special Features:** Detachable Jug, Dishwasher Safe Jug, Auto Shut-off

## WARRANTY & SUPPORT

---

For warranty information or technical support, please refer to the warranty card included in your product packaging or visit the official REDMOND website. Please have your model number (MMF-9103) and purchase details ready when contacting support.