Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GadgetMonster GDM-1023

GadgetMonster GDM-1023 Vlogging Stand with 10-inch LED Ring Light

INSTRUCTION MANUAL

Introduction

Thank you for choosing the GadgetMonster GDM-1023 Vlogging Stand. This manual provides detailed instructions for the assembly, operation, and maintenance of your new vlogging kit. Please read this manual carefully before use to ensure proper functionality and to maximize your product experience. Keep this manual for future reference.

Package Contents

Please check the package contents to ensure all items are present:

- 1 x 10-inch LED Ring Light
- 1 x Tripod Stand
- 1 x Phone Holder
- 1 x Remote Control (integrated with LED ring light cable)
- 1 x Instruction Manual

Product Overview

Familiarize yourself with the components of your GadgetMonster GDM-1023 Vlogging Stand.






Figure 1: Fully assembled GadgetMonster GDM-1023 Vlogging Stand, showing the 10-inch LED ring light, phone holder, and tripod stand.



Figure 2: Close-up front view of the 10-inch LED ring light with the phone holder mounted in the center.



Figure 3: Back view of the 10-inch LED ring light, illustrating the attached USB power cable and the inline remote control for light adjustments.

Setup Instructions

Follow these steps to assemble your vlogging stand:

1. **Unfold the Tripod:** Gently spread the legs of the tripod stand until they are fully extended and stable.
2. **Adjust Tripod Height:** Loosen the locking clamps on the tripod shaft to extend the stand to your desired

height (up to 160 cm). Securely tighten the clamps once the height is set.

3. **Attach the LED Ring Light:** Screw the 10-inch LED ring light onto the top of the tripod stand. Ensure it is firmly attached. The ring light features a ball joint for flexible positioning.
4. **Mount the Phone Holder:** Insert the phone holder into the center of the LED ring light. Adjust its angle and orientation as needed using the ball joint mechanism.
5. **Insert Your Phone:** Carefully place your smartphone into the adjustable phone holder. Ensure it is securely gripped.





Figure 4: The vlogging stand fully extended, demonstrating its adjustable height capability.





Figure 5: An angled view of the assembled vlogging stand, showing the phone securely mounted within the ring light.

Operating Instructions

To operate your LED ring light:

1. **Power Connection:** Connect the USB cable from the LED ring light to a compatible USB power source (e.g., a USB wall adapter, power bank, or computer USB port).
2. **Power On/Off:** Use the power button on the inline remote control to turn the LED ring light on or off.
3. **Adjust Brightness:** Use the '+' and '-' buttons on the remote control to increase or decrease the brightness of the LED light.
4. **Change Color Temperature:** Use the mode button on the remote control to cycle through different color temperature settings (e.g., warm, cool, natural light).
5. **Adjust Angle:** The LED ring light and phone holder can be rotated and tilted thanks to their ball joint articulation. Adjust them to achieve the optimal lighting and camera angle for your content.

Maintenance

To ensure the longevity and optimal performance of your vlogging stand:

- **Cleaning:** Use a soft, dry cloth to wipe down the LED ring light and tripod stand. Do not use abrasive cleaners or solvents.

- **Storage:** When not in use, collapse the tripod and store the vlogging stand in a dry, cool place away from direct sunlight and moisture.
- **Handling:** Avoid dropping the unit or subjecting it to strong impacts, as this may damage the LED components or mechanical parts.

Troubleshooting

If you encounter any issues, refer to the following common problems and solutions:

- **LED Ring Light Does Not Turn On:**
  - Ensure the USB cable is securely connected to a working power source.
  - Try a different USB power adapter or port.
  - Check if the power button on the remote control has been pressed.
- **Light Brightness or Color Temperature Cannot Be Adjusted:**
  - Verify that the remote control buttons are functioning correctly.
  - Ensure the unit is powered on.
- **Stand is Unstable:**
  - Ensure the tripod legs are fully extended and spread out.
  - Tighten all locking clamps on the tripod shaft.
  - Place the stand on a flat, stable surface.

Specifications

Feature	Specification
Model Number	GDM-1023
LED Ring Light Size	10 inches
Adjustable Height	Up to 160 cm
Product Dimensions	50 x 50 x 28 cm (assembled)
Product Weight	1 kg
Features	10-inch LED Ring, Remote Control, Tripod Mount, Ball Joint (Rotatable & Tiltable)

Warranty and Support

GadgetMonster products are designed for quality and reliability. This product comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation provided at the time of purchase or contact your retailer.
For technical support, troubleshooting assistance, or inquiries regarding your GadgetMonster GDM-1023 Vlogging Stand, please contact your point of purchase or visit the official GadgetMonster website for customer service information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09HKHJ16P

More documents and user manuals: **https://manuals.plus/**