

[Manuals.plus](#) /

› [Qaba](#) /

› Qaba 2-in-1 Foldable Kids Kitchen Step Stool and Toddler Standing Tower with Chalkboard, Model 312-058WT

Qaba 312-058WT

Qaba 2-in-1 Foldable Kids Kitchen Step Stool and Toddler Standing Tower with Chalkboard, Model 312-058WT

User Manual

1. INTRODUCTION

This manual provides essential information for the safe and proper use of your Qaba 2-in-1 Foldable Kids Kitchen Step Stool and Toddler Standing Tower. Please read all instructions carefully before assembly and use, and retain this manual for future reference.

This product is designed to assist children aged 3-6 years in reaching elevated surfaces such as kitchen countertops, sinks, and bathroom mirrors, promoting independence and engagement in household activities. It features a foldable design for convenient storage and an integrated chalkboard for creative play.



Image 1: Qaba 2-in-1 Foldable Kids Kitchen Step Stool in white with chalkboard feature.

2. SAFETY INFORMATION

- **Adult Supervision Required:** Always supervise children when they are using the step stool.
- **Age and Weight Limit:** Suitable for children aged 3-6 years. Maximum weight capacity is 110 lbs (50 kg). Do not exceed this limit.
- **Stable Surface:** Ensure the step stool is placed on a flat, stable, and level surface before use.
- **Lockable Handrail:** Always ensure the lockable handrail is securely engaged before a child uses the stool.
- **No Climbing:** Instruct children not to climb on the outside of the stool or stand on the top rail.
- **Keep Clear:** Ensure the area around the stool is clear of obstructions to prevent tripping hazards.
- **Assembly:** Ensure all parts are correctly assembled and fasteners are tightened before use. Regularly check for loose parts.
- **Chalkboard:** The chalkboard is removable. Ensure it is securely attached if in use, or stored safely when not.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Main frame components (side panels, crossbars)
- Step platform
- Lockable handrail assembly
- Removable chalkboard
- Assembly hardware (screws, nuts, bolts, hinges)
- Instruction manual

4. SETUP AND ASSEMBLY

Assembly is required. Please follow these steps carefully. It is recommended to have a second person assist during certain steps.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Side Panels:** Attach the crossbars between the two main side panels using the provided hardware. Ensure all connections are secure.
3. **Install Step Platform:** Secure the step platform into its designated position. Ensure it is level and firmly attached.
4. **Attach Lockable Handrail:** Install the lockable handrail mechanism according to the diagrams. Test the locking function to ensure it operates smoothly and securely.
5. **Mount Chalkboard:** The chalkboard can be attached to the back of the tower. Note that for folding, the chalkboard may need to be removed (refer to the "Folding and Storage" section).
6. **Final Check:** Before first use, double-check all screws and connections to ensure they are tight and secure.

FOLDABLE DESIGN

Easy to store and move



Remove the pedal screw
and chalkboard first

Image 2: Illustration of the foldable design, indicating the removal of the pedal screw and chalkboard for compact storage.

5. OPERATING INSTRUCTIONS

5.1 Using the Step Stool

1. **Placement:** Position the step stool on a flat, stable surface near the desired countertop, sink, or other elevated area.
2. **Child Entry:** Guide your child to step onto the platform. Ensure they are centered and stable.
3. **Secure Handrail:** Always ensure the lockable handrail is properly engaged to provide a secure enclosure for your child.
4. **Supervision:** Maintain constant adult supervision while the child is on the step stool.



Image 3: A child safely using the Qaba step stool at a kitchen counter with adult supervision.

5.2 Folding and Storage

The step stool features a foldable design for compact storage. To fold the unit:

1. **Remove Chalkboard:** If attached, carefully remove the chalkboard from its position.
2. **Loosen Pedal Screw:** Locate and loosen the designated pedal screw (as indicated in Image 2) that secures the step platform.
3. **Fold Components:** Gently fold the side panels inward and the step platform upwards until the unit is flat.
4. **Secure for Storage:** Ensure all folding mechanisms are engaged to keep the unit in its compact form. Store in a dry, safe place.

SAFE MATERIAL & STURDY



▲ Lockable Handrail

▼ With non-slip mat



Image 4: Details of the lockable handrail and non-slip mat for enhanced safety.

5.3 Using the Chalkboard

The removable chalkboard provides an additional activity for children. Use standard chalk for drawing and a soft, damp cloth for cleaning. Ensure the chalkboard is securely attached if used on the tower, or placed on a stable surface if removed for play.

6. MAINTENANCE

- **Cleaning:** Wipe the step stool with a soft, damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals that could damage the finish. Dry thoroughly after cleaning.
- **Regular Checks:** Periodically inspect all screws, bolts, and hinges to ensure they are tight. Tighten any loose fasteners immediately.
- **Storage:** When not in use, store the step stool in a dry environment away from direct sunlight or extreme temperatures to prevent material degradation.
- **Damage:** If any part of the step stool becomes damaged, discontinue use immediately and contact customer

support for replacement parts or advice.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Stool feels unstable or wobbly.	Loose fasteners; uneven surface.	Tighten all screws and bolts. Ensure the stool is on a flat, level surface.
Difficulty folding the stool.	Chalkboard or pedal screw not removed/loosened.	Ensure the chalkboard is removed and the pedal screw is loosened as per folding instructions.
Handrail does not lock securely.	Improper assembly; obstruction in locking mechanism.	Check handrail assembly. Ensure no debris is blocking the locking mechanism.

8. SPECIFICATIONS

Model Name: 312-058WT

Brand: Qaba

Material: Engineered Wood

Color: White

Product Dimensions (Overall): 22.25" L x 22.25" W x 37" H

Folded Size: 22.25" L x 3.25" W x 37" H

Suitable Age: 3-6 Years Old

Weight Capacity: 110 lbs (50 kg)

Special Features: Chalkboard, Foldable Design, Lockable Handrail

Assembly Required: Yes

UPC: 196393062364



Image 5: Detailed dimensions of the Qaba step stool.

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the purchase documentation or contact the retailer where the product was purchased. Keep your proof of purchase for any warranty claims.

Manufacturer: Aosom LLC

© 2023 Qaba. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09HKTX1WP>

More documents and user manuals: **<https://manuals.plus/>**