

[manuals.plus](#) /› [BLAUX](#) /› **BLAUX Heatcore Personal Portable Heater - 450W Ceramic Electric Fan Heater User Manual**

## BLAUX 30448

# BLAUX Heatcore Personal Portable Heater

Model: 30448

Brand: BLAUX

## 1. INTRODUCTION AND OVERVIEW

Thank you for choosing the BLAUX Heatcore Personal Portable Heater. This compact 450W ceramic electric fan heater is designed to provide efficient and targeted warmth for small indoor spaces such as offices, under-desk areas, dorm rooms, and bedrooms. Its advanced ceramic heating technology ensures rapid heating, while integrated safety features offer peace of mind.

This manual provides essential information for the safe and effective use of your new heater. Please read it thoroughly before operation and retain it for future reference.

## 2. SAFETY INFORMATION

**WARNING: To reduce the risk of fire, electric shock, or injury, read and understand all instructions before using this heater.**

- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and keep them away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Discard heater, or return to authorized service facility for examination and/or repair.
- Do not use outdoors.
- To disconnect heater, turn controls to off, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.

- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable vapors or liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.

#### Integrated Safety Features:

- **Tip-Over Safety Switch:** The heater automatically shuts off if it is accidentally tipped over.
- **Overheat Protection:** The heater will automatically shut off if it detects overheating.
- **Flame-Resistant Materials:** Constructed with innovative flame-resistant materials for enhanced safety.



Image: The BLAUX Heatcore heater with icons illustrating its safety features: Overheat Protection, Tip-Over Safety Switch, Flame Resistant Materials, and a Main Safety Switch.

### 3. PRODUCT FEATURES

- **Powerful Heating:** Delivers 450W of heating power for rapid warmth.
- **5-Second Warming:** Experience quick heat output.
- **Ceramic Heating Technology:** Utilizes advanced ceramic elements for efficient and consistent heat.
- **Compact & Portable Design:** Lightweight and easy to move, ideal for personal spaces.
- **Air Filtration:** Features a unique filter that helps catch dust and hair, contributing to cleaner air.
- **Quiet Operation:** Designed for whisper-quiet warming, suitable for bedrooms and offices.
- **Sleek Aesthetics:** Modern design with fluid edges and metallic highlights.



Image: An exploded diagram of the BLAUX Heatcore heater, illustrating its internal components and key benefits such as cost savings, instant heat, high efficiency, and accurate spot heating.

## 4. PACKAGE CONTENTS

- BLAUX Heatcore Personal Portable Heater (Model: 30448)
- User Manual

## 5. SETUP

1. Unpack the heater and all accessories.
2. Place the heater on a firm, level surface. Ensure there are no obstructions to the air intake (rear) or exhaust (front).
3. Plug the power cord into a standard 120V AC electrical outlet.



Image: The BLAUX Heatcore Personal Portable Heater, ready for use.

## 6. OPERATING INSTRUCTIONS

The BLAUX Heatcore heater features a simple on/off control. There are no adjustable heat settings or timers on this model, providing consistent 450W heat output when active.

- Power On:** Locate the power switch, typically on the top or rear of the unit. Flip the switch to the 'ON' position. An indicator light may illuminate, and the fan will begin to operate, quickly distributing warm air.
- Power Off:** To turn off the heater, flip the power switch to the 'OFF' position. The fan may continue to run for a short period (e.g., 20 seconds) to cool down the heating elements before completely shutting off.



Image: The back of the BLAUX Heatcore heater, showing the power cord and the simple on/off switch.

#### Official Product Video:

Your browser does not support the video tag.

Video: An official product video from BLAUX demonstrating the Heatcore Personal Portable Heater.

## 7. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your heater.

- **Cleaning:** Always unplug the heater before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Filter Cleaning:** The heater includes a filter to catch dust and hair. Periodically check and clean the filter to maintain air quality and heating efficiency. Refer to the diagram below for filter location.
- **Storage:** When not in use, store the heater in a cool, dry place.



Image: An exploded diagram of the BLAUX Heatcore heater, useful for identifying the filter for cleaning.

## 8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Heater does not turn on.	Not plugged in; Power switch is off; Tip-over switch activated; Overheat protection activated.	Ensure power cord is securely plugged in; Flip power switch to 'ON'; Place heater on a flat, stable surface; Unplug, wait 10 minutes, then plug back in.
No heat output.	Overheat protection activated; Air intakes/exhaust blocked.	Unplug, wait 10 minutes, then plug back in; Ensure clear space around the heater.
Unusual odor.	New heater odor; Dust accumulation on heating element.	Initial use may produce a slight odor, which will dissipate; Clean the heater's exterior and filter.

## 9. SPECIFICATIONS

- Brand:** BLAUX
- Model Number:** 30448
- Power:** 450W
- Special Features:** Energy Efficient, Overheat Protection, Portable, Tip-Over Safety Switch
- Color:** White
- Form Factor:** Tower or Pedestal (Compact)
- Indoor/Outdoor Usage:** Indoor

- **Product Dimensions:** 5.4"D x 5.7"W x 8.3"H
- **Item Weight:** 1.54 pounds
- **Recommended Uses:** Home (small rooms, office, under desk, dorm, bedroom)
- **Heating Coverage:** Up to 100 sq. ft.
- **Burner Type:** Ceramic
- **Heat Output:** Up to 175 Degrees Celsius
- **Fuel Type:** Electric
- **Number of Speeds:** 1



Image: A diagram illustrating the compact dimensions of the BLAUX Heatcore heater.

## 10. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or visit the official BLAUX website. You may also contact BLAUX customer service directly for assistance with product inquiries, troubleshooting, or replacement parts.

### Contact Information:

- **Website:** [Visit the BLAUX Store on Amazon](#)
- **Email/Phone:** (Refer to product packaging or official website for current contact details)

