

Manuals+


[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Vileda](#) /

› **Vileda Steam PLUS XXL Steam Cleaner User Manual**

Vileda 4023103229754



Introduction

The Vileda Steam PLUS XXL is an advanced steam cleaner designed for efficient and hygienic cleaning of large floor areas. This powerful device eliminates up to 99.9% of bacteria and viruses without the need for harsh chemical cleaning agents, relying solely on the power of steam. Its extra-wide 40 cm wiping plate makes it particularly effective for covering extensive surfaces quickly.

This manual provides comprehensive instructions for the safe and effective use, maintenance, and troubleshooting of your Vileda Steam PLUS XXL Steam Cleaner. Please read it thoroughly before first use to ensure optimal performance and longevity of your appliance.



Image: The Vileda Steam PLUS XXL Steam Cleaner, showcasing its sleek design and wide cleaning head.

Important Safety Information

Always adhere to the following safety precautions to prevent injury or damage to the appliance:

- Do not direct steam at people, animals, or electrical appliances.
- Always unplug the appliance from the power outlet before filling, emptying, or cleaning.

- Do not leave the steam cleaner unattended while it is plugged in or operating.
- Use only clean tap water in the water tank. Do not add detergents, perfumes, or other chemicals.
- Keep the appliance out of reach of children.
- Ensure the power cord is not damaged and avoid tripping hazards.
- Allow the appliance to cool down completely before storing.

Product Components

Your Vileda Steam PLUS XXL package includes the following components:

- 1x Vileda Steam PLUS XXL Steam Cleaner unit
- 2x Replacement Microfiber Covers
- 1x User Manual (this document)
- 1x Carpet Glider attachment
- 1x 250ml Measuring Cup



Image: Visual comparison highlighting the larger cleaning head of the Steam PLUS XXL model compared to a standard Vileda Steam cleaner.

Setup

1. **Assembly:** Insert the handle into the main body of the steam cleaner until it clicks securely into place. Ensure all connections are firm.
2. **Attach Cleaning Pad:** Place one of the microfiber replacement covers onto the cleaning head. The cover attaches easily with hook-and-loop fasteners.
3. **Fill Water Tank:** Open the water tank cap. Use the provided 250ml measuring cup to fill the tank with clean tap water. Do not overfill. Close the cap securely.
4. **Carpet Glider (Optional):** If cleaning carpets, attach the carpet glider over the cleaning head with the

microfiber cover already in place.

Operating Instructions

Follow these steps for effective cleaning:

1. **Power On:** Plug the steam cleaner into a suitable electrical outlet. The appliance will begin to heat up.
2. **Heating Time:** The Vileda Steam PLUS XXL heats up rapidly, ready for use in just 15 seconds.
3. **Select Steam Setting:** Choose one of the three practical steam settings based on your floor type:
 - *Low Steam:* Ideal for delicate floors such as wood or parquet.
 - *Maximum Steam:* Best for harder floors like tiles.
 - *Carpet Function:* Use with the carpet glider to refresh carpets.
4. **Begin Cleaning:** Move the steam cleaner slowly and steadily over the floor surface. The swivel head allows for easy maneuverability around furniture and into corners.
5. **Room Change Feature:** If you unplug the device to move to another room, simply plug it back in. Thanks to its new temperature detection, it will be immediately ready for use without waiting for reheating.
6. **Refilling:** If steam production stops, unplug the unit, allow it to cool slightly, and refill the water tank as described in the Setup section.



Image: The Vileda Steam PLUS XXL actively cleaning a floor, demonstrating its steam output and wide cleaning path.



Image: An illustration highlighting the rapid 15-second heat-up time of the Vileda Steam PLUS XXL.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your steam cleaner:

- **Cleaning Pads:** The microfiber cleaning pads are machine washable. After each use, remove the pad and wash it according to its care label. Do not use fabric softener, as it can reduce the pad's absorbency.
- **Emptying Water Tank:** After each use, unplug the appliance and allow it to cool. Empty any remaining water from the tank.
- **Descaling:** Depending on water hardness in your area, periodic descaling may be necessary to prevent mineral buildup. Consult the full manual for detailed descaling instructions or use a steam cleaner-specific descaling solution.
- **Storage:** The Steam PLUS XXL is designed for space-saving storage. Simply detach the handle and store the unit in a small space or cabinet. Ensure the appliance is completely cool and dry before storing.

Troubleshooting

If you encounter issues with your Vileda Steam PLUS XXL, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No steam production.	Water tank is empty or not properly filled. Appliance not heated up.	Fill the water tank. Wait 15 seconds for the appliance to heat up.
Steam output is weak or inconsistent.	Mineral buildup (limescale) in the system.	Perform a descaling procedure as per the full manual.

Problem	Possible Cause	Solution
Appliance not turning on.	Not plugged in correctly. No power from outlet.	Ensure the power cord is securely plugged into a working outlet. Check circuit breaker.
Floor remains too wet.	Incorrect steam setting for floor type. Moving too slowly. Pad is oversaturated or dirty.	Select a lower steam setting. Move the cleaner at a steady pace. Change or clean the microfiber pad.

If the problem persists after trying these solutions, please contact Vileda customer support.

Specifications

Feature	Detail
Model Name	Dampfreiniger (Steam Cleaner)
Model Number	4023103229754
Product Dimensions	1 x 1 x 1 cm (approximate, as per input)
Product Weight	2.2 Kilograms
Form Factor	Handheld
Care Instructions	Easy to clean
Assembly Required	No (minimal assembly of handle)
Number of Pieces	3 (main unit, handle, cleaning head)
Batteries Required	No
Surface Recommendation	Tile (also suitable for wood, parquet, carpets)
Special Feature	Compact, Practical

Warranty and Support

Warranty: Your Vileda Steam PLUS XXL Steam Cleaner comes with a 2-year warranty from the date of purchase. Please retain your proof of purchase for any warranty claims. The warranty covers defects in materials and workmanship under normal use.

Customer Support: For further assistance, technical support, or warranty inquiries, please visit the official Vileda website or contact their customer service department. Contact details can typically be found on the Vileda website or on the product packaging.

For more information and to explore other Vileda products, visit the [Vileda Store on Amazon](#).

