



[Manuals.plus](#) /

› [Blackdot](#) /

› Blackdot Pro Wireless Earbuds User Manual

Blackdot 8885019220005

Blackdot Pro Wireless Earbuds User Manual

Model: 8885019220005

1. INTRODUCTION

This manual provides comprehensive instructions for the Blackdot Pro Wireless Earbuds. Please read this manual carefully before using the product to ensure proper operation and to maximize your user experience. Keep this manual for future reference.



Image 1.1: Blackdot Pro Wireless Earbuds in their charging case.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- Blackdot Pro Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- Eartips (Multiple Sizes)
- User Manual

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Blackdot Pro Wireless Earbuds.



Image 3.1: Detailed view of an earbud showing Pogo Pins, Multi-functional Button (MFB), and LED Indicator/Microphone.

- **Multi-functional Button (MFB):** Used for playback control, call management, and voice assistant activation.
- **LED Indicator/Microphone:** Provides status indications and captures audio for calls and voice commands.
- **Pogo Pins:** Charging contacts for the earbuds when placed in the charging case.

4. SETUP

4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case.

1. Place the earbuds into the charging case. Ensure the Pogo Pins align correctly.
2. Connect the USB charging cable to the Type-C port on the charging case and to a power source.
3. The LED indicator on the case will show charging status. Once fully charged, the indicator will change or turn off.
4. A full charge provides up to 52 hours of total listening time with the charging case.



Image 4.1: Visual representation of key features including Type-C charging and extended battery life.

4.2 Bluetooth Pairing

Follow these steps to pair your earbuds with a Bluetooth-enabled device:

1. Open the charging case. The earbuds will automatically enter pairing mode. The LED indicators on the earbuds will flash.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for available Bluetooth devices and select "Blackdot Pro" from the list.
4. Once connected, the LED indicators on the earbuds will stop flashing and remain solid or turn off, indicating successful pairing.
5. The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

5. OPERATING INSTRUCTIONS

5.1 Button Controls (MFB)

The Multi-functional Button (MFB) on each earbud controls various functions:

Action	Function
Single Press	Play/Pause Music, Answer Call
Double Press (Left Earbud)	Previous Track
Double Press (Right Earbud)	Next Track
Long Press (2 seconds)	Reject Call, Activate Voice Assistant (Google/Siri)
Long Press (5 seconds)	Power On/Off

5.2 Call Management

The earbuds feature built-in microphones for clear communication.

- **Answer Call:** Press the MFB once.
- **End Call:** Press the MFB once during a call.
- **Reject Call:** Long press the MFB for 2 seconds.




Image 5.1: Illustration of call handling and voice assistant functionality.

5.3 Voice Assistant

Activate your device's voice assistant (Google Assistant or Siri) by long-pressing the MFB for 2 seconds. This allows for hands-free control and commands.

6. MAINTENANCE

Proper maintenance ensures the longevity and performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive materials or harsh chemicals. Gently clean the Pogo Pins and mesh areas to prevent debris buildup.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Water Resistance:** The earbuds are water-resistant. Avoid submerging them in water or exposing them to excessive moisture. Dry them thoroughly if they get wet.

7. TROUBLESHOOTING

If you encounter issues, refer to the following common solutions:

Problem	Solution
---------	----------

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget "Blackdot Pro" from your device's Bluetooth list and re-pair.
Only one earbud working	Place both earbuds back into the charging case, close the lid, wait a few seconds, then take them out again. Ensure both are charged.
No sound	Check device volume. Ensure earbuds are connected. Try playing audio from a different application.
Charging issue	Verify the charging cable and power adapter are working. Clean the charging contacts (Pogo Pins) on the earbuds and in the case.

8. SPECIFICATIONS

Feature	Detail
Model Number	8885019220005
Connectivity	Bluetooth 5.3
Microphones	2 x Built-in Microphones
Battery Life (Total with Case)	Up to 52 hours
Control Type	Button/Touch Control, Voice Control
Water Resistance	Water Resistant
Material	Plastic
Dimensions	4.4 x 4.4 x 3.5 cm
Weight	150 g
Compatible Devices	Mobile Phones, Laptops, Tablets, Smart Speakers, etc.

9. WARRANTY AND SUPPORT

Blackdot products are designed for reliability and performance. For warranty information or technical support, please refer to the official Blackdot website or contact customer service through your purchase platform.

For further assistance, visit: [Blackdot Store on Amazon](#)