

[Manuals.plus](#) /

> [GUESS](#) /

> GUESS Cut Thru Dial Bracelet Watch Instruction Manual

GUESS GW0324G1

GUESS Cut Thru Dial Bracelet Watch

Model: GW0324G1

PRODUCT OVERVIEW

The GUESS Cut Thru Dial Bracelet Watch (Model GW0324G1) is a sophisticated timepiece designed for men. It features a silver-tone stainless steel bracelet with a pilot buckle closure, ensuring a secure fit. The watch boasts a bold chrono-look with a striking blue dial accented with silver and black elements. A distinctive cut-through dial design highlights the contrast second hand and pushers. The robust 48MM stainless steel case is equipped with a durable mineral glass crystal. This watch is water resistant up to 50 meters (165 feet), making it suitable for short periods of recreational swimming, but not for diving or snorkeling.



Front view of the GUESS Cut Thru Dial Bracelet Watch, showcasing its blue dial and silver-tone bracelet.

Initial Setup and Time Adjustment

Your GUESS watch comes with a pre-installed lithium metal battery. To set the time:

1. **Pull out the crown:** Locate the crown on the right side of the watch case. Gently pull it out to the time-setting position.
2. **Adjust the time:** Rotate the crown clockwise or counter-clockwise to move the hour and minute hands to the correct time.
3. **Push in the crown:** Once the time is set, push the crown back into its original position to start the watch movement.

Bracelet Adjustment

The stainless steel bracelet features a pilot buckle closure. For optimal comfort and fit, the bracelet may need to be adjusted by removing or adding links. This procedure typically requires specialized tools and is best performed by a qualified jeweler or watch technician.



The watch worn on a wrist, demonstrating its size and fit.

OPERATING INSTRUCTIONS

Basic Timekeeping

The watch displays hours, minutes, and seconds. The bold chrono-look design includes sub-dials that provide additional timekeeping functions, such as 24-hour display and day/date indicators, depending on the specific movement. Refer to the detailed markings on the dial for specific sub-dial functions.

Water Resistance

This watch is water resistant to 50 meters (165 feet). This rating means the watch is suitable for short periods of recreational swimming, such as in a pool or shallow water. It is *not* suitable for diving, snorkeling, or high-impact water sports. Avoid operating the crown or pushers when the watch is wet or submerged to prevent water ingress.

MAINTENANCE

Cleaning Your Watch

To maintain the appearance of your watch, wipe the case and bracelet regularly with a soft, dry cloth. For stainless steel components, a slightly damp cloth can be used, followed by immediate drying. Avoid using chemical cleaners, abrasive materials, or solvents, as these can damage the watch's finish and seals.

Battery Replacement

The watch is powered by one lithium metal battery. When the watch stops or the second hand begins to skip, it indicates that the battery needs replacement. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and functionality, especially for water resistance.

Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. Keeping it in its original box or a watch case can help protect it from dust and scratches.



Side profile of the watch, showing the crown and pushers.

TROUBLESHOOTING

Common Issues and Solutions

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Watch stops or runs intermittently.	Low or dead battery.	Replace the battery. Consult a professional watch technician.
Time is incorrect.	Crown is not fully pushed in after setting.	Ensure the crown is fully pushed into the case. Reset the time if necessary.
Condensation inside the crystal.	Exposure to extreme temperature changes or water ingress.	Immediately take the watch to a qualified watch repair center. Do not attempt to dry it yourself.

SPECIFICATIONS

Model Number: GW0324G1

Case Diameter: 48MM

Case Material: Stainless Steel

Crystal Material: Mineral Glass

Bracelet Material: Stainless Steel

Clasp Type: Pilot Buckle Closure

Water Resistance: 50 meters (165 feet)

Battery Type: 1 Lithium Metal battery (included)

Product Dimensions: 7 x 5 x 7 inches

Item Weight: 12.24 ounces

WARRANTY AND SUPPORT

GUESS watches typically come with a manufacturer's warranty covering defects in materials and workmanship. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or visit the official GUESS Watches website. For support, repairs, or service inquiries, contact GUESS customer service or an authorized service center.

You can find more information and contact details on the official GUESS website: www.guesswatches.com

