Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Motorola XT2139-1

Motorola Edge 20 Lite XT2139-1 User Manual

Your comprehensive guide to setting up, operating, and maintaining your device.

1. Introduction

Welcome to the Motorola Edge 20 Lite user manual. This guide provides essential information to help you get the most out of your new smartphone. The Motorola Edge 20 Lite (Model XT2139-1) features a vibrant 6.7-inch 90Hz OLED display, a powerful 108MP triple camera system, 5G connectivity, and a long-lasting 5000 mAh battery.

Please read this manual carefully to ensure proper usage and to understand all the functionalities of your device.



Image 1.1: Front and back view of the Motorola Edge 20 Lite smartphone. The front displays a vibrant screen with a punch-hole camera, while the back shows the triple camera module and the Motorola logo.

2. Setup

2.1. Unboxing and Initial Inspection

Upon opening the package, ensure all components are present. Your Motorola Edge 20 Lite typically includes the smartphone, a charger, a USB cable, and a 128GB SD card. Inspect the device for any physical damage before proceeding.

2.2. SIM Card and SD Card Installation

The Motorola Edge 20 Lite supports Dual SIM functionality and includes a 128GB SD card for expanded storage. Locate the SIM tray on the side of the device. Use the provided SIM ejector tool to open the tray. Carefully place your Nano-SIM cards and the SD card into their respective slots, ensuring correct orientation. Gently push the tray back into the device until it clicks into place.



Image 2.1: Side view of the Motorola Edge 20 Lite, highlighting the camera module and the device's slim profile. The SIM tray is typically located on one of the side edges.

2.3. Charging the Device

Before first use, it is recommended to fully charge your device. Connect the USB cable to the charging port on your phone

and then to the power adapter. Plug the adapter into a wall outlet. The battery indicator on the screen will show charging progress. Note that some international models may come with a charger designed for specific regions (e.g., UK plug) and may require a compatible adapter for use in other regions. For optimal performance, use a charger and cable designed for your region.

2.4. Powering On and Initial Configuration

Press and hold the Power button (usually on the right side) until the Motorola logo appears. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, set up your Google account, and configure security features like fingerprint unlock or a PIN/pattern.

3. Operating Your Device

3.1. Display and Navigation

Your Motorola Edge 20 Lite features a 6.7-inch 90Hz OLED display, providing smooth visuals and vibrant colors. Navigate the interface using touch gestures: tap to select, swipe to scroll, pinch to zoom. The 90Hz refresh rate enhances the fluidity of animations and scrolling.

3.2. Camera Usage

The device is equipped with a 108MP triple camera system on the rear and a front-facing camera. To open the camera, tap the camera icon on your home screen or lock screen. Select different modes (e.g., Photo, Video, Portrait, Night Vision) by swiping across the screen. Tap the shutter button to capture images or start/stop video recording. Adjust settings like flash, timer, and aspect ratio from the camera interface.



Image 3.1: Back view of the Motorola Edge 20 Lite, showcasing the 108MP triple camera array and the Motorola batwing logo.

3.3. Software Overview (Android 11)

The Motorola Edge 20 Lite runs on Android 11. This operating system offers features such as enhanced privacy controls, chat bubbles, screen recording, and improved media controls. Access your apps from the app drawer by swiping up from the home screen. Customize your device through the Settings menu.

3.4. Connectivity

- **5G/4G LTE:** Your device supports 5G and 4G LTE networks for fast mobile data. Ensure your SIM card and plan are compatible with 5G services in your region.
- **Wi-Fi:** Connect to wireless networks for internet access. Go to Settings > Network & internet > Wi-Fi to manage

connections.

- **Bluetooth:** Pair with wireless headphones, speakers, and other Bluetooth-enabled accessories via Settings > Connected devices.
- **GPS:** The device has built-in GPS for location services and navigation.

3.5. Audio

Please note that the Motorola Edge 20 Lite does not feature a 3.5mm headphone jack. Audio output is primarily through the USB-C port (with an adapter, if needed) or via Bluetooth wireless headphones.

3.6. Managing Applications

To close or switch between open applications, use the recent apps button or gesture (depending on your navigation settings). Swipe up from the bottom of the screen and hold to view recent apps, then swipe an app card up to close it. For force-stopping or uninstalling apps, go to Settings > Apps & notifications.

4. Maintenance

4.1. Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your phone. Avoid using harsh chemicals or abrasive materials, as these can damage the display or finish. If necessary, slightly dampen the cloth with water or a screen cleaner designed for electronics.

4.2. Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. Go to Settings > System > System update to check for available updates.

4.3. Battery Optimization

To maximize battery life (5000 mAh capacity, up to 32 hours talk time), consider these tips:

- Reduce screen brightness.
- Enable Adaptive Battery in Settings > Battery.
- Turn off Wi-Fi, Bluetooth, and GPS when not in use.
- Limit background app activity.

4.4. Storage Management

Your device comes with 128GB of internal storage, expandable with the included 128GB SD card. Regularly review your storage usage in Settings > Storage. Delete unnecessary files, uninstall unused apps, and move large media files to the SD card or cloud storage to free up space.

5. Troubleshooting

5.1. Common Issues and Solutions

- **Device Not Responding:** If your phone freezes, press and hold the Power button for about 10-15 seconds to force a restart.
- **Battery Drains Quickly:** Review battery optimization tips in Section 4.3. Check for apps consuming excessive

power in Settings > Battery.

- **Camera Performance Issues:** Ensure the camera lenses are clean. Try clearing the camera app's cache (Settings > Apps & notifications > Camera > Storage & cache > Clear cache).
- **Connectivity Problems:** For Wi-Fi or mobile data issues, try toggling airplane mode on and off. Restart your router for Wi-Fi problems.

5.2. Factory Reset

A factory reset will erase all data from your phone and restore it to its original factory settings. This can resolve persistent software issues. Before performing a factory reset, back up all important data. Go to Settings > System > Reset options > Erase all data (factory reset).

6. Specifications

Feature	Specification
Model Number	XT2139-1
Operating System	Android 11.0
Display	6.7 Inches OLED, 1080 x 2400 Resolution, 90Hz Refresh Rate
Processor (CPU)	MediaTek Kompanio 800T, 2E+3 MHz
RAM	6 GB
Internal Storage	128 GB (expandable with SD card)
Rear Camera	108MP Triple Camera
Front Camera	Yes
Battery Capacity	5000 Milliamp Hours
Phone Talk Time	32 Hours
Connectivity	5G, 4G LTE, Wi-Fi, GPS
Audio Jack	No 3.5mm headphone jack
Dimensions	6 x 4 x 2 inches
Item Weight	14.9 ounces (422 Grams)
Color	Black

7. Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official Motorola support website for your region. Please be aware that warranty coverage for international models may vary or be limited depending on your geographical location and the point of purchase.

For technical assistance, troubleshooting beyond this manual, or to inquire about repairs, please contact Motorola

customer support through their official website or designated service centers. Keep your proof of purchase handy when seeking support.

You can find more information and support resources on the official Motorola website: www.motorola.com

© 2023 Motorola. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09HN2ZRBS

More documents and user manuals: **https://manuals.plus/**