

ProCase PC-08363111

ProCase Smart Case Instruction Manual

Model: PC-08363111

For iPad mini 7 A17 Pro 2024 / iPad Mini 6 2021 8.3 Inch

1. INTRODUCTION AND OVERVIEW

The ProCase Smart Case is a slim, lightweight, and protective hard back cover designed specifically for the 8.3-inch iPad Mini A17 Pro 2024 (Models: A2995, A2996, A2993) and iPad Mini 6th Gen 2021 (Models: A2567, A2568, A2569). This case offers robust protection against accidental drops and bumps while maintaining a minimal bulk profile. Its intelligent design incorporates features such as automatic sleep/wake functionality and a versatile tri-fold stand.



Figure 1: ProCase Smart Case for iPad mini.

2. PRODUCT FEATURES

- **Precise Compatibility:** Slim case designed for 8.3-inch iPad Mini A17 Pro 2024 (Model: A2995/A2996/A2993) and iPad Mini 6th Gen 2021 (Model: A2567 A2568 A2569). Please verify your iPad model number (found on the back of your device, starting with "Axxxx") to ensure proper fit.

Only Compatible with 8.3" iPad Mini A17 Pro 2024 & Mini 6th 2021

iPad	Model number
✓ iPad Mini A17 Pro 2024	A2993 A2995 A2996
✓ iPad Mini 6th Gen 2021	A2567 A2568 A2569



Find your iPad model here



Figure 2: iPad Model Compatibility Guide.

- **Ultra-Slim and Lightweight Design:** Adds minimal bulk to your device while providing excellent protection against accidental drops and bumps.
- **Translucent Frosted Back Cover:** Allows the original Apple icon to be visible while protecting your device from fingerprints and scratches.



Figure 3: Translucent Back Cover Detail.

- **Apple Pencil Support:** Supports 2nd Gen Apple Pencil's magnetic attachment and wireless charging capabilities. (Apple Pencil not included).



Support 2nd Gen Apple Pencil

Apple Pencil Is Not Included



Figure 4: Apple Pencil Charging Support.

- **Smart Functionality:** Supports auto Sleep/Wake feature and Touch ID unlock function. A strong magnet secures the case closure, allowing for easy snap on and off.



Auto Sleep / Wake Function



Figure 5: Auto Sleep/Wake Functionality.

- **Versatile Tri-fold Stand:** The front cover features a tri-fold design, providing dual standing positions for comfortable viewing and typing angles.
- **Full Access:** Precise cutouts ensure full access to all features, including cameras, speakers, ports, and buttons.



■ **Slim Fit**

■ **4 Reinforced Corners**

Perfect Fit, Great Protection

■ **Precise Cutouts**
Perfect Fit



Figure 6: Precise Cutouts and Reinforced Corners.

3. SETUP AND INSTALLATION

1. **Unpack the Case:** Carefully remove the ProCase Smart Case from its packaging.
2. **Align Your iPad:** Hold your iPad Mini and align it with the hard back shell of the case. Ensure the camera cutout and port openings on the case match those on your iPad.
3. **Snap into Place:** Gently press your iPad into the case, starting from one corner and working your way around. The case is designed to snap securely around all four corners of your device, providing comprehensive protection.
4. **Verify Fit:** Once installed, ensure that all buttons (power, volume) are accessible and functional, and that all ports (charging, speakers) are unobstructed.

4. OPERATING INSTRUCTIONS

- **Auto Sleep/Wake:** Simply open the front cover to automatically wake your iPad, and close it to put your iPad to sleep. This feature helps conserve battery life.
- **Using the Tri-fold Stand:** The front cover can be folded into two different standing positions:
 - **Viewing Mode:** Fold the front cover into a triangular stand to prop your iPad up at an angle ideal for watching videos, making video calls, or browsing.
 - **Typing Mode:** Fold the front cover into a lower, more acute angle to provide a comfortable incline for typing on the screen.



Figure 7: Stable Magnetic Stand for Viewing and Typing.

- **Apple Pencil Charging:** When using a 2nd Gen Apple Pencil, simply attach it magnetically to the side of your iPad while it is in the case. The case design allows for seamless wireless charging.

5. MAINTENANCE

To ensure the longevity and appearance of your ProCase Smart Case, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the case regularly with a soft, damp cloth to remove dust, fingerprints, and light smudges. Avoid using harsh chemicals or abrasive cleaners, as these may damage the material.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Sharp Objects:** Keep the case away from sharp objects that could scratch or puncture its surface.

6. TROUBLESHOOTING

If you encounter any issues with your ProCase Smart Case, consider the following common solutions:

- **Case Not Fitting Correctly:** Double-check your iPad model number against the compatible models listed in Section 2. Ensure the iPad is properly aligned and fully snapped into all four corners of the case.
- **Auto Sleep/Wake Not Working:** Ensure the front cover is fully closed and making proper contact with the iPad screen. Sometimes, a screen protector or a misaligned iPad can interfere with this function. Verify that the iPad's 'Lock/Unlock' setting is enabled (Settings > Display & Brightness > Lock/Unlock).
- **Apple Pencil Not Charging:** Ensure the Apple Pencil is correctly aligned and magnetically attached to the charging strip on the side of the iPad. Remove any other accessories that might obstruct the magnetic connection.
- **Scratches or Wear:** While the case offers protection, extreme impacts or abrasive surfaces can still cause cosmetic damage. Regular cleaning and careful handling can minimize wear.

7. SPECIFICATIONS

Attribute	Value
Product Dimensions	7.87 x 5.51 x 0.39 inches
Item Weight	4.7 ounces
ASIN	B09HQ4GRF6
Item Model Number	PC-08363111
Special Features	Slim Fit
Other Display Features	Wireless
Form Factor	Cover

Attribute	Value
Color	Navy
Manufacturer	Procase
Compatible Devices	8.3-inch Apple iPad Mini 6th Gen 2021 (Model numbers: A2567, A2568, A2569), iPad Mini 7th Gen 2024 (Model numbers: A2995, A2996, A2993)
Shell Type	Hard

8. WARRANTY AND SUPPORT

For information regarding warranty coverage, returns, or technical support for your ProCase Smart Case, please refer to the official ProCase website or contact their customer service directly. Contact details are typically provided on the product packaging or on the manufacturer's official online channels. You can visit the [ProCase Store on Amazon](#) for more information and support resources.

© 2025 ProCase. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

