

[Manuals.plus](#) /

› [Studio Halloween](#) /

› Studio Halloween Salem Witch Costume 4-6 Instruction Manual

Studio Halloween 21133_46

Studio Halloween Salem Witch Costume Instruction Manual

Model: 21133_46 | Size: Child Small (4-6)

1. INTRODUCTION

This manual provides instructions for the Studio Halloween Salem Witch Costume, designed for children aged 4-6. This costume is intended for dress-up and pretend play. Please read all instructions carefully before use to ensure proper handling and care.



Image 1.1: Studio Halloween Salem Witch Costume (Dress and Wig)

2. SETUP AND COMPONENTS

The Studio Halloween Salem Witch Costume includes the following components:

- One (1) Salem Witch Dress
- One (1) Red Curly Wig



Image 2.1: Included Costume Components

2.1 Unpacking

1. Carefully remove all items from the packaging.
2. Inspect the dress and wig for any damage or missing parts.
3. Retain packaging for future storage or reference.

3. OPERATING (WEARING THE COSTUME)

Follow these steps to properly wear the Salem Witch Costume:

1. **Dress:** Carefully put on the dress. Ensure it fits comfortably and does not restrict movement.
2. **Wig:** Place the wig on the head. Adjust it so that it sits securely and comfortably.

3.1 Safety Guidelines

- Ensure the costume does not impede vision or movement to prevent tripping hazards.
- Keep the costume away from open flames or heat sources.

- Adult supervision is recommended during wear.

4. MAINTENANCE AND CARE

Proper care will extend the life of your costume. Adhere to the following instructions:

4.1 Dress Care

- **Washing:** Hand Wash Only. Do not bleach. Do not tumble dry. Do not iron. Do not dry clean.
- **Drying:** Hang to dry in a well-ventilated area, away from direct sunlight.

4.2 Wig Care

- Gently comb the wig with a wide-tooth comb or your fingers to remove tangles.
- Do not wash the wig unless absolutely necessary, and if so, use cold water and a mild shampoo specifically for wigs.
- Allow the wig to air dry completely on a wig stand or similar support to maintain its shape.

4.3 Storage

Store the costume and wig in a cool, dry place, away from direct sunlight and moisture. Use the original packaging or a breathable garment bag to protect the costume from dust and damage.

MADE IN CHINA
TRACKING: SH202105



STUDIO HALLOWEEN

Materials: 100% Polyester.
Do not wash
Do not bleach
Do not dry clean
Do not iron.
Imported by
Studio Halloween, Inc.
550 Fillmore Ave.
Tombawanda, NY 14150
Please keep this packaging for future reference

WARNING: Keep away from fire.
Advertencia: Manténgase alejado del fuego.
Tener a la vista de los niños.
WARNING: Children's clothing parts.
No debe haber más de 3 partes.
Advertencia: No debe haber más de 3 partes.
Respecto al etiquetado: No debe haber más de 3 partes.
Respecto al etiquetado: No debe haber más de 3 partes.

STUDIO HALLOWEEN



Image for illustration only. Accessories shown not included, unless otherwise stated.

STYLE #21133

Salem Witch Boss Costume Child

INCLUDES

Dress and wig / robe, perruque

SIZE

SM



810073313767

265mm

435mm

365mm

58mm

12mm

5. TROUBLESHOOTING

- **Wig Tangles:** If the wig becomes tangled, gently detangle it using your fingers or a wide-tooth comb, starting from the ends and working upwards. Avoid pulling forcefully.
- **Costume Fit Issues:** Refer to the size specifications in Section 6. If the costume does not fit as expected, ensure the correct size was purchased.
- **Minor Damage (e.g., loose seams):** Small tears or loose seams can often be repaired with basic sewing techniques.

6. SPECIFICATIONS

Product Name	Salem Witch Costume
Brand	Studio Halloween
Model Number	21133_46
Size	Child Small (4-6)
Age Range Description	39-48" height, 26" chest, 23" waist, 27" hip, 20" inseam
Included Components	Dress, Wig
Material	Fiber (100% Polyester)
Care Instructions	Hand Wash Only
UPC	810073313767
ASIN	B09HQ8SXN2

7. WARRANTY INFORMATION

No specific warranty information is provided for this product. Please refer to the retailer's return policy or contact the point of purchase for details regarding returns or defects.

8. SUPPORT

For further assistance or inquiries regarding the Studio Halloween Salem Witch Costume, please contact the retailer from whom the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question