Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

realme realme 5w Speaker

realme Cobble Bluetooth Speaker Instruction Manual

Model: realme 5w Speaker

Introduction **What's in the Box** **Product Overview** **Setup** **Operation** **realme Link App** **Maintenance** **Troubleshooting** **Specifications** **Warranty & Support**

1. Introduction

Thank you for choosing the realme Cobble Bluetooth Speaker. This manual provides essential information for the safe and efficient use of your device. Please read it thoroughly before operating the speaker and retain it for future reference.



Image 1.1: Front view of the realme Cobble Bluetooth Speaker.

2. What's in the Box

Verify that all items are present in the package:

- realme Cobble Bluetooth Speaker
- Type-C Charging Cable
- User Guide

3. Product Overview

Familiarize yourself with the speaker's components and controls.

3.1. Controls and Indicators




Image 3.1: Side view of the speaker with labeled controls.

- **Microphone:** For hands-free calls.
- **Multi-function Button (M):** Controls playback, mode switching, and other features.
- **Power Button:** Turns the speaker on/off.
- **LED Indicator:** Displays status (pairing, charging, power).

3.2. Ports



Image 3.2: Close-up of the Type-C charging port.

- **Type-C Charging Port:** Used for charging the speaker.

4. Setup

4.1. Charging the Speaker

Before first use, fully charge the speaker. Use the provided Type-C charging cable.

1. Connect the Type-C cable to the speaker's charging port.
2. Connect the other end of the cable to a USB power adapter (not included).
3. The LED indicator will show charging status. A full charge takes approximately 2.5 hours.

4.2. Power On/Off

- **To Power On:** Press and hold the Power Button for 2 seconds. The LED indicator will light up.
- **To Power Off:** Press and hold the Power Button for 2 seconds. The LED indicator will turn off.

4.3. Bluetooth Pairing

Pair your realme Cobble speaker with your device for wireless audio playback.

1. Ensure the speaker is powered on and in pairing mode (LED indicator will flash).
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for "realme Cobble" in the list of available Bluetooth devices.
4. Select "realme Cobble" to connect. The LED indicator will turn solid blue once connected.

5. Operating Instructions

5.1. Music Playback

- **Play/Pause:** Short press the Multi-function Button.
- **Next Track:** Double press the Multi-function Button.
- **Previous Track:** Triple press the Multi-function Button.
- **Volume Control:** Adjust volume directly from your connected device.

5.2. Stereo Pairing (TWS)

Connect two realme Cobble speakers for an immersive stereo sound experience.



Image 5.1: Stereo pairing setup with two speakers.

1. Ensure both speakers are powered on and not connected to any device.
2. On one speaker (the primary), double press the Multi-function Button. It will enter TWS pairing mode.
3. The two speakers will automatically connect to each other. Once connected, the primary speaker's LED will flash, and the secondary speaker's LED will be solid.
4. Connect your device to the primary speaker via Bluetooth as described in Section 4.3.

5.3. Gaming Mode

Activate Gaming Mode for ultra-low latency audio, ideal for gaming and video playback.



Image 5.2: Speaker in use during gaming, highlighting low latency.

- **Activate Gaming Mode:** Press and hold the Multi-function Button for 2 seconds. You will hear an audio prompt.
- **Deactivate Gaming Mode:** Press and hold the Multi-function Button for 2 seconds again.

5.4. Equalizer Presets

Switch between different sound modes to suit your audio preference.

- **Switch Presets:** Short press the Multi-function Button twice rapidly.
- Available presets include: **Dynamic**, **Bass**, and **Bright**.

6. realme Link App

Enhance your experience by connecting your realme Cobble speaker to the realme Link App. The app allows for customization of settings, firmware updates, and more.




Image 6.1: realme Link App download information.



Image 6.2: realme Link App user interface for speaker control.

Download the realme Link App from:https://www.realme.com/app-download#realmeLink

7. Maintenance

7.1. Cleaning

- Wipe the speaker with a soft, dry cloth.
- Do not use harsh chemicals or abrasive cleaners.

7.2. Water Resistance (IPX5)



Image 7.1: Speaker demonstrating IPX5 water resistance.

The realme Cobble speaker is IPX5 water-resistant, meaning it can withstand splashes and light rain. Do not submerge the speaker in water.

7.3. Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.

8. Troubleshooting

Problem	Possible Solution
Speaker does not power on.	Ensure the speaker is charged. Connect to a power source and try again.
Cannot pair via Bluetooth.	◦ Ensure the speaker is in pairing mode (flashing LED). ◦ Make sure Bluetooth is enabled on your device. ◦ Move the speaker closer to your device (within 10 meters). ◦ Forget "realme Cobble" from your device's Bluetooth list and try pairing again.

Problem	Possible Solution
No sound or low volume.	◦ Increase volume on both the speaker (via connected device) and your audio source. ◦ Ensure the speaker is properly connected to your device.
Stereo Pairing (TWS) fails.	◦ Ensure both speakers are fully charged and not connected to any other device. ◦ Place speakers close to each other. ◦ Follow the TWS pairing steps carefully (Section 5.2).

9. Specifications

Detailed technical specifications for the realme Cobble Bluetooth Speaker.

Feature	Detail
Brand	realme
Model Name	realme 5w Speaker
Speaker Maximum Output Power	5 Watts
Connectivity Technology	Bluetooth
Audio Output Mode	Stereo
Material	Plastic
Product Features	Bass Boost, USB Port
Color	Black
Battery Average Life	9 Hours
Is Waterproof	True (IPX5 Water Resistant)
Maximum Range	10 meters
Control Method	Touch
Wireless Technology Type	Bluetooth
Power Source	Battery Powered
Audio Driver Type	Dynamic Driver
Item Dimensions (D x W x H)	4D x 11.3W x 9.7H Centimeters

Feature	Detail
Item Weight	280 Grams
Compatible Devices	Desktop, Gaming Console, Laptop, Smartphone, Tablet, Television
Battery Charge Time	2.5 Hours

Note: Battery charge time may vary based on charger and usage conditions. While product specifications list 6 hours, typical charging duration is approximately 2.5 hours.

10. Warranty and Support

The realme Cobble Bluetooth Speaker comes with a **1-Year Domestic Warranty** from the date of purchase. This warranty covers manufacturing defects.
For warranty claims, technical support, or further assistance, please contact realme customer service or visit the official realme support website.

- **Manufacturer:** Ganzhou Dehuida Technology Co., Ltd
- **Importer:** Oppo Mobiles India Private Limited

Product Video Overview

Your browser does not support the video tag.

Video 1: A brief overview of the realme Cobble Bluetooth Speaker, highlighting its key features and design.

© 2026 realme. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09HQZ56MQ

More documents and user manuals: **https://manuals.plus/**