



Manuals.plus /

› Cloudeck /

› Cloudeck MSJ01A Mouse Jiggler & Auto Clicker Instruction Manual

Cloudeck MSJ01A

Cloudeck MSJ01A Mouse Jiggler & Auto Clicker Instruction Manual

Model: MSJ01A

PRODUCT OVERVIEW

The Cloudeck MSJ01A is a versatile 2-in-1 device designed to prevent your computer from entering sleep mode and to perform continuous mouse clicks automatically. It is recognized as a standard mouse by your computer's operating system, ensuring it remains undetectable by IT monitoring systems. This device is ideal for maintaining computer activity during long meetings, downloads, or other tasks where continuous presence is required, and can also assist in gaming or online purchasing with its auto-click function.

KEY FEATURES

- **Unique 2-In-1 Design:** Functions as both a mouse mover to prevent sleep/hibernation and an auto clicker for continuous clicking.
- **100% Undetectable:** Recognized as a regular mouse, ensuring it cannot be detected by IT departments.
- **Auto High-Frequency Click Technology:** Provides continuous clicks at a rate of 5 times per second.
- **Plug & Play:** No software or drivers required for installation.
- **Universal Compatibility:** Supports Windows, macOS, Linux, and Android operating systems.
- **Non-Slip Design:** Features thoughtful non-slip pads on the back for stability.

WHAT'S IN THE BOX

- 1 x Cloudeck MSJ01A Mouse Jiggler Device
- 1 x USB Cable

SETUP INSTRUCTIONS

1. **Connect the Device:** Plug the provided USB cable into the Cloudeck MSJ01A device and then into an available USB port on your computer or a 5V USB power adapter.

Safe and 100% Undetectable

Latest developments
We work as a "USB Mouse"



Setting up a device
We're setting up 'USB Mouse'.



Drive-free



Security



Undetectable



Image: The Cloudeck Mouse Jiggler connected to a laptop, showing the USB cable plugged into the device and the laptop.

2. **Place Your Mouse:** Place your optical mouse directly on the circular rotating platform of the Cloudeck MSJ01A device. Ensure the optical sensor of your mouse is centered over the rotating part for optimal movement detection.

HOW TO USE?



Image: A visual guide demonstrating the correct placement of a mouse on the jiggler for both jiggle and continuous click modes.

3. **Power On:** The device will power on automatically once connected.

OPERATING INSTRUCTIONS

The Cloudeck MSJ01A features two primary modes: Mouse Jiggler (Random Jiggler Mode) and Auto Clicker (Continuous Click Mode). These modes can be easily switched using the button on the device.

1. Switching Modes:

- **Single Press:** Press the button once to activate the *Random Jiggler Mode*. In this mode, the device will simulate subtle, random mouse movements to keep your computer active.
- **Double Press:** Double-press the button to switch to *Auto Click Mode*. In this mode, the device will continuously click at the current mouse pointer location approximately 5 times per second.
- **Turn Off:** Press the button again to turn off the device and stop all functions.



Image: Step-by-step visual instructions for connecting the device, activating Random Jiggler Mode with a single press, activating Auto Click Mode with a double press, and turning off the device.

2. **Mouse Jiggler Function:** When in Random Jiggler Mode, the device will gently move your mouse cursor across the screen at random intervals, preventing your computer from going to sleep or activating screen savers. This is ideal for maintaining an active status during periods of inactivity.

Your browser does not support the video tag.

Video: Demonstrates the 2-in-1 functionality of the Cloudeck Mouse Jiggler, showing both the mouse movement and auto-click features in action.

3. **Auto Clicker Function:** In Auto Click Mode, the device will perform rapid, continuous clicks at the current position of your mouse cursor. This can be useful for repetitive tasks, gaming, or quickly securing online items.

Your browser does not support the video tag.

Video: Shows the EAXBUX Ultra-Slim Mouse Jiggler in operation, highlighting its undetectable nature and how it keeps the mouse active.

MAINTENANCE

- Keep the device clean and free from dust. Use a soft, dry cloth for cleaning.
- Avoid exposing the device to extreme temperatures or moisture.
- Do not attempt to disassemble or repair the device, as this will void the warranty.

TROUBLESHOOTING

- **Device not turning on:** Ensure the USB cable is securely connected to both the device and a powered USB port or adapter.
- **Mouse not moving/clicking:**
 - Verify your optical mouse is correctly placed with its sensor centered on the device's rotating platform.
 - Check if the device is in the correct mode (Jiggler or Auto Clicker) by pressing the button.
 - Ensure your mouse's optical sensor is clean and unobstructed.
- **Computer still going to sleep:** Confirm the device is powered on and actively moving the mouse. Check your computer's power settings to ensure they are not overriding the mouse activity.

SPECIFICATIONS

Attribute	Detail
Model Number	MSJ01A
Product Dimensions	13.78 x 1.57 x 0.04 inches
Item Weight	1.02 ounces
Connectivity Technology	USB
Movement Detection Technology	Optical
Compatibility	Windows, macOS, Linux, Android OS

WARRANTY AND SUPPORT

Cloudeck products are designed for reliability and performance. For any inquiries or support needs, please refer to the official Cloudeck website for dedicated after-sales service. Our support team aims to respond within 12 hours. Alternatively, you may contact us through Amazon messages for assistance.