

- › [Qaba](#) /
- › [Qaba Kids Play Kitchen Set Food Truck Dining Car Instruction Manual](#)

Qaba US350-0900131

Qaba Kids Play Kitchen Set Food Truck Dining Car Instruction Manual

Model: US350-0900131

Brand: Qaba

INTRODUCTION

Thank you for choosing the Qaba Kids Play Kitchen Set Food Truck Dining Car. This multi-functional playset is designed to provide an engaging and educational experience for children aged 3 to 6 years, fostering social skills, number recognition, and motor skills. Please read this manual thoroughly before assembly and use to ensure safe and correct operation.



Image: The Qaba Kids Play Kitchen Set Food Truck Dining Car, showcasing its full setup with various accessories.

SAFETY INFORMATION

This product is designed with safety in mind. Please observe the following guidelines:

- **Recommended Age:** Suitable for children aged 36 months to 6 years.
- **Material Safety:** Constructed from safe PP and ABS materials.
- **Rounded Edges:** All parts feature rounded edges to prevent injury during play.
- **Adult Supervision:** Always supervise children during play to ensure safe use of all components.

- **Choking Hazard:** Contains small parts. Not suitable for children under 3 years due to potential choking hazards.

PACKAGE CONTENTS

The Qaba Kids Play Kitchen Set includes a total of 50 pieces. Please verify that all items listed below are present before beginning assembly:


- Food Truck Playset Base and Structure
- Cashier Register
- Checkout Counter
- Menu Board with various food items (Pizza, Ice Cream, Hamburger, Chips, Hot Dog)
- Assorted Kitchen Supplies (pots, pans, utensils, cups, plates)
- Pretend Food Items (burger, pizza slice, hot dog, chicken leg, fries)
- Condiment Bottles (ketchup, salt, pepper)
- Storage Racks and Hooks
- Instruction Manual



Disk Rack



Operation Platform



Considerate Hooks



Colorful Accessories

Image: A comprehensive display of the 50 colorful accessories included with the Qaba Kids Play Kitchen Set, such as plates, cups, utensils, pots, pans, and various pretend food items.

ASSEMBLY INSTRUCTIONS

Assembly of the Qaba Kids Play Kitchen Set is straightforward. Follow the visual guides and ensure all connections are secure.

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the package contents list.
2. **Assemble Base Structure:** Connect the side panels to the bottom and top sections, ensuring they click into place securely.
3. **Attach Wheels:** Secure the simulated wheels to the designated slots on the base.
4. **Install Oven Door:** Insert the openable oven door into its frame. Ensure it swings freely and closes properly.
5. **Mount Push Handle:** Attach the push handle to the side of the playset.

6. **Place Countertops and Awning:** Position the main countertop, side shelves, and the 'Fast Food' awning.
7. **Arrange Accessories:** Place the cashier register, pots, pans, and other accessories onto the playset. Utilize the considerate hooks for hanging utensils.




Openable Oven Door



Push Handle



Simulated Wheel



Round Edge

Image: Close-up details of the playset, highlighting the openable oven door, the ergonomic push handle, simulated wheels for mobility, and the smooth, round edges designed for safety.

OPERATING INSTRUCTIONS

The Qaba Kids Play Kitchen Set offers interactive features for a realistic play experience.

Cashier Register Operation

- **Receipt Roll-up:** Press the button on the left side of the cashier register to simulate a receipt rolling up.
- **Drawer Pop-up:** Press the button on the right side of the cashier register to open the cash drawer.

Oven Operation

- **Open/Close Door:** The oven door can be opened and closed manually to place or remove pretend food items.
- **Control Knobs:** The front panel features decorative knobs that can be turned to simulate cooking adjustments.




Image: A composite image showing the menu board for customer orders, various kitchen supplies for the chef, and the interactive cashier register for cashier play.

MAINTENANCE

Proper care and maintenance will extend the life of your Qaba Kids Play Kitchen Set.

- **Cleaning:** Wipe down all surfaces with a damp cloth and mild soap as needed. Avoid harsh chemicals or abrasive cleaners.
- **Drying:** Ensure all parts are completely dry before storing to prevent moisture damage.

- **Storage:** When not in use, store the playset and all accessories in a clean, dry place. The playset is equipped with multiple racks, hooks, and an openable cabinet for organized storage.
- **Inspection:** Periodically check for any loose or damaged parts. Discontinue use if any damage is found and contact customer support for replacement parts if necessary.

TROUBLESHOOTING

If you encounter any issues with your Qaba Kids Play Kitchen Set, please refer to the following common solutions:

Problem	Possible Cause	Solution
Parts do not fit together	Incorrect orientation or misalignment.	Review assembly instructions carefully. Ensure parts are oriented correctly and apply gentle, even pressure.
Cashier register buttons not working	Mechanism jammed or debris present.	Check for any obstructions. Ensure buttons are pressed firmly and directly.
Playset is unstable	Loose connections or uneven surface.	Verify all assembly connections are secure. Place the playset on a flat, level surface.
Missing accessories	Items overlooked during unpacking.	Double-check all packaging materials. If still missing, contact Qaba customer support.

SPECIFICATIONS

- **Product Dimensions:** 31.25 inches (Length) x 13 inches (Width) x 35.75 inches (Height)
- **Item Weight:** 10.56 pounds
- **Model Number:** US350-0900131
- **Manufacturer Recommended Age:** 36 months - 6 years
- **Material:** PP and ABS plastic

35.75"



Image: A diagram illustrating the key dimensions of the Qaba Kids Play Kitchen Set, showing its length, width, and height for reference.





WARRANTY AND SUPPORT



For any questions, concerns, or to report missing/damaged parts, please contact Qaba customer support. Refer to your purchase documentation for specific warranty details and contact information.

You can typically find support contact details on the manufacturer's website or through the retailer where the product was purchased.

© 2025 Qaba. All rights reserved.

Related Documents - US350-0900131

	<p>Qaba Play Kitchen 350-196V80 Assembly Instructions for Kids</p> <p>Detailed assembly instructions for the Qaba 350-196V80 play kitchen. This guide includes parts lists, hardware, and step-by-step diagrams for safe assembly of this toy kitchen for children aged 3-8 years.</p>
	<p>Qaba 4-Piece Kids Table and Chair Set with Storage Bench - Model 312-001</p> <p>Assembly instructions, safety warnings, and maintenance guide for the Qaba 4-Piece Kids Table and Chair Set with Storage Bench (Model 312-001). This set is designed for children aged 3 years and older, with a maximum weight capacity of 25 Kg for chairs and table. The document includes bilingual (English/French) safety information and contact details for Aosom.</p>
	<p>Qaba 350-141V00 Kids Play Kitchen Set Assembly Instructions</p> <p>Comprehensive assembly guide for the Qaba 350-141V00 Kids Play Kitchen Set. This manual provides a detailed parts list, hardware inventory, and step-by-step instructions for adult assembly, ensuring a safe and fun play experience for children aged 3-6 years. Includes contact information for Aosom customer care.</p>
	<p>Qaba 3D0-016V00 Foam Climbing Blocks: Toddler Soft Play Set User Guide</p> <p>Essential safety, usage, and maintenance information for the Qaba 6-Piece Foam Climbing Blocks (models 3D0-016V00, 3D0-016V01, 3D0-016V02). This soft play set is designed for toddlers aged 1-3 years. Contact Aosom for support.</p>

 The image shows the cover of the assembly instructions for the Qaba Kids Desk and Chair Set with Drawer (Model: 312-136V80). It features a line drawing of the desk and chair. The Qaba logo is at the top left. The model number 312-136V80 is at the top right. There are warning and attention icons with text in English and Chinese.	<p>Qaba Kids Desk and Chair Set with Drawer - Assembly Instructions</p> <p>Official assembly instructions for the Qaba Kids Desk and Chair Set (Model: 312-136V80). Includes parts list, hardware details, step-by-step assembly guide, and safety warnings. Features a drawer for storage.</p>
 The image shows the cover of the assembly instructions for the Qaba 312-134V80 Kids Table and Chair Set. It features a line drawing of the table and chair. The Qaba logo is at the top left. The model number 312-134V80 is at the top right. There are warning and attention icons with text in English and Chinese.	<p>Qaba 312-134V80 Kids Table and Chair Set Assembly Instructions</p> <p>Official assembly instructions for the Qaba 312-134V80 Kids Table and Chair Set. Includes parts list, hardware details, step-by-step assembly guide, and care instructions. Suitable for ages 3+.</p>