

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Honsel](#) /
- › [Fischer & Honsel THOR 3-Light Suspension Lamp User Manual](#)

Honsel 60825



Fischer & Honsel THOR 3-Light Suspension Lamp

Model: 60825

INTRODUCTION

Thank you for choosing the Fischer & Honsel THOR 3-Light Suspension Lamp. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new lighting fixture. Please read these instructions carefully before installation and retain them for future reference.



Image: The Fischer & Honsel THOR 3-Light Suspension Lamp with three cylindrical white fabric shades and a chrome-plated metal bar.

SAFETY INSTRUCTIONS

Always follow basic safety precautions when installing, operating, or maintaining electrical products to reduce the risk of fire, electric shock, or injury.

- **Disconnect Power:** Always switch off the main power supply at the circuit breaker or fuse box before beginning installation or performing any maintenance.
- **Qualified Electrician:** Installation should be performed by a qualified electrician or a competent person in accordance with all local electrical codes and regulations.
- **Voltage:** Ensure the supply voltage is compatible with the fixture's requirements (230V).
- **Bulb Type:** Use only E27 bulbs with a maximum wattage of 40W per socket. Do not exceed the recommended wattage.
- **Dimmable Functionality:** If using dimmable bulbs, ensure your wall dimmer is compatible and installed correctly.
- **Handling:** Handle the fixture and bulbs with care to prevent damage.
- **Environment:** This fixture is designed for indoor use (IP20 protection class). Do not expose it to moisture or extreme temperatures.

PACKAGE CONTENTS

Please check that all components are present and undamaged before installation:

- 1 x Suspension Lamp (chrome-plated metal bar with three E27 sockets)

- 3 x Cylindrical White Fabric Shades
- Mounting Hardware (screws, wall plugs, etc.)
- Instruction Manual

Note: Light bulbs are not included and must be purchased separately.



Image: A close-up view of one of the cylindrical white fabric shades, highlighting its texture and integrated decor.

SETUP AND INSTALLATION

Follow these steps for proper installation of your suspension lamp. Ensure power is disconnected before proceeding.

1. **Prepare the Installation Area:** Choose a suitable location on the ceiling. Ensure the ceiling can support the weight of the fixture (2.41 kg).
2. **Mark Drilling Points:** Hold the mounting bracket (part of the suspension bar) against the ceiling at the desired location and mark the drilling points with a pencil.
3. **Drill Holes:** Drill holes at the marked points. Insert appropriate wall plugs if necessary.
4. **Secure Mounting Bracket:** Attach the mounting bracket to the ceiling using the provided screws.
5. **Electrical Connection:** Carefully connect the household electrical wires to the terminal block on the

fixture. Ensure correct polarity (Live, Neutral, Earth). If unsure, consult a qualified electrician.

6. **Attach Fixture to Bracket:** Secure the suspension lamp's main body to the mounting bracket, ensuring all wires are safely tucked away and not pinched.
7. **Install Light Bulbs:** Screw three E27 light bulbs (not included, max 40W each) into the sockets.
8. **Attach Fabric Shades:** Carefully attach the cylindrical fabric shades to the lamp's suspension points.
9. **Restore Power:** Once installation is complete and all connections are secure, restore power at the circuit breaker.

OPERATING INSTRUCTIONS

The Fischer & Honsel THOR suspension lamp is designed for straightforward operation.

- **Turning On/Off:** Operate the lamp using your standard wall switch connected to the fixture.
- **Dimming Functionality:** If you have installed dimmable E27 bulbs and a compatible wall dimmer, you can adjust the light intensity using the dimmer switch. Refer to your dimmer's instructions for specific operation.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your lamp.

- **Cleaning:** Disconnect power before cleaning. Wipe the chrome-plated metal parts with a soft, dry cloth. For the fabric shades, use a soft, slightly damp cloth or a lint roller to remove dust. Do not use abrasive cleaners or solvents.
- **Bulb Replacement:** Disconnect power before replacing bulbs. Allow old bulbs to cool completely. Unscrew the old bulb and screw in a new E27 bulb (max 40W). Ensure the new bulb is fully seated in the socket.
- **Inspection:** Periodically check the fixture for any signs of damage or loose connections. If any issues are found, disconnect power and consult a qualified technician.

TROUBLESHOOTING

If you encounter issues with your lamp, refer to the following common problems and solutions:

- **Light Does Not Turn On:**
 - Check if the power supply is connected and the wall switch is on.
 - Verify that the circuit breaker has not tripped.
 - Ensure bulbs are correctly installed and not faulty. Try replacing with a known working bulb.
 - Check electrical connections for looseness (only after disconnecting power).
- **Light Flickers:**
 - Ensure bulbs are fully screwed in.
 - If using dimmable bulbs, check compatibility with your dimmer switch.
 - Replace faulty bulbs.
- **Dimming Not Working:**

- Confirm that you are using dimmable E27 bulbs.
- Ensure your wall dimmer is compatible with the bulbs and correctly installed.

If problems persist after attempting these solutions, please contact customer support or a qualified electrician.

SPECIFICATIONS

Feature	Detail
Brand	Honsel
Model Number	60825
Manufacturer	Fischer & Honsel GmbH
Type	Suspension Lamp / Pendant Light
Material	Metal (chrome), Textile/Fabric
Color	White (shades), Shiny Chrome Silver (metal)
Dimensions (Overall)	Height: 150 cm, Width: 110 cm
Shade Diameter	16 cm (each)
Number of Bulbs	3
Socket Type	E27
Max. Wattage per Bulb	40 W
Dimmable	Yes (external via home installation with dimmable bulbs)
Voltage	230 V
Protection Class	IP20 (Class 2)
Weight	2.41 kg
Energy Label	E
Luminous Flux	10800 lumen (total, assuming 3x 40W equivalent)
Installation Type	Ceiling Mount / Semi-flush Mount
Specific Uses	Kitchen, Living Room



Image: The Fischer & Honsel THOR 3-Light Suspension Lamp with key dimensions indicated: 150cm height and 110cm width.

WARRANTY INFORMATION

Warranty information for this product is not available in the provided details. Please refer to your purchase documentation or contact the retailer for specific warranty terms and conditions.

CUSTOMER SUPPORT

Customer support contact details are not available in the provided information. For assistance, please contact the retailer from whom you purchased the product or visit the official Fischer & Honsel website for support options.

